

TRIPLE S *Customs*

EAGLE VISION 1993-1997 VEHICLE WIRING

WIRING INFORMATION: 1993 Eagle Vision

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
SECOND IGNITION WIRE	RED/WHITE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (+)	ORANGE/WHITE	Harness Behind Fuse Box
POWER DOOR UNLOCK (+)	PINK/PURPLE	Harness Behind Fuse Box
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOORS TRIGGER	TAN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE (20 Gauge)	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1994 Eagle Vision

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	PINK/BLACK, RED (20A)	Ignition Harness
STARTER WIRE	YELLOW/GOLD DOTS	Ignition Harness
IGNITION WIRE	DK. BLUE/GOLD DOTS	Ignition Harness
SECOND IGNITION WIRE	RED/WHT/GOLD DOTS	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER LOCK (+)	ORANGE/WHITE	Harness Behind Fuse Panel
POWER UNLOCK (+)	PINK/PURPLE	Harness Behind Fuse Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOORS TRIGGER	TAN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE (20 gauge wire)	Harness In Driver's Kick Panel
TACHOMETER WIRE	RED, WHITE, or BLACK	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Horn Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

- If the SRS (air bag) warning light comes on after remote starting the vehicle, find an 18gauge (NOT 12 gauge) RED/WHITE wire in the ignition harness and use an additional relay to power it as a third ignition wire.

WIRING INFORMATION: 1995 Eagle Vision

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	PINK/BLACK, RED (20A)	Ignition Harness
STARTER WIRE	YELLOW/GOLD DOTS	Ignition Harness
IGNITION WIRE	DK. BLUE/GOLD DOTS	Ignition Harness
SECOND IGNITION WIRE	RED/WHT/GOLD DOTS	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER LOCK (+)	ORANGE/WHITE	Harness Behind Fuse Panel
POWER UNLOCK (+)	PINK/PURPLE	Harness Behind Fuse Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOORS TRIGGER	TAN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE (20 gauge wire)	Harness In Driver's Kick Panel
TACHOMETER WIRE	RED, WHITE, or BLACK	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Horn Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> If the SRS (air bag) warning light comes on after remote starting the vehicle, find an 18gauge (NOT 12 gauge) RED/WHITE wire in the ignition harness and use an additional relay to power it as a third ignition wire. 		

WIRING INFORMATION: 1996 Eagle Vision

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	PINK/BLACK, RED (20A)	Ignition Harness
STARTER WIRE	YELLOW/GOLD DOTS	Ignition Harness
IGNITION WIRE	DK. BLUE/GOLD DOTS	Ignition Harness
SECOND IGNITION WIRE	RED/WHT/GOLD DOTS	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER LOCK (+)	ORANGE/WHITE	Harness Behind Fuse Panel
POWER UNLOCK (+)	PINK/PURPLE	Harness Behind Fuse Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOORS TRIGGER	TAN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE (20 gauge wire)	Harness In Driver's Kick Panel
TACHOMETER WIRE	RED, WHITE, or BLACK	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Horn Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> If the SRS (air bag) warning light comes on after remote starting the vehicle, find an 18gauge (NOT 12 gauge) RED/WHITE wire in the ignition harness and use an additional relay to power it as a third ignition wire. 		

WIRING INFORMATION: 1997 Eagle Vision

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	PINK/BLACK, RED (20A)	Ignition Harness
STARTER WIRE	YELLOW/GOLD DOTS	Ignition Harness
IGNITION WIRE	DK. BLUE/GOLD DOTS	Ignition Harness
SECOND IGNITION WIRE	RED/WHT/GOLD DOTS	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER LOCK (+)	ORANGE/WHITE	Harness Behind Fuse Panel
POWER UNLOCK (+)	PINK/PURPLE	Harness Behind Fuse Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DRIVER DOOR TRIGGER (-)	TAN	Harness In Driver's Kick Panel
PASSENGER DOORS TRIGGER	TAN/RED	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE (20 gauge wire)	Harness In Driver's Kick Panel
TACHOMETER WIRE	RED, WHITE, or BLACK	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	Horn Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door
<ul style="list-style-type: none"> If the SRS (air bag) warning light comes on after remote starting the vehicle, find an 18gauge (NOT 12 gauge) RED/WHITE wire in the ignition harness and use an additional relay to power it as a third ignition wire. 		