

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	RED/YELLOW	OEM Alarm Under Passenger Seat
POWER DOOR UNLOCK (-)	RED/BLUE	OEM Alarm Under Passenger Seat
PARKING LIGHTS (+)	RED/BLACK	OEM Alarm Under Passenger Seat
HEADLIGHTS (-)	BLUE/RED	Harness To The Left Of Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOMESUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	LT. GREEN/BLACK	OEM Alarm Under Passenger Seat
HOOD TRIGGER (-)	LT. GREEN	OEM Alarm Under Passenger Seat
TRUNK RELEASE (5-wire)	BLUE/RED	OEM Alarm Under Passenger Seat
FACTORY ALARM ARM		

**Notes:** ARMS WITH LOCK

### FACTORY ALARM DISARM

**Notes:** DISARMS WITH UNLOCK

DISARM NO UNLOCK (-)	BLUE	OEM Alarm Module Under Passenger Seat
TACHOMETER WIRE (AC)	BLUE	2-Pin Connector On Passenger's Side Of The Fire Wall
SPEED SENSE (AC)	ORANGE	At PCM Module Under Carpet At Passenger Footrest
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
LEFT FRONT SPEAKER (-)	BLUE/GREEN	Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Speaker	
RIGHT FRONT SPEAKER (-)	RED/GREEN	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Speaker	
LEFT REAR SPEAKER (-)	BLUE/YELLOW	Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	RED/YELLOW	Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7890, METRA 99-7898, METRA 99-7892		SCOSCHE HA02B/BCB, METRA 70-1720	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	RED/YELLOW	OEM Alarm Under Passenger Seat
POWER DOOR UNLOCK (-)	RED/BLUE	OEM Alarm Under Passenger Seat
PARKING LIGHTS (+)	RED/BLACK	OEM Alarm Under Passenger Seat
HEADLIGHTS (-)	BLUE/RED	Harness To The Left Of Steering Column
DOMESUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	LT. GREEN/BLACK	OEM Alarm Under Passenger Seat
HOOD TRIGGER (-)	LT. GREEN	OEM Alarm Under Passenger Seat
TRUNK RELEASE (5-wire)	BLUE/RED	OEM Alarm Under Passenger Seat
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	OEM Alarm Module Under Passenger Seat
TACHOMETER WIRE (AC)	BLUE	2-Pin Connector On Passenger's Side Of The Fire Wall
SPEED SENSE (AC)	ORANGE	At PCM Module Under Carpet At Passenger Footrest
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
LEFT FRONT SPEAKER (-)	BLUE/GREEN	Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Speaker	
RIGHT FRONT SPEAKER (-)	RED/GREEN	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Speaker	
LEFT REAR SPEAKER (-)	BLUE/YELLOW	Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	RED/YELLOW	Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7890, METRA 99-7898, METRA 99-7892		SCOSCHE HA02B/BCB, METRA 70-1720	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	RED/YELLOW	OEM Alarm Under Passenger Seat
POWER DOOR UNLOCK (-)	RED/BLUE	OEM Alarm Under Passenger Seat
PARKING LIGHTS (+)	RED/BLACK	OEM Alarm Under Passenger Seat
HEADLIGHTS (-)	BLUE/RED	Harness To The Left Of Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOME SUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	LT. GREEN/BLACK	OEM Alarm Under Passenger Seat
HOOD TRIGGER (-)	LT. GREEN	OEM Alarm Under Passenger Seat
TRUNK RELEASE (5-wire)	BLUE/RED	OEM Alarm Under Passenger Seat
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	OEM Alarm Module Under Passenger Seat
TACHOMETER WIRE (AC)	BLUE	2-Pin Connector On Passenger's Side Of The Fire Wall
SPEED SENSE (AC)	ORANGE	At PCM Module Under Carpet At Passenger Footrest
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	BLUE/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
LEFT FRONT SPEAKER (-)	BLUE/GREEN	Speaker	
LEFT FRONT SPEAKER (-)	GRAY/BLACK	Speaker	
RIGHT FRONT SPEAKER (-)	RED/GREEN	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/BLACK	Speaker	
LEFT REAR SPEAKER (-)	BLUE/YELLOW	Speaker	
LEFT REAR SPEAKER (-)	GRAY/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	RED/YELLOW	Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7890, METRA 99-7898, METRA 99-7892		SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	BLACK/BLUE	In 22-Pin Harness In Front Of Passenger Fuse Box
POWER DOOR UNLOCK (-)	ORANGE	In 22-Pin Harness In Front Of Passenger Fuse Box
PARKING LIGHTS (+)	RED/YELLOW	Harness To The Left Of Steering Column
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOMESUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	BLUE/GREEN	Harness At Driver's Fuse Box
HOOD TRIGGER (-)	YELLOW	Harness At Passenger Fuse Box
TRUNK RELEASE (+)	WHITE	Module Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Inside Driver's Door At Key Cylinder
TACHOMETER WIRE (AC)	BLUE	Plug At Drivers Shock Tower
SPEED SENSE (AC)	ORANGE	At Cruise Control Module Under Dash - Left of Column
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)			
AMP TURN ON (+)	YELLOW/WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE	Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Speaker	
LEFT REAR SPEAKER (-)	RED	Speaker	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	BLUE	Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7890, METRA 99-7898, METRA 99-7892		SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	BLACK/BLUE	In 22-Pin Harness In Front Of Passenger Fuse Box
POWER DOOR UNLOCK (-)	ORANGE	In 22-Pin Harness In Front Of Passenger Fuse Box
PARKING LIGHTS (+)	RED/YELLOW	Harness To The Left Of Steering Column
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOME SUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	BLUE/GREEN	Harness At Driver's Fuse Box
HOOD TRIGGER (-)	YELLOW	Harness At Passenger Fuse Box
TRUNK RELEASE (+)	WHITE	Module Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Inside Driver's Door At Key Cylinder
TACHOMETER WIRE (AC)	BLUE	Plug At Drivers Shock Tower
SPEED SENSE (AC)	ORANGE	At Cruise Control Module Under Dash - Left of Column
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)			
AMP TURN ON (+)	YELLOW/WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE	Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Speaker	
LEFT REAR SPEAKER (-)	RED	Speaker	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	BLUE	Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7868, SCOSCHE AA1574B		SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	BLACK/BLUE	In 22-Pin Harness In Front Of Passenger Fuse Box
POWER DOOR UNLOCK (-)	ORANGE	In 22-Pin Harness In Front Of Passenger Fuse Box
PARKING LIGHTS (+)	RED/YELLOW	Harness To The Left Of Steering Column
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOMESUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	BLUE/GREEN	Harness At Driver's Fuse Box
HOOD TRIGGER (-)	YELLOW	Harness At Passenger Fuse Box
TRUNK RELEASE (+)	WHITE	Module Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Inside Driver's Door At Key Cylinder
TACHOMETER WIRE (AC)	BLUE	Plug At Drivers Shock Tower
SPEED SENSE (AC)	ORANGE	At Cruise Control Module Under Dash - Left of Column
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)			
AMP TURN ON (+)	YELLOW/WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE	Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Speaker	
LEFT REAR SPEAKER (-)	RED	Speaker	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	BLUE	Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7868, SCOSCHE AA1574B		SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	BLACK/BLUE	In 22-Pin Harness In Front Of Passenger Fuse Box
POWER DOOR UNLOCK (-)	ORANGE	In 22-Pin Harness In Front Of Passenger Fuse Box
PARKING LIGHTS (+)	RED/YELLOW	Harness To The Left Of Steering Column
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOME SUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	BLUE/GREEN	Harness At Driver's Fuse Box
HOOD TRIGGER (-)	YELLOW	Harness At Passenger Fuse Box
TRUNK RELEASE (+)	WHITE	Module Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Inside Driver's Door At Key Cylinder
TACHOMETER WIRE (AC)	BLUE	Plug At Drivers Shock Tower
SPEED SENSE (AC)	ORANGE	At Cruise Control Module Under Dash - Left of Column
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
POWER ANTENNA (+)			
AMP TURN ON (+)	YELLOW/WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE	Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Speaker	
LEFT REAR SPEAKER (-)	RED	Speaker	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	BLUE	Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7868, SCOSCHE AA1574B		SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	WHITE/BLACK	Ignition Harness
ACCESSORY WIRE	YELLOW	Ignition Harness
KEYSENSE (-)	BLUE/WHITE	Ignition Harness
NEUTRAL SAFETY (-)	LIGHT GREEN	At PCM Module Under Carpet At Passenger Footrest
POWER DOOR LOCK (-)	BLACK/BLUE	In 22-Pin Harness In Front Of Passenger Fuse Box
POWER DOOR UNLOCK (-)	ORANGE	In 22-Pin Harness In Front Of Passenger Fuse Box
PARKING LIGHTS (+)	RED/YELLOW	Harness To The Left Of Steering Column
HEADLIGHTS (+)	RED/YELLOW	Harness At Steering Column
ALL DOOR TRIGGER (-)	BLACK/WHITE	OEM Alarm Under Passenger Seat
DOME SUPERVISION	USE ALL DOOR TRIGGER	
TRUNK TRIGGER (-)	BLUE/GREEN	Harness At Driver's Fuse Box
HOOD TRIGGER (-)	YELLOW	Harness At Passenger Fuse Box
TRUNK RELEASE (+)	WHITE	Module Behind Fuse Box
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Inside Driver's Door At Key Cylinder
TACHOMETER WIRE (AC)	BLUE	Plug At Drivers Shock Tower
SPEED SENSE (AC)	ORANGE	At Cruise Control Module Under Dash - Left of Column
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
REVERSE LIGHT (+)	GREEN/WHITE	At Gear Selector
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/YELLOW	At Driver Window Switch Inside Door
LEFT FRONT WINDOW DOWN	RED/BLUE	At Driver Window Switch Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE/YELLOW	Radio Harness	
RADIO SWITCHED	WHITE/RED	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
ILLUMINATION (+)	RED/BLACK	Radio Harness	
AMP TURN ON (+)	YELLOW/WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE	Speaker	
LEFT FRONT SPEAKER (-)	ORANGE	Speaker	
RIGHT FRONT SPEAKER (-)	YELLOW	Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Speaker	
LEFT REAR SPEAKER (-)	RED	Speaker	
LEFT REAR SPEAKER (-)	GREEN/WHITE	Speaker	
RIGHT REAR SPEAKER (-)	BLUE	Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6x9	Right-rear of trunk	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-7868, SCOSCHE AA1574B	SCOSCHE HA08B/BCB, METRA 70-1721	
Please verify all part numbers before ordering.		