

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------|
| None required | N/A | N/A |
| Please verify all part numbers before ordering. | | |

| AUDIO WIRING | | | |
|-------------------------|--------------|--------------------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|-----------------------------|------------------------------|
| METRA 99-9106 | METRA 70-1787, SCOSCHE VW03 | METRA 40-VW53, SCOSCHE VWA2B |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------------------------------------------------|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

| AUDIO WIRING | | | |
|-------------------------|--------------|--------------------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|-----------------------------|------------------------------|
| Not Available | METRA 70-1787, SCOSCHE VW03 | METRA 40-VW53, SCOSCHE VWA2B |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------------------------------------------------|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|-------------------------|--------------|--------------------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|-----------------------------|------------------------------|
| Not Available | METRA 70-1787, SCOSCHE VW03 | METRA 40-VW53, SCOSCHE VWA2B |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------------------------------------------------|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

| AUDIO WIRING | | | |
|-------------------------|--------------|--------------------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|-----------------------------|------------------------------|
| Not Available | METRA 70-1787, SCOSCHE VW03 | METRA 40-VW53, SCOSCHE VWA2B |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------------------------------------------------|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|-------------------------|--------------|--------------------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|-----------------------------|------------------------------|
| Not Available | METRA 70-1787, SCOSCHE VW03 | METRA 40-VW53, SCOSCHE VWA2B |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------|---------------------------------------------------|
| 12V CONSTANT WIRE | RED | Ignition harness |
| 12V IGNITION WIRE | BLACK | Ignition harness |
| STARTER WIRE | BLACK/RED | Ignition harness |
| SECOND STARTER WIRE | BLUE | Ignition harness |
| 12V ACCESSORY WIRE | YELLOW/BLACK | Ignition harness |
| PARKING LIGHTS (+) | GREEN/BLACK and GREEN/RED | At Headlight Switch |
| Notes: If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition | | |
| POWER DOOR LOCK (-) | BROWN/RED | At Harness Coming Into Vehicle From Driver's Door |
| POWER DOOR UNLOCK (-) | BROWN/YELLOW | At Harness Coming Into Vehicle From Driver's Door |
| Notes: Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors. | | |
| LEFT FRONT DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| LEFT REAR DOOR TRIGGER (-) | BROWN/WHITE | In Gray Connector Leading To Instrument Cluster |
| RIGHT FRONT DOOR TRIGGER (-) | BLACK/YELLOW | In Gray Connector Leading To Instrument Cluster |
| RIGHT REAR DOOR TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK TRIGGER (-) | RED/BLACK | In Gray Connector Leading To Instrument Cluster |
| HOOD TRIGGER (-) | BROWN/BLACK | In Gray Connector Leading To Instrument Cluster |
| TRUNK RELEASE (+) | RED/BROWN | At Trunk Release Switch |
| FACTORY ALARM ARM | Arms with lock | |
| FACTORY ALARM DISARM | Disarms with unlock | |
| TACHOMETER WIRE | Wire that is NOT BLACK/YELLOW, BROWN, or BROWN/BLACK | At Any Ignition Coil |
| BRAKE WIRE (+) | RED/BLACK | At Brake Pedal Switch |
| REVERSE LIGHT (+) | BLUE/RED | In Driver's Kick Panel |
| HORN TRIGGER (+) | BLACK/GREEN | Relay Under Dash On Driver's Side |
| LEFT FRONT WINDOW UP | Not recommended | |
| LEFT FRONT WINDOW DOWN | Not recommended | |
| RIGHT FRONT WINDOW UP | Not recommended | |
| RIGHT FRONT WINDOW DOWN | Not recommended | |
| LEFT REAR WINDOW UP | Not recommended | |
| LEFT REAR WINDOW DOWN | Not recommended | |
| RIGHT REAR WINDOW UP | Not recommended | |
| RIGHT REAR WINDOW DOWN | Not recommended | |

| INTERFACE | PART NUMBER | NOTES |
|-------------------------------------------------|-------------|-------------------------------------------------|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

| AUDIO WIRING | | | |
|-------------------------------------------------|-----------------------------|--------------------------|------------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED | Radio Harness | |
| RADIO GROUND | BROWN | Ground to chassis strap | |
| ILLUMINATION (+) | BLUE | Radio Harness | |
| POWER ANTENNA (+) | WHITE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | ORANGE/WHITE | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | GREEN/BLACK | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLACK/WHITE | Radio Harness or Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 5.25", 1" Tweeter | 6.5", 1" Tweeter | | |
| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | | ANTENNA ADAPTER OPTIONS |
| Not Available | METRA 70-1787, SCOSCHE VW03 | | METRA 40-VW53, SCOSCHE VWA2B |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.