

TRIPLE S *Customs*

**BUICK PARK AVENUE 1990-2005
VEHICLE WIRING**

WIRING INFORMATION: 1990 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch Or In Driver's Kick Panel
DOOR TRIGGER (-)	LT.BLUE or WHITE	Harness Low In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK	At Trunk Release switch
FACTORY ALARM ARM (-)	YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARKBLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION: 1991 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
TRUNK RELEASE (+)	LT.BLUE or BLACK/WHITE	At Trunk Release switch
FACTORY ALARM ARM (-)	YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARKBLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.

WIRING INFORMATION: 1992 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
TRUNK RELEASE (+)	LT.BLUE or BLACK/WHITE	At Trunk Release switch
FACTORY ALARM ARM (-)	YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARKBLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1993 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
TRUNK RELEASE (+)	LT.BLUE or BLACK/WHITE	At Trunk Release switch
FACTORY ALARM ARM (-)	YELLOW	Harness In Driver's Kick Panel
FACTORY ALARM DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARKBLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1994 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
If the vehicle has a trunk ajar indicator on the dash, a RED/BLACK wire can be found in the driver's kick panel for trunk trigger.		
DOOR TRIGGER (-)	DK.BLUE or WHITE	In Driver's Door Harness
TRUNK RELEASE (+)	BLACK/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	In Driver's Door Harness
TACHOMETER WIRE	PURPLE/WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1995 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (+)	LT. BLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	WHITE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
If the vehicle has a trunk ajar indicator on the dash, a RED/BLACK wire can be found in the driver's kick panel for trunk trigger.		
DOOR TRIGGER (-)	DK.BLUE or WHITE	In Driver's Door Harness
TRUNK RELEASE (+)	BLACK/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	In Driver's Door Harness
TACHOMETER WIRE	PURPLE/WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1996 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door Harness
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door Harness
PARKING LIGHTS (+)	BROWN	In Driver's Kick Panel
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	TAN (driver's door) DK.BLUE (passenger doors)	In Driver's Door Harness Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	In Driver's Door Harness
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	WHITE or LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1997 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1998 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 1999 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2000 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2001 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2002 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	Door Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	Door Module Inside Left Rear Door
RIGHT REAR WINDOW UP	DARK BLUE	Door Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	Door Module Inside Right Rear Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start.		

WIRING INFORMATION: 2003 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
DOOR TRIGGER (-)	WHITE	At Under Dash Light
To avoid the dome light delay of the door trigger wire, all 4 individual door trigger wires must be located and diode isolated. For the front driver's door use GRAY/BLACK at the module inside the driver's door. For the front passenger door use BLACK/WHITE at the module inside the passenger door. For the rear driver's side door use LT.BLUE/BLACK at the rear door module located under the center of the rear seat. For the rear passenger door use LT.GREEN/BLACK at the rear door module located under the center of the rear seat.		
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WHEN LOCKING DOORS WITH A DOOR OPEN	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	At Module Under Rear Seat
LEFT REAR WINDOW DOWN	BROWN	
RIGHT REAR WINDOW UP	DARK BLUE	
RIGHT REAR WINDOW DOWN	BROWN	
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2004 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
LEFT FRONT DOOR TRIGGER (-)	TAN	At Module Inside Left Front Door
RIGHT FRONT DOOR TRIGGER (-)	LT.GREEN	At Module Inside Right Front Door
LEFT REAR DOOR TRIGGER (-)	DK.BLUE/WHITE	At Module Under Rear Seat
RIGHT REAR DOOR TRIGGER (-)	YELLOW/BLACK	At Module Under Rear Seat
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WHEN LOCKING DOORS WITH A DOOR OPEN	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	At Module Under Rear Seat
LEFT REAR WINDOW DOWN	BROWN	
RIGHT REAR WINDOW UP	DARK BLUE	
RIGHT REAR WINDOW DOWN	BROWN	
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Buick Park Avenue

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	BLACK & YELLOW	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver's Door At Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver's Door At Switch
Relays must be used to trigger the door lock wires.		
PARKING LIGHTS (+)	BROWN	At Module To Right Of Steering Wheel Attached To Back Of Dash
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	At Light In Trunk
LEFT FRONT DOOR TRIGGER (-)	TAN	At Module Inside Left Front Door
RIGHT FRONT DOOR TRIGGER (-)	LT.GREEN	At Module Inside Right Front Door
LEFT REAR DOOR TRIGGER (-)	DK.BLUE/WHITE	At Module Under Rear Seat
RIGHT REAR DOOR TRIGGER (-)	YELLOW/BLACK	At Module Under Rear Seat
TRUNK RELEASE (-)	BLACK	At Release Switch
FACTORY ALARM ARM	ARMS WHEN LOCKING DOORS WITH A DOOR OPEN	
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver's Door Module Inside Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	Ignition coil
BRAKE WIRE (+)	LT.BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	Door Module Inside Left Front Door
LEFT FRONT WINDOW DOWN	BROWN	Door Module Inside Left Front Door
RIGHT FRONT WINDOW UP	DARK BLUE	Door Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	Door Module Inside Right Front Door
LEFT REAR WINDOW UP	DARK BLUE	At Module Under Rear Seat
LEFT REAR WINDOW DOWN	BROWN	
RIGHT REAR WINDOW UP	DARK BLUE	
RIGHT REAR WINDOW DOWN	BROWN	
This vehicle is equipped with the Pass-Key III immobilizer. This must be bypassed when installing a remote start system.		