

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	Body Control Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLACK/PURPLE	Body Control Module In Passenger Kick Panel
PARKING LIGHTS (+)	GRAY/GREEN	Parking Light Relay Located To The Right Of The Steering Column
Notes: Only use the parking light wire at the parking light relay. Do not use GRAY/BLACK, GRAY/RED, or GRAY/GREEN in the kick panel, even though they also test as parking light wire.		
HEADLIGHTS (-)	BROWN/RED	At Light Switch
DOOR TRIGGER WIRE (-)	GRAY	Body Control Module In Passenger Kick Panel
DOME SUPERVISION WIRE	USE DOOR TRIGGER	
TRUNK TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
TRUNK RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FUEL DOOR RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BROWN/PURPLE	Body Control Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN	Behind Instrument Cluster Or Engine Control Module By Driver Strut Tower
BRAKE WIRE (+)	BLACK/YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
LEFT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK	Radio Harness	
POWER ANTENNA WIRE	RED/WHITE	Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLUE	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	BROWN/GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under tray in trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2004, SCOSCHE GM1584B		METRA GMOS-06, SCOSCHE GM03	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	Body Control Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLACK/PURPLE	Body Control Module In Passenger Kick Panel
PARKING LIGHTS (+)	GRAY/GREEN	Parking Light Relay Located To The Right Of The Steering Column
Notes: Only use the parking light wire at the parking light relay. Do not use GRAY/BLACK, GRAY/RED, or GRAY/GREEN in the kick panel, even though they also test as parking light wire.		
HEADLIGHTS (-)	BROWN/RED	At Light Switch
DOOR TRIGGER WIRE (-)	GRAY	Body Control Module In Passenger Kick Panel
DOME SUPERVISION WIRE	USE DOOR TRIGGER	
TRUNK TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
TRUNK RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FUEL DOOR RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BROWN/PURPLE	Body Control Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN	Behind Instrument Cluster Or Engine Control Module By Driver Strut Tower
BRAKE WIRE (+)	BLACK/YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
LEFT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK	Radio Harness	
POWER ANTENNA WIRE	RED/WHITE	Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLUE	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	BROWN/GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under tray in trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2004, SCOSCHE GM1584B		METRA GMOS-06, SCOSCHE GM03	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	Body Control Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLACK/PURPLE	Body Control Module In Passenger Kick Panel
PARKING LIGHTS (+)	GRAY/GREEN	Parking Light Relay Located To The Right Of The Steering Column
Notes: Only use the parking light wire at the parking light relay. Do not use GRAY/BLACK, GRAY/RED, or GRAY/GREEN in the kick panel, even though they also test as parking light wire.		
HEADLIGHTS (-)	BROWN/RED	At Light Switch
DOOR TRIGGER WIRE (-)	GRAY	Body Control Module In Passenger Kick Panel
DOME SUPERVISION WIRE	USE DOOR TRIGGER	
TRUNK TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
TRUNK RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FUEL DOOR RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BROWN/PURPLE	Body Control Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN	Behind Instrument Cluster Or Engine Control Module By Driver Strut Tower
BRAKE WIRE (+)	BLACK/YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel

LEFT FRONT WINDOW UP

Notes: Not possible. Factory window module is attached to window motor

LEFT FRONT WINDOW DOWN

Notes: Not possible. Factory window module is attached to window motor

RIGHT FRONT WINDOW UP

Notes: Not possible. Factory window module is attached to window motor

RIGHT FRONT WINDOW DOWN

Notes: Not possible. Factory window module is attached to window motor

LEFT REAR WINDOW UP

Notes: Not possible. Factory window module is attached to window motor

LEFT REAR WINDOW DOWN

Notes: Not possible. Factory window module is attached to window motor

RIGHT REAR WINDOW UP

Notes: Not possible. Factory window module is attached to window motor

RIGHT REAR WINDOW DOWN

Notes: Not possible. Factory window module is attached to window motor

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK	Radio Harness	
POWER ANTENNA WIRE	RED/WHITE	Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLUE	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	BROWN/GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under tray in trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2004, SCOSCHE GM1584B		METRA GMOS-06, SCOSCHE GM03	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	Body Control Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLACK/PURPLE	Body Control Module In Passenger Kick Panel
PARKING LIGHTS (+)	GRAY/GREEN	Parking Light Relay Located To The Right Of The Steering Column
Notes: Only use the parking light wire at the parking light relay. Do not use GRAY/BLACK, GRAY/RED, or GRAY/GREEN in the kick panel, even though they also test as parking light wire.		
HEADLIGHTS (-)	BROWN/RED	At Light Switch
DOOR TRIGGER WIRE (-)	GRAY	Body Control Module In Passenger Kick Panel
DOME SUPERVISION WIRE	USE DOOR TRIGGER	
TRUNK TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
TRUNK RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FUEL DOOR RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BROWN/PURPLE	Body Control Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN	Behind Instrument Cluster Or Engine Control Module By Driver Strut Tower
BRAKE WIRE (+)	BLACK/YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
LEFT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK	Radio Harness	
POWER ANTENNA WIRE	RED/WHITE	Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLUE	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	BROWN/GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under tray in trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2004, SCOSCHE GM1584B		METRA GMOS-06, SCOSCHE GM03	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	BLACK/RED	Ignition Harness
IGNITION WIRE	BROWN	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	BLACK/BROWN	Body Control Module In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLACK/PURPLE	Body Control Module In Passenger Kick Panel
PARKING LIGHTS (+)	GRAY/GREEN	Parking Light Relay Located To The Right Of The Steering Column
Notes: Only use the parking light wire at the parking light relay. Do not use GRAY/BLACK, GRAY/RED, or GRAY/GREEN in the kick panel, even though they also test as parking light wire.		
HEADLIGHTS (-)	BROWN/RED	At Light Switch
DOOR TRIGGER WIRE (-)	GRAY	Body Control Module In Passenger Kick Panel
DOME SUPERVISION WIRE	USE DOOR TRIGGER	
TRUNK TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
TRUNK RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FUEL DOOR RELEASE (5-wire)	BLACK/RED	Body Control Module In Passenger Kick Panel
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	BROWN/PURPLE	Body Control Module In Passenger Kick Panel
TACHOMETER WIRE	GREEN	Behind Instrument Cluster Or Engine Control Module By Driver Strut Tower
BRAKE WIRE (+)	BLACK/YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Body Control Module In Passenger Kick Panel
LEFT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT FRONT WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
LEFT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW UP		
Notes: Not possible. Factory window module is attached to window motor		
RIGHT REAR WINDOW DOWN		
Notes: Not possible. Factory window module is attached to window motor		
INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK	Radio Harness	
POWER ANTENNA WIRE	RED/WHITE	Radio Harness	
LEFT FRONT SPEAKER (+)	BLUE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	BROWN/BLUE	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	YELLOW	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	BROWN/GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	BROWN/WHITE	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under tray in trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-2004, SCOSCHE GM1584B		METRA GMOS-06, SCOSCHE GM03	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			