

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	GRAY	Behind Instrument Cluster Or At Light In Trunk
TRUNK RELEASE (-)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHTIE or WHITE	At Distributor
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	LIGHT BLUE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	GRAY	Behind Instrument Cluster Or At Light In Trunk
TRUNK RELEASE (-)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness In Driver's Kick Panel
TACHOMETER WIRE	PURPLE/WHTIE or WHITE	At Distributor
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	LIGHT BLUE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	4", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE (Only on v	BROWN	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove one screw from left side of radio console
- 2 Remove 2 screws which secure right edge of the instrument cluster trim panel
- 3 Remove 2 screws from bottom of radio trim panel and 2 screws from right edge of radio trim panel
- 4 Move shifter to rearmost position
- 5 Pull right side of radio trim panel away from console and then slide left side out from under the instrument cluster trim panel.
- 6 Remove 4 screws which secure radio, unplug, and remove

### FRONT SPEAKER REMOVAL

#### DASH SPEAKER REMOVAL

**NOTE:** Factory speaker is a 4x6" speaker

- 1 Remove 2 screws from top of console trim panel and 3 screws from top of instrument cluster trim panel
- 2 Remove 2 screws from front of dash pad in defroster duct location.
- 3 Pull pad towards rear of car to release clips and remove pad.

#### DOOR PANEL REMOVAL

**NOTE:** If equipped with a factory BOSE system, factory speaker is a 4" speaker.

- 1 Remove 4 screws which secure the speaker grill and remove grill
- 2 Remove 6 screws from lower edge of door panel and one screw from rear edge of doorpanel.
- 3 Remove one screw from behind door latch handle in trim cup.
- 4 Pull panel off door and disconnect harnesses.
- 5 Remove 7mm bolts and 10mm bolts from galvanized plate which locates the door handle assembly in the center of the door.
- 6 Slide plate down and pull top of plate away from door.
- 7 Remove four 7mm bolts which secure BOSE enclosure to door. Disconnect harness and slide box out of door between top of steel plate and door structure.

### REAR SPEAKER REMOVAL

**NOTE:** Factory NON-BOSE speaker is a 6x9" speaker. BOSE-equipped vehicles have a 4" speaker in a BOSE enclosure.

- 1 Remove 4 screws from speaker grill and remove grill
- 2 Remove 4 screws securing speaker, unplug and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE (Only on v	BROWN	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove one screw from left side of radio console
- 2 Remove 2 screws which secure right edge of the instrument cluster trim panel
- 3 Remove 2 screws from bottom of radio trim panel and 2 screws from right edge of radio trim panel
- 4 Move shifter to rearmost position
- 5 Pull right side of radio trim panel away from console and then slide left side out from under the instrument cluster trim panel.
- 6 Remove 4 screws which secure radio, unplug, and remove

### FRONT SPEAKER REMOVAL

#### DASH SPEAKER REMOVAL

**NOTE:** Factory speaker is a 4x6" speaker

- 1 Remove 2 screws from top of console trim panel and 3 screws from top of instrument cluster trim panel
- 2 Remove 2 screws from front of dash pad in defroster duct location.
- 3 Pull pad towards rear of car to release clips and remove pad.

#### DOOR PANEL REMOVAL

**NOTE:** If equipped with a factory BOSE system, factory speaker is a 4" speaker.

- 1 Remove 4 screws which secure the speaker grill and remove grill
- 2 Remove 6 screws from lower edge of door panel and one screw from rear edge of doorpanel.
- 3 Remove one screw from behind door latch handle in trim cup.
- 4 Pull panel off door and disconnect harnesses.
- 5 Remove 7mm bolts and 10mm bolts from galvanized plate which locates the door handle assembly in the center of the door.
- 6 Slide plate down and pull top of plate away from door.
- 7 Remove four 7mm bolts which secure BOSE enclosure to door. Disconnect harness and slide box out of door between top of steel plate and door structure.

### REAR SPEAKER REMOVAL

**NOTE:** Factory NON-BOSE speaker is a 6x9" speaker. BOSE-equipped vehicles have a 4" speaker in a BOSE enclosure.

- 1 Remove 4 screws from speaker grill and remove grill
- 2 Remove 4 screws securing speaker, unplug and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE (Only on v	BROWN	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove one screw from left side of radio console
- 2 Remove 2 screws which secure right edge of the instrument cluster trim panel
- 3 Remove 2 screws from bottom of radio trim panel and 2 screws from right edge of radio trim panel
- 4 Move shifter to rearmost position
- 5 Pull right side of radio trim panel away from console and then slide left side out from under the instrument cluster trim panel.
- 6 Remove 4 screws which secure radio, unplug, and remove

### FRONT SPEAKER REMOVAL

#### DASH SPEAKER REMOVAL

**NOTE:** Factory speaker is a 4x6" speaker

- 1 Remove 2 screws from top of console trim panel and 3 screws from top of instrument cluster trim panel
- 2 Remove 2 screws from front of dash pad in defroster duct location.
- 3 Pull pad towards rear of car to release clips and remove pad.

#### DOOR PANEL REMOVAL

**NOTE:** If equipped with a factory BOSE system, factory speaker is a 4" speaker.

- 1 Remove 4 screws which secure the speaker grill and remove grill
- 2 Remove 6 screws from lower edge of door panel and one screw from rear edge of doorpanel.
- 3 Remove one screw from behind door latch handle in trim cup.
- 4 Pull panel off door and disconnect harnesses.
- 5 Remove 7mm bolts and 10mm bolts from galvanized plate which locates the door handle assembly in the center of the door.
- 6 Slide plate down and pull top of plate away from door.
- 7 Remove four 7mm bolts which secure BOSE enclosure to door. Disconnect harness and slide box out of door between top of steel plate and door structure.

### REAR SPEAKER REMOVAL

**NOTE:** Factory NON-BOSE speaker is a 6x9" speaker. BOSE-equipped vehicles have a 4" speaker in a BOSE enclosure.

- 1 Remove 4 screws from speaker grill and remove grill
- 2 Remove 4 screws securing speaker, unplug and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE (Only on v	BROWN	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DOOR TRIGGER (-)	WHITE	At Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use Door Trigger Wire
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN/WHITE	Harness In Driver's Kick Panel
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	PURPLE/WHITE or WHITE	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4544, SCOSCHE GM1508B	METRA 70-1677-1, SCOSCHE GM01B	Not required

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove one screw from left side of radio console
- 2 Remove 2 screws which secure right edge of the instrument cluster trim panel
- 3 Remove 2 screws from bottom of radio trim panel and 2 screws from right edge of radio trim panel
- 4 Move shifter to rearmost position
- 5 Pull right side of radio trim panel away from console and then slide left side out from under the instrument cluster trim panel.
- 6 Remove 4 screws which secure radio, unplug, and remove

### FRONT SPEAKER REMOVAL

#### DASH SPEAKER REMOVAL

**NOTE:** Factory speaker is a 4x6" speaker

- 1 Remove 2 screws from top of console trim panel and 3 screws from top of instrument cluster trim panel
- 2 Remove 2 screws from front of dash pad in defroster duct location.
- 3 Pull pad towards rear of car to release clips and remove pad.

#### DOOR PANEL REMOVAL

**NOTE:** If equipped with a factory BOSE system, factory speaker is a 4" speaker.

- 1 Remove 4 screws which secure the speaker grill and remove grill
- 2 Remove 6 screws from lower edge of door panel and one screw from rear edge of doorpanel.
- 3 Remove one screw from behind door latch handle in trim cup.
- 4 Pull panel off door and disconnect harnesses.
- 5 Remove 7mm bolts and 10mm bolts from galvanized plate which locates the door handle assembly in the center of the door.
- 6 Slide plate down and pull top of plate away from door.
- 7 Remove four 7mm bolts which secure BOSE enclosure to door. Disconnect harness and slide box out of door between top of steel plate and door structure.

### REAR SPEAKER REMOVAL

**NOTE:** Factory NON-BOSE speaker is a 6x9" speaker. BOSE-equipped vehicles have a 4" speaker in a BOSE enclosure.

- 1 Remove 4 screws from speaker grill and remove grill
- 2 Remove 4 screws securing speaker, unplug and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
DOME LIGHT SUPERVISION (-)	WHITE	At Courtesy Light Under Dash
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	WHITE	Ignition Coil
BRAKE SWITCH (+)	WHITE or LT.BLUE	Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove 2 screws from center air duct. One from each side. Remove the duct piece.
- 2 Remove the single screw from the tab located along the top right of the radio trim panel
- 3 Open the ashtray/lighter door. Pull the ashtray cup out and remove the screw from the console trim piece.
- 4 Open the center console storage compartment. Pull back the liner material and remove the 2 screw securing the rear of the center console trim.
- 5 Lift the center console trim away. Disconnect the connectors. Remove 4 screws from the shift boot trim and remove the assembly.
- 6 Remove the 2 screws securing the bottom of the radio trim panel.
- 7 The panel is secured with spring clips. One at the top and one on each side of the radio. Release the clips and remove the panel.
- 8 Remove 2 screws from the mounting tabs located on the padded outside section of the dash. This will provide the flexibility necessary to access the radio mounting screws.
- 9 Remove the top left and bottom radio mounting screws.
- 10 Flex back the console/dash pad material to access the bottom left screw and remove it.
- 11 Flex back the right outside console/dash pad material to remove the top right screws.
- 12 Pull the radio out of the cavity, unplug, and remove.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE speaker in a tuned enclosure.

- 1 Remove 2 screws from the outer door sill edge in carpet.
- 2 Remove 2 screws from the plastic trim located at the door sill back, slip up and down and remove the trim
- 3 Lift the door sill/speaker trim piece from the rear, slide to the rear, and remove the trim
- 4 Remove the enclosure fasteners to remove the assembly.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE 6" speaker in a tuned enclosure

- 1 Remove 6 screws securing the speaker grill and remove the grill
- 2 Remove 3 screws from the plastic trim located along the carpet edge
- 3 Pull back the carpeting
- 4 Remove 6 screws securing the speaker, unplug, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	WHITE	At Courtesy Light Under Dash
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	WHITE	Ignition Coil
BRAKE SWITCH (+)	WHITE or LT.BLUE	Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove 2 screws from center air duct. One from each side. Remove the duct piece.
- 2 Remove the single screw from the tab located along the top right of the radio trim panel
- 3 Open the ashtray/lighter door. Pull the ashtray cup out and remove the screw from the console trim piece.
- 4 Open the center console storage compartment. Pull back the liner material and remove the 2 screw securing the rear of the center console trim.
- 5 Lift the center console trim away. Disconnect the connectors. Remove 4 screws from the shift boot trim and remove the assembly.
- 6 Remove the 2 screws securing the bottom of the radio trim panel.
- 7 The panel is secured with spring clips. One at the top and one on each side of the radio. Release the clips and remove the panel.
- 8 Remove 2 screws from the mounting tabs located on the padded outside section of the dash. This will provide the flexibility necessary to access the radio mounting screws.
- 9 Remove the top left and bottom radio mounting screws.
- 10 Flex back the console/dash pad material to access the bottom left screw and remove it.
- 11 Flex back the right outside console/dash pad material to remove the top right screws.
- 12 Pull the radio out of the cavity, unplug, and remove.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE speaker in a tuned enclosure.

- 1 Remove 2 screws from the outer door sill edge in carpet.
- 2 Remove 2 screws from the plastic trim located at the door sill back, slip up and down and remove the trim
- 3 Lift the door sill/speaker trim piece from the rear, slide to the rear, and remove the trim
- 4 Remove the enclosure fasteners to remove the assembly.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE 6" speaker in a tuned enclosure

- 1 Remove 6 screws securing the speaker grill and remove the grill
- 2 Remove 3 screws from the plastic trim located along the carpet edge
- 3 Pull back the carpeting
- 4 Remove 6 screws securing the speaker, unplug, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	LIGHTBLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	WHITE	At Courtesy Light Under Dash
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	WHITE	Ignition Coil
BRAKE SWITCH (+)	WHITE or LT.BLUE	Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove 2 screws from center air duct. One from each side. Remove the duct piece.
- 2 Remove the single screw from the tab located along the top right of the radio trim panel
- 3 Open the ashtray/lighter door. Pull the ashtray cup out and remove the screw from the console trim piece.
- 4 Open the center console storage compartment. Pull back the liner material and remove the 2 screw securing the rear of the center console trim.
- 5 Lift the center console trim away. Disconnect the connectors. Remove 4 screws from the shift boot trim and remove the assembly.
- 6 Remove the 2 screws securing the bottom of the radio trim panel.
- 7 The panel is secured with spring clips. One at the top and one on each side of the radio. Release the clips and remove the panel.
- 8 Remove 2 screws from the mounting tabs located on the padded outside section of the dash. This will provide the flexibility necessary to access the radio mounting screws.
- 9 Remove the top left and bottom radio mounting screws.
- 10 Flex back the console/dash pad material to access the bottom left screw and remove it.
- 11 Flex back the right outside console/dash pad material to remove the top right screws.
- 12 Pull the radio out of the cavity, unplug, and remove.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE speaker in a tuned enclosure.

- 1 Remove 2 screws from the outer door sill edge in carpet.
- 2 Remove 2 screws from the plastic trim located at the door sill back, slip up and down and remove the trim
- 3 Lift the door sill/speaker trim piece from the rear, slide to the rear, and remove the trim
- 4 Remove the enclosure fasteners to remove the assembly.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE 6" speaker in a tuned enclosure

- 1 Remove 6 screws securing the speaker grill and remove the grill
- 2 Remove 3 screws from the plastic trim located along the carpet edge
- 3 Pull back the carpeting
- 4 Remove 6 screws securing the speaker, unplug, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	LIGHT BLUE	Harness In Driver's Kick Panel
<b>Notes:</b> Lock is 5-wire reverse polarity		
POWER DOOR UNLOCK	BLACK	Harness In Driver's Kick Panel
<b>Notes:</b> Unlock is 5-wire reverse polarity- Test using passenger lock switch		
PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
DOMELIGHT SUPERVISION (-)	WHITE	At Courtesy Light Under Dash
TRUNK TRIGGER (-)	BLACK	At Light In Trunk
TRUNK RELEASE (+)	BROWN	At Trunk Release Switch
FACTORY ALARM ARM	Arms on lock	
FACTORY ALARM DISARM (-)	LIGHTGREEN	Harness Coming Into Vehicle From Driver's Door
TACHOMETER WIRE	WHITE	Ignition Coil
BRAKE SWITCH (+)	WHITE or LT.BLUE	Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5", 6x9"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### RADIO REMOVAL

- 1 Remove 2 screws from center air duct. One from each side. Remove the duct piece.
- 2 Remove the single screw from the tab located along the top right of the radio trim panel
- 3 Open the ashtray/lighter door. Pull the ashtray cup out and remove the screw from the console trim piece.
- 4 Open the center console storage compartment. Pull back the liner material and remove the 2 screw securing the rear of the center console trim.
- 5 Lift the center console trim away. Disconnect the connectors. Remove 4 screws from the shift boot trim and remove the assembly.
- 6 Remove the 2 screws securing the bottom of the radio trim panel.
- 7 The panel is secured with spring clips. One at the top and one on each side of the radio. Release the clips and remove the panel.
- 8 Remove 2 screws from the mounting tabs located on the padded outside section of the dash. This will provide the flexibility necessary to access the radio mounting screws.
- 9 Remove the top left and bottom radio mounting screws.
- 10 Flex back the console/dash pad material to access the bottom left screw and remove it.
- 11 Flex back the right outside console/dash pad material to remove the top right screws.
- 12 Pull the radio out of the cavity, unplug, and remove.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE speaker in a tuned enclosure.

- 1 Remove 2 screws from the outer door sill edge in carpet.
- 2 Remove 2 screws from the plastic trim located at the door sill back, slip up and down and remove the trim
- 3 Lift the door sill/speaker trim piece from the rear, slide to the rear, and remove the trim
- 4 Remove the enclosure fasteners to remove the assembly.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a BOSE 6" speaker in a tuned enclosure

- 1 Remove 6 screws securing the speaker grill and remove the grill
- 2 Remove 3 screws from the plastic trim located along the carpet edge
- 3 Pull back the carpeting
- 4 Remove 6 screws securing the speaker, unplug, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	RED/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster

**Notes:** Lock is 5-wire reverse polarity

POWER DOOR UNLOCK	ORANGE/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
-------------------	--------------	---

**Notes:** Unlock is 5-wire reverse polarity- Test using passenger lock switch

PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
TRUNK RELEASE (-)	LT. BLUE	At Trunk Release Switch Or Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM ARM (-)	YELLOW	At Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM DISARM (-)	GREEN	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
TACHOMETER WIRE	RED/BLACK	At Engine Control Module Above Battery
BRAKE WIRE (+)	WHITE OR LT. BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	RED/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster

**Notes:** Lock is 5-wire reverse polarity

POWER DOOR UNLOCK	ORANGE/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
-------------------	--------------	---

**Notes:** Unlock is 5-wire reverse polarity- Test using passenger lock switch

PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
TRUNK RELEASE (-)	LT. BLUE	At Trunk Release Switch Or Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM ARM (-)	YELLOW	At Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM DISARM (-)	GREEN	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
TACHOMETER WIRE	RED/BLACK	At Engine Control Module Above Battery
BRAKE WIRE (+)	WHITE OR LT. BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK	RED/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster

**Notes:** Lock is 5-wire reverse polarity

POWER DOOR UNLOCK	ORANGE/BLACK	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
-------------------	--------------	---

**Notes:** Unlock is 5-wire reverse polarity- Test using passenger lock switch

PARKING LIGHTS (+)	BROWN	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	Harness In Driver's Kick Panel
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	Harness In Passenger Kick Panel
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
TRUNK RELEASE (-)	LT. BLUE	At Trunk Release Switch Or Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM ARM (-)	YELLOW	At Passive Keyless Entry Module Behind Center Of Instrument Cluster
FACTORY ALARM DISARM (-)	GREEN	Harness In Driver's Kick Panel Or At Passive Keyless Entry Module Behind Center Of Instrument Cluster
TACHOMETER WIRE	RED/BLACK	At Engine Control Module Above Battery
BRAKE WIRE (+)	WHITE OR LT. BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Driver Window Switch
LEFT FRONT WINDOW DOWN	BROWN	At Driver Window Switch
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Passenger Window Switch
RIGHT FRONT WINDOW DOWN	TAN	At Passenger Window Switch

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3051	METRA 70-1857	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4x6", 4"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE & BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Driver Door At Lock Switch
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Driver Door At Lock Switch
PARKING LIGHTS (+)	BROWN	Harness At Steering Column
DRIVER DOOR TRIGGER (-)	BLACK/WHITE	At Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/YELLOW	At Body Control Module
TRUNK TRIGGER (-)	RED/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
HOOD TRIGGER (-)	PINK/BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
TRUNK RELEASE (-)	LT. BLUE	At Body Control Module In Passenger Foot Well Underneath Carpet
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT. GREEN	In Driver's Door
TACHOMETER WIRE	WHITE	At Powertrain Control Module- Remove Right Front Tire And Access Panel In Inner Fender To Access Module. Tachometer Wire Will Be Found In The Red Connector
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	At Body Control Module In Passenger Foot Well Underneath Carpet
LEFT FRONT WINDOW UP	DARK BLUE	At Motor In Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor In Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	At Motor In Passenger's Door
RIGHT FRONT WINDOW DOWN	TAN	At Motor In Passenger's Door

INTERFACE	PART NUMBER	NOTES
VATS Bypass	Relay and resistor (Resistor value varies.) DEI 652T resistor pack contains all possible resistors. Refer to TechDoc 3739	Required when installing a remote start system. VATS anti-theft wires can be found at the Body Control Module. They are PURPLE/WHITE and WHITE/BLACK.

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED	YELLOW	At Radio Harness	
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
8", 3"	6.5"	Amplified at each speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-4000, SCOSCHE GM1588B	METRA XSVI-2004	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.