

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING                                    |                    |   |  |
|---|--------------------|---|--|
| WIRE  | COLOR              | LOCATION  | NOTES  |
| RADIO 12V CONSTANT WIRE                         | RED/WHITE          | Radio Harness   |  |
| RADIO SWITCHED WIRE                             |                    |   | The radio harness does not provide a switched power source |
| RADIO GROUND WIRE                               | BLACK/WHITE        | Radio Harness   |  |
| POWER ANTENNA WIRE                              | YELLOW             | Radio Harness   |  |
| AMP TURN-ON WIRE (+)                            | PINK               | Radio Harness   |  |
| LEFT FRONT SPEAKER (+)                          | TAN                | Left Front Speaker  |  |
| LEFT FRONT SPEAKER (-)                          | GRAY               | Left Front Speaker  |  |
| RIGHT FRONT SPEAKER (+)                         | LT.GREEN           | Right Front Speaker   |  |
| RIGHT FRONT SPEAKER (-)                         | DK.GREEN           | Right Front Speaker   |  |
| LEFT REAR SPEAKER (+)                           | BROWN              | Left Rear Speaker   |  |
| LEFT REAR SPEAKER (-)                           | YELLOW             | Left Rear Speaker   |  |
| RIGHT REAR SPEAKER (+)                          | DK.BLUE            | Right Rear Speaker  |  |
| RIGHT REAR SPEAKER (-)                          | LT.BLUE            | Right Rear Speaker  |  |
| FRONT SPEAKERS SIZE                             | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES  |
| 6.5"  | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |  |
| RADIO DASH KIT OPTIONS                          |                    | RADIO WIRE HARNESS OPTIONS                                  | ANTENNA ADAPTER OPTIONS                                    |
| METRA 99-3302, SCOSCHE GM1587B                  |                    | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB                | METRA 40-CR10, SCOSCHE CRAB                                |
| Please verify all part numbers before ordering. |                    |   |  |

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING            |             |                     |  |
|-------------------------|-------------|---------------------|--|
| WIRE                    | COLOR       | LOCATION            | NOTES  |
| RADIO 12V CONSTANT WIRE | RED/WHITE   | Radio Harness       |  |
| RADIO SWITCHED WIRE     |             |                     | The radio harness does not provide a switched power source |
| RADIO GROUND WIRE       | BLACK/WHITE | Radio Harness       |  |
| POWER ANTENNA WIRE      | YELLOW      | Radio Harness       |  |
| AMP TURN-ON WIRE (+)    | PINK        | Radio Harness       |  |
| LEFT FRONT SPEAKER (+)  | TAN         | Left Front Speaker  |  |
| LEFT FRONT SPEAKER (-)  | GRAY        | Left Front Speaker  |  |
| RIGHT FRONT SPEAKER (+) | LT.GREEN    | Right Front Speaker |  |
| RIGHT FRONT SPEAKER (-) | DK.GREEN    | Right Front Speaker |  |
| LEFT REAR SPEAKER (+)   | BROWN       | Left Rear Speaker   |  |
| LEFT REAR SPEAKER (-)   | YELLOW      | Left Rear Speaker   |  |
| RIGHT REAR SPEAKER (+)  | DK.BLUE     | Right Rear Speaker  |  |
| RIGHT REAR SPEAKER (-)  | LT.BLUE     | Right Rear Speaker  |  |

  

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES |
|---------------------|--------------------|---|-------|
| 6.5"                | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |       |

  

| RADIO DASH KIT OPTIONS         | RADIO WIRE HARNESS OPTIONS                   | ANTENNA ADAPTER OPTIONS     |
|--------------------------------|--|-----------------------------|
| METRA 99-3302, SCOSCHE GM1587B | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB | METRA 40-CR10, SCOSCHE CRAB |

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

| WIRE                    | COLOR       | LOCATION            | NOTES   |
|-------------------------|-------------|---------------------|---|
| RADIO 12V CONSTANT WIRE | RED/WHITE   | Radio Harness       |   |
| RADIO SWITCHED WIRE     |             |                     | The radio harness does not supply a switched power source |
| RADIO GROUND WIRE       | BLACK/WHITE | Radio Harness       |   |
| POWER ANTENNA WIRE      | YELLOW      | Radio Harness       |   |
| AMP TURN-ON WIRE (+)    | PINK        | Radio Harness       |   |
| LEFT FRONT SPEAKER (+)  | TAN         | Left Front Speaker  |   |
| LEFT FRONT SPEAKER (-)  | GRAY        | Left Front Speaker  |   |
| RIGHT FRONT SPEAKER (+) | LT.GREEN    | Right Front Speaker |   |
| RIGHT FRONT SPEAKER (-) | DK.GREEN    | Right Front Speaker |   |
| LEFT REAR SPEAKER (+)   | BROWN       | Left Rear Speaker   |   |
| LEFT REAR SPEAKER (-)   | YELLOW      | Left Rear Speaker   |   |
| RIGHT REAR SPEAKER (+)  | DK.BLUE     | Right Rear Speaker  |   |
| RIGHT REAR SPEAKER (-)  | LT.BLUE     | Right Rear Speaker  |   |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES |
|---------------------|--------------------|---|-------|
| 6.5"                | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |       |

| RADIO DASH KIT OPTIONS                          | RADIO WIRE HARNESS OPTIONS                   | ANTENNA ADAPTER OPTIONS     |
|---|--|-----------------------------|
| METRA 99-3302, SCOSCHE GM1587B                  | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB | METRA 40-CR10, SCOSCHE CRAB |
| Please verify all part numbers before ordering. |  |                             |

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING                                    |                    |   |   |
|---|--------------------|---|---|
| WIRE  | COLOR              | LOCATION  | NOTES   |
| RADIO 12V CONSTANT WIRE                         | RED/WHITE          | Radio Harness   |   |
| RADIO SWITCHED WIRE                             |                    |   | The radio harness does not supply a switched power source |
| RADIO GROUND WIRE                               | BLACK/WHITE        | Radio Harness   |   |
| POWER ANTENNA WIRE                              | YELLOW             | Radio Harness   |   |
| AMP TURN-ON WIRE (+)                            | PINK               | Radio Harness   |   |
| LEFT FRONT SPEAKER (+)                          | TAN                | Left Front Speaker  |   |
| LEFT FRONT SPEAKER (-)                          | GRAY               | Left Front Speaker  |   |
| RIGHT FRONT SPEAKER (+)                         | LT.GREEN           | Right Front Speaker   |   |
| RIGHT FRONT SPEAKER (-)                         | DK.GREEN           | Right Front Speaker   |   |
| LEFT REAR SPEAKER (+)                           | BROWN              | Left Rear Speaker   |   |
| LEFT REAR SPEAKER (-)                           | YELLOW             | Left Rear Speaker   |   |
| RIGHT REAR SPEAKER (+)                          | DK.BLUE            | Right Rear Speaker  |   |
| RIGHT REAR SPEAKER (-)                          | LT.BLUE            | Right Rear Speaker  |   |
| FRONT SPEAKERS SIZE                             | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES   |
| 6.5"  | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |   |
| RADIO DASH KIT OPTIONS                          |                    | RADIO WIRE HARNESS OPTIONS                                  | ANTENNA ADAPTER OPTIONS                                   |
| METRA 99-3302, SCOSCHE GM1587B                  |                    | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB                | METRA 40-CR10, SCOSCHE CRAB                               |
| Please verify all part numbers before ordering. |                    |   |   |

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING            |             |                     |   |
|-------------------------|-------------|---------------------|---|
| WIRE                    | COLOR       | LOCATION            | NOTES   |
| RADIO 12V CONSTANT WIRE | RED/WHITE   | Radio Harness       |   |
| RADIO SWITCHED WIRE     |             |                     | The radio harness does not supply a switched power source |
| RADIO GROUND WIRE       | BLACK/WHITE | Radio Harness       |   |
| POWER ANTENNA WIRE      | YELLOW      | Radio Harness       |   |
| AMP TURN-ON WIRE (+)    | PINK        | Radio Harness       |   |
| LEFT FRONT SPEAKER (+)  | TAN         | Left Front Speaker  |   |
| LEFT FRONT SPEAKER (-)  | GRAY        | Left Front Speaker  |   |
| RIGHT FRONT SPEAKER (+) | LT.GREEN    | Right Front Speaker |   |
| RIGHT FRONT SPEAKER (-) | DK.GREEN    | Right Front Speaker |   |
| LEFT REAR SPEAKER (+)   | BROWN       | Left Rear Speaker   |   |
| LEFT REAR SPEAKER (-)   | YELLOW      | Left Rear Speaker   |   |
| RIGHT REAR SPEAKER (+)  | DK.BLUE     | Right Rear Speaker  |   |
| RIGHT REAR SPEAKER (-)  | LT.BLUE     | Right Rear Speaker  |   |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES |
|---------------------|--------------------|---|-------|
| 6.5"                | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |       |

| RADIO DASH KIT OPTIONS                          | RADIO WIRE HARNESS OPTIONS                   | ANTENNA ADAPTER OPTIONS     |
|---|--|-----------------------------|
| METRA 99-3302, SCOSCHE GM1587B                  | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB | METRA 40-CR10, SCOSCHE CRAB |
| Please verify all part numbers before ordering. |  |                             |

### ALARM REMOTE START WIRING

| WIRE  | COLOR                         | LOCATION   |
|---|-------------------------------|--|
| 12V CONSTANT WIRE   | RED/BLACK                     | In Plug C3 At BCM On Front Passenger Side Of Center Console                                |
| STARTER WIRE (-)  | YELLOW (Not For Remote Start) | In Blue Connector At PCM In Front Of Fuse Box In Engine Bay                                |
| IGNITION WIRE   | YELLOW                        | Ignition Harness   |
| <b>Notes:</b> The WHITE/BLUE or WHITE second ignition/keysense wire needs to be interrupted using a relay |                               |  |
| ACCESSORY WIRE  | BROWN                         | Ignition Harness   |
| POWER DOOR LOCK AND UNLOCK  | WHITE                         | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| <b>Notes:</b> Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.         |                               |  |
| PARKING LIGHTS (+)  | BROWN                         | Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console |
| PARKING LIGHTS (-)  | BROWN/WHITE                   | Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console |
| LEFT FRONT DOOR TRIGGER (-)   | GRAY/BLACK                    | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| PASSENGER DOOR(S) TRIGGER (-)   | TAN/WHITE                     | Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console     |
| DOMELIGHT SUPERVISION (-)   | GRAY                          | Plug C3 At BCM On Front Passenger Side Of Center Console                                   |
| TRUNK TRIGGER (-)   | ORANGE/BLACK                  | Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console |
| TRUNK RELEASE (-)   | TAN                           | Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console                 |
| FACTORY ALARM ARM AND DISARM  | Factory Remote Only           |  |
| TACHOMETER WIRE   | NOT PINK or PINK/BLACK        | Any Fuel Injector  |
| BRAKE WIRE (+)  | LT.BLUE                       | At Brake Pedal Switch  |
| HORN TRIGGER (-)  | TAN                           | Plug C2 At BCM On Front Passenger Side Of Center Console                                   |
| LEFT FRONT WINDOW UP  | DK.BLUE                       | At Switch Inside Door  |
| LEFT FRONT WINDOW DOWN  | BROWN                         | At Switch Inside Door  |
| RIGHT FRONT WINDOW UP   | LT.BLUE                       | Harness In Driver's Kick From Driver's Door  |
| RIGHT FRONT WINDOW DOWN   | TAN                           | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW UP   | DK.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| LEFT REAR WINDOW DOWN   | PURPLE                        | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW UP  | LT.GREEN                      | Harness In Driver's Kick From Driver's Door  |
| RIGHT REAR WINDOW DOWN  | PURPLE                        | Harness In Driver's Kick From Driver's Door  |

| INTERFACE                                       | PART NUMBER | NOTES   |
|---|-------------|---|
| Passkey III Immobilizer Bypass Module           | DEI 556UW   | Required when installing a remote start system. |
| Please verify all part numbers before ordering. |             |   |

| AUDIO WIRING                                    |                    |   |   |
|---|--------------------|---|---|
| WIRE  | COLOR              | LOCATION  | NOTES   |
| RADIO 12V CONSTANT WIRE                         | RED/WHITE          | Radio Harness   |   |
| RADIO SWITCHED WIRE                             |                    |   | The radio harness does not supply a switched power source |
| RADIO GROUND WIRE                               | BLACK/WHITE        | Radio Harness   |   |
| POWER ANTENNA WIRE                              | YELLOW             | Radio Harness   |   |
| AMP TURN-ON WIRE (+)                            | PINK               | Radio Harness   |   |
| LEFT FRONT SPEAKER (+)                          | TAN                | Left Front Speaker  |   |
| LEFT FRONT SPEAKER (-)                          | GRAY               | Left Front Speaker  |   |
| RIGHT FRONT SPEAKER (+)                         | LT.GREEN           | Right Front Speaker   |   |
| RIGHT FRONT SPEAKER (-)                         | DK.GREEN           | Right Front Speaker   |   |
| LEFT REAR SPEAKER (+)                           | BROWN              | Left Rear Speaker   |   |
| LEFT REAR SPEAKER (-)                           | YELLOW             | Left Rear Speaker   |   |
| RIGHT REAR SPEAKER (+)                          | DK.BLUE            | Right Rear Speaker  |   |
| RIGHT REAR SPEAKER (-)                          | LT.BLUE            | Right Rear Speaker  |   |
| FRONT SPEAKERS SIZE                             | REAR SPEAKERS SIZE | AMP LOCATION  | NOTES   |
| 6.5"  | 6x9"               | Factory amplifier is in the driver side rear quarter panel. |   |
| RADIO DASH KIT OPTIONS                          |                    | RADIO WIRE HARNESS OPTIONS                                  | ANTENNA ADAPTER OPTIONS                                   |
| METRA 99-3302, SCOSCHE GM1587B                  |                    | METRA GMOS-LAN-03, SCOSCHE S3-SR1 + S3GM11LB                | METRA 40-CR10, SCOSCHE CRAB                               |
| Please verify all part numbers before ordering. |                    |   |   |