

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED/BLACK	Ignition harness
STARTER	Starter wire not required for remote start. Starter cranks when ignition has voltage and accessory loses voltage	
IGNITION	PINK	Ignition harness
ACCESSORY	BROWN	Ignition harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger. Unlock is a negative trigger through a 1500 ohm resistor. Relays must be used.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel or C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel or C2 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PASSENGER DOOR TRIGGER (-)	TAN/WHITE	Harness In Passenger Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DOMESUPERVISION (-)	GRAY	C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HOOD TRIGGER (-)	PINK/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK RELEASE (-)	BROWN/WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
FACTORY ARM	Arms on lock	
FACTORY DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: Disarm is a negative trigger through a 500-ohm resistor. Factory alarm also disarms with ignition and Passkey present.		
TACHOMETER WIRE	Not PINK	Any Fuel Injector
Notes: The ECM is located under the left side of the dash to the left of the column.		
BRAKE WIRE (+)	WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HORN TRIGGER (-)	TAN	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DARK BLUE	At Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW or DEI 556GW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B		METRA XSVI-2103, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED/BLACK	Ignition harness
STARTER	Starter wire not required for remote start. Starter cranks when ignition has voltage and accessory loses voltage	
IGNITION	PINK	Ignition harness
ACCESSORY	BROWN	Ignition harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger. Unlock is a negative trigger through a 1500 ohm resistor. Relays must be used.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel or C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel or C2 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PASSENGER DOOR TRIGGER (-)	TAN/WHITE	Harness In Passenger Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DOMESUPERVISION (-)	GRAY	C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HOOD TRIGGER (-)	PINK/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK RELEASE (-)	BROWN/WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
FACTORY ARM	Arms on lock	
FACTORY DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: Disarm is a negative trigger through a 500-ohm resistor. Factory alarm also disarms with ignition and Passkey present.		
TACHOMETER WIRE	Not PINK	Any Fuel Injector
Notes: The ECM is located under the left side of the dash to the left of the column.		
BRAKE WIRE (+)	WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HORN TRIGGER (-)	TAN	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DARK BLUE	At Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW or DEI 556GW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B		METRA XSVI-2103, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED/BLACK	Ignition harness
STARTER	Starter wire not required for remote start. Starter cranks when ignition has voltage and accessory loses voltage	
IGNITION	PINK	Ignition harness
ACCESSORY	BROWN	Ignition harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger. Unlock is a negative trigger through a 1500 ohm resistor. Relays must be used.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel or C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel or C2 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PASSENGER DOOR TRIGGER (-)	TAN/WHITE	Harness In Passenger Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DOMESUPERVISION (-)	GRAY	C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HOOD TRIGGER (-)	PINK/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK RELEASE (-)	BROWN/WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
FACTORY ARM	Arms on lock	
FACTORY DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: Disarm is a negative trigger through a 500-ohm resistor. Factory alarm also disarms with ignition and Passkey present.		
TACHOMETER WIRE	Not PINK	Any Fuel Injector
Notes: The ECM is located under the left side of the dash to the left of the column.		
BRAKE WIRE (+)	WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HORN TRIGGER (-)	TAN	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DARK BLUE	At Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW or DEI 556GW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B		METRA XSVI-2103, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	RED/BLACK	Ignition harness
STARTER	Starter wire not required for remote start. Starter cranks when ignition has voltage and accessory loses voltage	
IGNITION	PINK	Ignition harness
ACCESSORY	BROWN	Ignition harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: The same wire is used to lock and unlock the doors. Lock is a negative trigger. Unlock is a negative trigger through a 1500 ohm resistor. Relays must be used.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel or C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel or C2 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
PASSENGER DOOR TRIGGER (-)	TAN/WHITE	Harness In Passenger Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
DOMESUPERVISION (-)	GRAY	C3 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HOOD TRIGGER (-)	PINK/BLACK	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
TRUNK RELEASE (-)	BROWN/WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
FACTORY ARM	Arms on lock	
FACTORY DISARM (-)	LT.GREEN	Harness In Driver's Kick Panel or C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
Notes: Disarm is a negative trigger through a 500-ohm resistor. Factory alarm also disarms with ignition and Passkey present.		
TACHOMETER WIRE	Not PINK	Any Fuel Injector
Notes: The ECM is located under the left side of the dash to the left of the column.		
BRAKE WIRE (+)	WHITE	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
HORN TRIGGER (-)	TAN	C1 Connector At Body Control Module Attached To Fuse Box On Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DARK BLUE	At Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	DARK GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	LIGHT GREEN	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW or DEI 556GW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	At Radio Harness	
12V SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK	At Radio Harness	
ILLUMINATION (+)	GRAY	At Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	At Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Radio Harness Or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B		METRA XSVI-2103, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			