

TRIPLE S *Customs*

CHEVROLET VENTURE 1997-2005 VEHICLE WIRING

WIRING INFORMATION: 1997 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED OR RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
POWER DOORUNLOCK (-)	WHITE	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	At Light Switch
DOOR TRIGGER	There are three separate door trigger wires. They are: TAN for the driver's door, DK. BLUE for the passenger door and lift gate, and ORANGE for the sliding door(s).	Body Control Module Above Passenger Kick Panel
REAR HATCH TRIGGER	SEE DOOR TRIGGER	
FACTORY ALARM ARM (-)	RED/BLACK	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
TACHOMETER WIRE	PURPLE/WHITE OR WHITE	Main Harness On The Driver's Side Of Engine On Top Of The Manifold Cover
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION: 1998 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED OR RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-)	LT. BLUE	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
POWER DOORUNLOCK (-)	WHITE	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	At Light Switch
DOOR TRIGGER	There are three separate door trigger wires. They are: TAN for the driver's door, DK. BLUE for the passenger door and lift gate, and ORANGE for the sliding door(s).	Body Control Module Above Passenger Kick Panel
REAR HATCH TRIGGER	SEE DOOR TRIGGER	
FACTORY ALARM ARM (-)	RED/BLACK	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
FACTORY ALARM DISARM (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Body Control Module Above Passenger Kick Panel
TACHOMETER WIRE	PURPLE/WHITE OR WHITE	Main Harness On The Driver's Side Of Engine On Top Of The Manifold Cover
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION: 1999 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2000 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2001 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2002 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2003 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2004 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
POWER DOOR LOCK (-) **Wire will only meter when turning the key in either door key cylinder**	RED/BLACK **On vehicles without the factory alarm, use LT. BLUE for lock**	Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-) **Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **	ORANGE/BLACK **On vehicles without the factory alarm, use WHITE for unlock**	Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
DOOR TRIGGER (-)	Use TAN for the driver's door, BLUE for the passenger door and the lift gate, and ORANGE for the sliding doors.	Body Control Module Behind Glove Box
DOME SUPERVISION	USE DOOR TRIGGER	
REAR HATCH TRIGGER	TIED IN WITH DOORS	
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		

WIRING INFORMATION: 2005 Chevy Venture

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED & RED/WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
SECOND IGNITION WIRE	WHITE	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	In Blue Plug At Body Control Module Behind Glove Box
*Wire will only meter when turning the key in either door key cylinder **On vehicles without the factory alarm, use LT. BLUE for lock		
POWER DOOR UNLOCK (-)	ORANGE/BLACK	In Blue Plug At Body Control Module Behind Glove Box
*Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors **On vehicles without the factory alarm, use WHITE for unlock**		
PARKING LIGHTS (+)	BROWN	Harness In Drivers Kick Panel Or Light Switch
PARKING LIGHTS (-)	BROWN/WHITE	In Blue Plug At Body Control Module Behind Glove Box
LEFT FRONT DOOR TRIGGER (-)	TAN	
RIGHT FRONT & LIFT GATE DOOR TRIGGER (-)	BLUE	
SLIDING DOORS TRIGGER (-)	ORANGE	
DOME SUPERVISION (-)	GRAY/BLACK	In Tan Plug At Body Control Module Behind Glove Box
FACTORY ALARM ARM	ARMS W/ LOCK	
FACTORY ALARM DISARM	DISARMS W/ UNLOCK	
DISARM NO UNLOCK	To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire	
TACHOMETER WIRE	PURPLE/WHITE	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door
This vehicle is equipped with the Pass-Key III immobilizer. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same time.		