

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V constant.	
STARTER WIRE	YELLOW	Ignition Harness
SECOND STARTER WIRE	PURPLE/BROWN	Ignition Harness
<b>Notes:</b> The second starter wire is a negative trigger through a 180-ohm resistor. Refer to TechDoc 3011		
IGNITION WIRE	PINK/GRAY	Ignition Harness
POWER DOOR LOCK AND UNLOCK	PURPLE/LT.BLUE	Module Inside Driver's Door
<b>Notes:</b> Lock is a negative trigger through a 1.8K-ohm resistor. Unlock is negative trigger through a 750-ohm resistor. Unlock requires a double pulse.		
PARKING LIGHTS (-)	BROWN/WHITE	Behind Headlight Switch
<b>Notes:</b> Parking light wire is a negative trigger through a 920-ohm resistor. A relay must be used to isolate away from the switch. . Refer to TechDoc 3965		
LEFT FRONT DOOR TRIGGER (-)	PURPLE	Module Inside Driver's Door
RIGHT FRONT DOOR TRIGGER (-)	PURPLE/WHITE	Module Inside Passenger Front Door
LEFT REAR DOOR TRIGGER (-)	PURPLE/GRAY	At Body Control Module Under Dash Against Firewall
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	At Body Control Module Under Dash Against Firewall
TRUNK TRIGGER (-)	PURPLE/ORANGE	At Body Control Module Under Dash Against Firewall
TRUNK RELEASE	PURPLE/TAN	At Body Control Module Under Dash Against Firewall
<b>Notes:</b> To activate power hatch, give a negative trigger through a 4.7 ohm resistor.		
FACTORY ALARM ARM	Arms with lock	At Body Control Module Under Dash Against Firewall
FACTORY ALARM DISARM	Disarms with unlock	At Body Control Module Under Dash Against Firewall
FACTORY DISARM NO UNLOCK	Single pulse to unlock wire	At Body Control Module Under Dash Against Firewall
TACHOMETER WIRE	Wire NOT BROWN/WHITE	At Any Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	Module In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	Module In Left Front Door
RIGHT FRONT WINDOW UP	BROWN/ORANGE	Module In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE/ORANGE	Module In Right Front Door
LEFT REAR WINDOW UP	TAN/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	TAN/LT.BLUE	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	ORANGE/BROWN	Harness In Passenger's Kick Panel
RIGHT REAR WINDOW DOWN	ORANGE/PURPLE	Harness In Passenger's Kick Panel

INTERFACE	PART NUMBER	NOTES
Sentry Key Immobilizer Bypass Module	DEI 556CW or DEI 556UW	Required when installing a remote start system and not using a databus module.
Databus Module	DEI IOM-Chrysler-6	Recommended when installing a remote start system. Operates bypass and locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/ORANGE	Radio Harness	
RADIO SWITCHED WIRE	PINK/ORANGE	Radio Harness	
RADIO GROUND WIRE	BLACK/LT. GREEN	Radio Harness	
POWER ANTENNA WIRE (+)	GRAY/ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	GRAY/PURPLE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY/YELLOW	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	DK. GREEN/PURPLE	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK. GREEN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT. GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	GRAY/DK. GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK. GREEN/LT. GREEN	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	DK. GREEN/GRAY	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5", 1" Tweeter	Factory amplifier is on floor of passenger rear cargo area	8" subwoofer, if equipped with Infinity audio system
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6506, SCOSCHE CR1284B		METRA 70-6506, SCOSCHE CR02	METRA 40-CR10, SCOSCHE CRA
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V constant.	
STARTER WIRE	YELLOW	Ignition Harness
SECOND STARTER WIRE	PURPLE/BROWN	Ignition Harness
<b>Notes:</b> The second starter wire is a negative trigger through a 180-ohm resistor. Refer to TechDoc 3011		
IGNITION WIRE	PINK/GRAY	Ignition Harness
POWER DOOR LOCK AND UNLOCK	PURPLE/LT.BLUE	Module Inside Driver's Door
<b>Notes:</b> Lock is a negative trigger through a 1.8K-ohm resistor. Unlock is negative trigger through a 750-ohm resistor. Unlock requires a double pulse.		
PARKING LIGHTS (-)	BROWN/WHITE	Behind Headlight Switch
<b>Notes:</b> Parking light wire is a negative trigger through a 920-ohm resistor. A relay must be used to isolate away from the switch. . Refer to TechDoc 3965		
LEFT FRONT DOOR TRIGGER (-)	PURPLE	Module Inside Driver's Door
RIGHT FRONT DOOR TRIGGER (-)	PURPLE/WHITE	Module Inside Passenger Front Door
LEFT REAR DOOR TRIGGER (-)	PURPLE/GRAY	At Body Control Module Under Dash Against Firewall
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	At Body Control Module Under Dash Against Firewall
TRUNK TRIGGER (-)	PURPLE/ORANGE	At Body Control Module Under Dash Against Firewall
TRUNK RELEASE	PURPLE/TAN	At Body Control Module Under Dash Against Firewall
<b>Notes:</b> To activate power hatch, give a negative trigger through a 4.7 ohm resistor.		
FACTORY ALARM ARM	Arms with lock	At Body Control Module Under Dash Against Firewall
FACTORY ALARM DISARM	Disarms with unlock	At Body Control Module Under Dash Against Firewall
FACTORY DISARM NO UNLOCK	Single pulse to unlock wire	At Body Control Module Under Dash Against Firewall
TACHOMETER WIRE	Wire NOT BROWN/WHITE	At Any Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	Module In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	Module In Left Front Door
RIGHT FRONT WINDOW UP	BROWN/ORANGE	Module In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE/ORANGE	Module In Right Front Door
LEFT REAR WINDOW UP	TAN/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	TAN/LT.BLUE	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	ORANGE/BROWN	Harness In Passenger's Kick Panel
RIGHT REAR WINDOW DOWN	ORANGE/PURPLE	Harness In Passenger's Kick Panel

INTERFACE	PART NUMBER	NOTES
Sentry Key Immobilizer Bypass Module	DEI 556CW or DEI 556UW	Required when installing a remote start system and not using a databus module.
Databus Module	DEI IOM-Chrysler-6	Recommended when installing a remote start system. Operates bypass and locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/ORANGE	Radio Harness	
RADIO SWITCHED WIRE	PINK/ORANGE	Radio Harness	
RADIO GROUND WIRE	BLACK/LT. GREEN	Radio Harness	
POWER ANTENNA WIRE (+)	GRAY/ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	GRAY/PURPLE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY/YELLOW	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	DK. GREEN/PURPLE	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK. GREEN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT. GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	GRAY/DK. GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK. GREEN/LT. GREEN	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	DK. GREEN/GRAY	Right Rear Speaker	

  

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5", 1" Tweeter	Factory amplifier is on floor of passenger rear cargo area	8" subwoofer, if equipped with Infinity audio system

  

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6506, SCOSCHE CR1284B	METRA 70-6506, SCOSCHE CR02	METRA 40-CR10, SCOSCHE CRA

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V constant.	
STARTER WIRE	YELLOW	Ignition Harness
SECOND STARTER WIRE	PURPLE/BROWN	Ignition Harness
<b>Notes:</b> The second starter wire is a negative trigger through a 180-ohm resistor. Refer to TechDoc 3011		
IGNITION WIRE	PINK/GRAY	Ignition Harness
POWER DOOR LOCK AND UNLOCK	PURPLE/LT.BLUE	Module Inside Driver's Door
<b>Notes:</b> Lock is a negative trigger through a 1.8K-ohm resistor. Unlock is negative trigger through a 750-ohm resistor. Unlock requires a double pulse.		
PARKING LIGHTS (-)	BROWN/WHITE	Behind Headlight Switch
<b>Notes:</b> Parking light wire is a negative trigger through a 920-ohm resistor. A relay must be used to isolate away from the switch. . Refer to TechDoc 3965		
LEFT FRONT DOOR TRIGGER (-)	PURPLE	Module Inside Driver's Door
RIGHT FRONT DOOR TRIGGER (-)	PURPLE/WHITE	Module Inside Passenger Front Door
LEFT REAR DOOR TRIGGER (-)	PURPLE/GRAY	At Body Control Module Under Dash Against Firewall
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	At Body Control Module Under Dash Against Firewall
TRUNK TRIGGER (-)	PURPLE/ORANGE	At Body Control Module Under Dash Against Firewall
TRUNK RELEASE	PURPLE/TAN	At Body Control Module Under Dash Against Firewall
<b>Notes:</b> To activate power hatch, give a negative trigger through a 4.7 ohm resistor.		
FACTORY ALARM ARM	Arms with lock	At Body Control Module Under Dash Against Firewall
FACTORY ALARM DISARM	Disarms with unlock	At Body Control Module Under Dash Against Firewall
FACTORY DISARM NO UNLOCK	Single pulse to unlock wire	At Body Control Module Under Dash Against Firewall
TACHOMETER WIRE	Wire NOT BROWN/WHITE	At Any Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	Module In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	Module In Left Front Door
RIGHT FRONT WINDOW UP	BROWN/ORANGE	Module In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE/ORANGE	Module In Right Front Door
LEFT REAR WINDOW UP	TAN/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	TAN/LT.BLUE	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	ORANGE/BROWN	Harness In Passenger's Kick Panel
RIGHT REAR WINDOW DOWN	ORANGE/PURPLE	Harness In Passenger's Kick Panel

INTERFACE	PART NUMBER	NOTES
Sentry Key Immobilizer Bypass Module	DEI 556CW or DEI 556UW	Required when installing a remote start system and not using a databus module.
Databus Module	DEI IOM-Chrysler-6	Recommended when installing a remote start system. Operates bypass and locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/ORANGE	Radio Harness	
RADIO SWITCHED WIRE	PINK/ORANGE	Radio Harness	
RADIO GROUND WIRE	BLACK/LT. GREEN	Radio Harness	
POWER ANTENNA WIRE (+)	GRAY/ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	GRAY/PURPLE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY/YELLOW	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	DK. GREEN/PURPLE	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK. GREEN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT. GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	GRAY/DK. GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK. GREEN/LT. GREEN	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	DK. GREEN/GRAY	Right Rear Speaker	

  

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5", 1" Tweeter	Factory amplifier is on floor of passenger rear cargo area	8" subwoofer, if equipped with Infinity audio system

  

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6506, SCOSCHE CR1284B	METRA 70-6506, SCOSCHE CR02	METRA 40-CR10, SCOSCHE CRA

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V constant.	
STARTER WIRE	YELLOW	Ignition Harness
SECOND STARTER WIRE	PURPLE/BROWN	Ignition Harness
<b>Notes:</b> The second starter wire is a negative trigger through a 180-ohm resistor. Refer to TechDoc 3011		
IGNITION WIRE	PINK/GRAY	Ignition Harness
POWER DOOR LOCK AND UNLOCK	PURPLE/LT.BLUE	Module Inside Driver's Door
<b>Notes:</b> Lock is a negative trigger through a 1.8K-ohm resistor. Unlock is negative trigger through a 750-ohm resistor. Unlock requires a double pulse.		
PARKING LIGHTS (-)	BROWN/WHITE	Behind Headlight Switch
<b>Notes:</b> Parking light wire is a negative trigger through a 920-ohm resistor. A relay must be used to isolate away from the switch. . Refer to TechDoc 3965		
LEFT FRONT DOOR TRIGGER (-)	PURPLE	Module Inside Driver's Door
RIGHT FRONT DOOR TRIGGER (-)	PURPLE/WHITE	Module Inside Passenger Front Door
LEFT REAR DOOR TRIGGER (-)	PURPLE/GRAY	At Body Control Module Under Dash Against Firewall
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	At Body Control Module Under Dash Against Firewall
TRUNK TRIGGER (-)	PURPLE/ORANGE	At Body Control Module Under Dash Against Firewall
TRUNK RELEASE	PURPLE/TAN	At Body Control Module Under Dash Against Firewall
<b>Notes:</b> To activate power hatch, give a negative trigger through a 4.7 ohm resistor.		
FACTORY ALARM ARM	Arms with lock	At Body Control Module Under Dash Against Firewall
FACTORY ALARM DISARM	Disarms with unlock	At Body Control Module Under Dash Against Firewall
FACTORY DISARM NO UNLOCK	Single pulse to unlock wire	At Body Control Module Under Dash Against Firewall
TACHOMETER WIRE	Wire NOT BROWN/WHITE	At Any Ignition Coil
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	Module In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	Module In Left Front Door
RIGHT FRONT WINDOW UP	BROWN/ORANGE	Module In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE/ORANGE	Module In Right Front Door
LEFT REAR WINDOW UP	TAN/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	TAN/LT.BLUE	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	ORANGE/BROWN	Harness In Passenger's Kick Panel
RIGHT REAR WINDOW DOWN	ORANGE/PURPLE	Harness In Passenger's Kick Panel

INTERFACE	PART NUMBER	NOTES
Sentry Key Immobilizer Bypass Module	DEI 556CW or DEI 556UW	Required when installing a remote start system and not using a databus module.
Databus Module	DEI IOM-Chrysler-6	Recommended when installing a remote start system. Operates bypass and locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/ORANGE	Radio Harness	
RADIO SWITCHED WIRE	PINK/ORANGE	Radio Harness	
RADIO GROUND WIRE	BLACK/LT. GREEN	Radio Harness	
POWER ANTENNA WIRE (+)	GRAY/ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	GRAY/PURPLE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY/YELLOW	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	DK. GREEN/PURPLE	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK. GREEN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT. GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	GRAY/DK. GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK. GREEN/LT. GREEN	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	DK. GREEN/GRAY	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5", 1" Tweeter	Factory amplifier is on floor of passenger rear cargo area	8" subwoofer, if equipped with Infinity audio system
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6506, SCOSCHE CR1284B		METRA 70-6506, SCOSCHE CR02	METRA 40-CR10, SCOSCHE CRA
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	PURPLE/RED x2	Pins 1 and 2 in plug C1 at BCM under the driver's side dash on the firewall
STARTER WIRE	YELLOW	Pin 4 of 5-Pin Plug At Ignition Switch
SECOND STARTER WIRE	PURPLE/BROWN	Pin 2 of 5-Pin Plug At Ignition Switch
<b>Notes:</b> The second starter wire is a negative trigger through a 180-ohm resistor. Refer to TechDoc 3011		
IGNITION WIRE	PINK/GRAY	Ignition Harness
ACCESSORY WIRE	Same as second starter wire.	
KEY-SENSE WIRE	Same as second starter wire	
<b>Notes:</b> The key-sense wire is a negative trigger through a 8.5K-ohm resistor.		
POWER DOOR LOCK AND UNLOCK	Use factory alarm arm and arm	
PARKING LIGHTS (-)	BROWN/WHITE	Behind Headlight Switch. Also found at Pins 31 in plug C1 at BCM under the driver's side dash on the firewall
<b>Notes:</b> Parking light wire is a negative trigger through a 920-ohm resistor. A relay must be used to isolate away from the switch. Refer to TechDoc 3965		
LEFT FRONT DOOR TRIGGER (-)	PURPLE	Pin 11 In 20-Pin Plug At Module Inside Left Front Door
RIGHT FRONT DOOR TRIGGER (-)	PURPLE/WHITE	Module Inside Right Front Door
LEFT REAR DOOR TRIGGER (-)	PURPLE/GRAY	At BCM Under The Driver's Side Dash On The Firewall
RIGHT REAR DOOR TRIGGER (-)	PURPLE/YELLOW	At BCM Under The Driver's Side Dash On The Firewall
TRUNK TRIGGER (-)	PURPLE/ORANGE	At BCM Under The Driver's Side Dash On The Firewall
TRUNK RELEASE	TAN/DK.GREEN	At Body Control Module Under Dash Against Firewall
<b>Notes:</b> To activate power hatch, give a negative trigger through a 4.7 ohm resistor.		
FACTORY ALARM ARM	PURPLE/LT.BLUE	Pin 13 In 20-Pin Plug At Module Inside Left Front Door
<b>Notes:</b> Arm is a negative trigger through a 1.8K-ohm resistor		
FACTORY ALARM DISARM	Same as arm wire	
<b>Notes:</b> Disarm is a negative trigger through a 750-ohm resistor. A double-pulse will unlock the doors		
FACTORY DISARM NO UNLOCK	Immobilizer and keysense	
TACHOMETER WIRE	Wire NOT BROWN/WHITE	At Any Ignition Coil
REVERSE LIGHT (+)	WHITE/LT.GREEN	Pin 3 in Plug C2 at BCM under the driver's side dash on the firewall. Also found in driver's kick panel
BRAKE WIRE (+)	WHITE/GREEN	At Brake Pedal Switch
HORN TRIGGER (-)	DK.GREEN/PURPLE	At Steering Column
LEFT FRONT WINDOW UP	ORANGE/LT.GREEN	Module In Left Front Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	Module In Left Front Door
RIGHT FRONT WINDOW UP	BROWN/ORANGE	Module In Right Front Door
RIGHT FRONT WINDOW DOWN	PURPLE/ORANGE	Module In Right Front Door
LEFT REAR WINDOW UP	TAN/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	TAN/LT.BLUE	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	ORANGE/BROWN	Harness In Passenger's Kick Panel
RIGHT REAR WINDOW DOWN	ORANGE/PURPLE	Harness In Passenger's Kick Panel

INTERFACE	PART NUMBER	NOTES
Sentry Key Immobilizer Bypass Module	DEI 556CW or DEI 556UW	Required when installing a remote start system and not using a databus module.
Databus Module	DEI IOM-Chrysler-6	Recommended when installing a remote start system. Operates bypass and locks

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/ORANGE	Radio Harness	
RADIO SWITCHED WIRE	PINK/ORANGE	Radio Harness	
RADIO GROUND WIRE	BLACK/LT. GREEN	Radio Harness	
POWER ANTENNA WIRE (+)	GRAY/ORANGE	Radio Harness	
LEFT FRONT SPEAKER (+)	GRAY/PURPLE	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY/YELLOW	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	DK. GREEN/PURPLE	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK. GREEN/YELLOW	Right Front Speaker	
LEFT REAR SPEAKER (+)	GRAY/LT. GREEN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	GRAY/DK. GREEN	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK. GREEN/LT. GREEN	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	DK. GREEN/GRAY	Right Rear Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1" Tweeter	6.5", 1" Tweeter	Factory amplifier is on floor of passenger rear cargo area	8" subwoofer, if equipped with Infinity audio system
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6506, SCOSCHE CR1284B		METRA 70-6506, SCOSCHE CR02	METRA 40-CR10, SCOSCHE CRA
Please verify all part numbers before ordering.			