

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--------------------------|----------------------------------|---|
| 12V CONSTANT WIRE | RED or PINK | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | DK. BLUE | Ignition Harness |
| ACCESSORY WIRE | BLACK/ORANGE | Ignition Harness |
| POWER DOOR LOCK (+) | ORANGE/PURPLE or ORANGE/WHITE | Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (+) | PINK/PURPLE | Harness In Driver's Kick Panel |
| PARKING LIGHTS (+) | BLACK/YELLOW | Harness In Driver's Kick Panel |
| DOOR TRIGGER (-) | YELLOW | Harness In Driver's Kick Panel |
| TRUNK TRIGGER (-) | TAN/BLACK | Harness In Driver's Kick Panel |
| TRUNK RELEASE (+) | BLACK/WHITE | At Trunk Release Switch |
| FACTORY ALARM ARM | ARMS WITH LOCK | |
| FACTORY ALARM DISARM (-) | LT.GREEN/ORANGE | Harness In Driver's Kick Panel |
| TACHOMETER WIRE | BLACK/GRAY | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK/RED | At Relay At Fuse Box |
| LEFT FRONT WINDOW UP | LT.BLUE | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | BROWN | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | PURPLE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW UP | RED | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW DOWN | DARK BLUE | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW UP | DARK BLUE | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW DOWN | DARK GREEN | Harness In Driver's Kick From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------|-------------|-------|
| None required | NA | NA |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|---|--------------------|------------------------------|-------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED/WHITE | Radio Harness | |
| RADIO GROUND | Not In Harness | Ground Strap | |
| ILLUMINATION (+) | ORANGE/WHITE | Radio Harness | |
| POWER ANTENNA (+) | | Radio Harness | |
| AMP TURN ON (+) | | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN/YELLOW | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | VIOLET | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | VIOLET/YELLOW | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | BROWN/YELLOW | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | BLUE/RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLUE/WHITE | Radio Harness or Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 3.5", 5.25" | 6x9" | | |
| RADIO DASH KIT OPTIONS | | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
| METRA 99-6501, SCOSCHE CJ1282B | | METRA 70-1817, SCOSCHE CR01B | Not required |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--------------------------|----------------------------------|---|
| 12V CONSTANT WIRE | RED, PINK/BLACK | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | DK. BLUE | Ignition Harness |
| ACCESSORY WIRE | BLACK/ORANGE | Ignition Harness |
| POWER DOOR LOCK (+) | ORANGE/PURPLE or ORANGE/WHITE | Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (+) | PINK/PURPLE | Harness In Driver's Kick Panel |
| PARKING LIGHTS (+) | BLACK/YELLOW | Harness In Driver's Kick Panel |
| DOOR TRIGGER (-) | YELLOW | Harness In Driver's Kick Panel |
| TRUNK TRIGGER (-) | BROWN/BLACK | Harness In Driver's Kick Panel |
| TRUNK RELEASE (+) | BLACK/WHITE | At Trunk Release Switch |
| FACTORY ALARM ARM | ARMS WITH LOCK | |
| FACTORY ALARM DISARM (-) | LT.GREEN/ORANGE | Harness In Driver's Kick Panel |
| TACHOMETER WIRE | BLACK/GRAY | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK/RED | At Relay At Fuse Box |
| LEFT FRONT WINDOW UP | LT.BLUE | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | BROWN/WHITE | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | PURPLE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW UP | BLUE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW DOWN | RED/BLUE | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW UP | GRAY/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW DOWN | GREEN/WHITE | Harness In Driver's Kick From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------|-------------|-------|
| None required | NA | NA |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|---|--------------------|------------------------------|-------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED/WHITE | Radio Harness | |
| RADIO GROUND | Not In Harness | Ground Strap | |
| ILLUMINATION (+) | ORANGE/WHITE | Radio Harness | |
| POWER ANTENNA (+) | | Radio Harness | |
| AMP TURN ON (+) | | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN/YELLOW | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | VIOLET | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | VIOLET/YELLOW | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | BROWN/YELLOW | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | BLUE/RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLUE/WHITE | Radio Harness or Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 3.5", 5.25" | 6x9" | | |
| RADIO DASH KIT OPTIONS | | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
| METRA 99-6501, SCOSCHE CJ1282B | | METRA 70-1817, SCOSCHE CR01B | Not required |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--------------------------|----------------------------------|---|
| 12V CONSTANT WIRE | RED, PINK/BLACK | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | DK. BLUE | Ignition Harness |
| ACCESSORY WIRE | BLACK/ORANGE | Ignition Harness |
| POWER DOOR LOCK (+) | ORANGE/PURPLE or ORANGE/WHITE | Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (+) | PINK/PURPLE | Harness In Driver's Kick Panel |
| PARKING LIGHTS (+) | BLACK/YELLOW | Harness In Driver's Kick Panel |
| DOOR TRIGGER (-) | YELLOW | Harness In Driver's Kick Panel |
| TRUNK TRIGGER (-) | BROWN/BLACK | Harness In Driver's Kick Panel |
| TRUNK RELEASE (+) | BLACK/WHITE | At Trunk Release Switch |
| FACTORY ALARM ARM | ARMS WITH LOCK | |
| FACTORY ALARM DISARM (-) | LT.GREEN/ORANGE | Harness In Driver's Kick Panel |
| TACHOMETER WIRE | BLACK/GRAY | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK/RED | At Relay At Fuse Box |
| LEFT FRONT WINDOW UP | LT.BLUE | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | BROWN/WHITE | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | PURPLE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW UP | BLUE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW DOWN | RED/BLUE | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW UP | GRAY/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW DOWN | GREEN/WHITE | Harness In Driver's Kick From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------|-------------|-------|
| None required | NA | NA |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|---|--------------------|------------------------------|-------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED/WHITE | Radio Harness | |
| RADIO GROUND | Not In Harness | Ground Strap | |
| ILLUMINATION (+) | ORANGE/WHITE | Radio Harness | |
| POWER ANTENNA (+) | | Radio Harness | |
| AMP TURN ON (+) | | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN/YELLOW | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | VIOLET | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | VIOLET/YELLOW | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | BROWN/YELLOW | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | BLUE/RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLUE/WHITE | Radio Harness or Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 3.5", 5.25" | 6x9" | | |
| RADIO DASH KIT OPTIONS | | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
| METRA 99-6501, SCOSCHE CJ1282B | | METRA 70-1817, SCOSCHE CR01B | Not required |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--------------------------|----------------------------------|---|
| 12V CONSTANT WIRE | RED, PINK/BLACK | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | DK. BLUE | Ignition Harness |
| ACCESSORY WIRE | BLACK/ORANGE | Ignition Harness |
| POWER DOOR LOCK (+) | ORANGE/PURPLE or ORANGE/WHITE | Harness In Driver's Kick Panel |
| POWER DOOR UNLOCK (+) | PINK/PURPLE | Harness In Driver's Kick Panel |
| PARKING LIGHTS (+) | BLACK/YELLOW | Harness In Driver's Kick Panel |
| DOOR TRIGGER (-) | YELLOW | Harness In Driver's Kick Panel |
| TRUNK TRIGGER (-) | BROWN/BLACK | Harness In Driver's Kick Panel |
| TRUNK RELEASE (+) | BLACK/WHITE | At Trunk Release Switch |
| FACTORY ALARM ARM | ARMS WITH LOCK | |
| FACTORY ALARM DISARM (-) | LT.GREEN/ORANGE | Harness In Driver's Kick Panel |
| TACHOMETER WIRE | BLACK/GRAY | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK/RED | At Relay At Fuse Box |
| LEFT FRONT WINDOW UP | LT.BLUE | At Driver Window Motor Inside Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Driver Window Motor Inside Door |
| RIGHT FRONT WINDOW UP | BROWN/WHITE | Harness In Driver's Kick From Driver Door |
| RIGHT FRONT WINDOW DOWN | PURPLE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW UP | BLUE/WHITE | Harness In Driver's Kick From Driver Door |
| LEFT REAR WINDOW DOWN | RED/BLUE | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW UP | GRAY/BLACK | Harness In Driver's Kick From Driver Door |
| RIGHT REAR WINDOW DOWN | GREEN/WHITE | Harness In Driver's Kick From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------|-------------|-------|
| None required | NA | NA |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | | |
|---|--------------------|------------------------------|-------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | RED | Radio Harness | |
| RADIO SWITCHED | RED/WHITE | Radio Harness | |
| RADIO GROUND | Not In Harness | Ground Strap | |
| ILLUMINATION (+) | ORANGE/WHITE | Radio Harness | |
| POWER ANTENNA (+) | | Radio Harness | |
| AMP TURN ON (+) | | Radio Harness | |
| LEFT FRONT SPEAKER(+) | GREEN | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | GREEN/YELLOW | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | VIOLET | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | VIOLET/YELLOW | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | BROWN/YELLOW | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | BLUE/RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | BLUE/WHITE | Radio Harness or Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 3.5", 5.25" | 6x9" | | |
| RADIO DASH KIT OPTIONS | | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
| METRA 99-6501, SCOSCHE CJ1282B | | METRA 70-1817, SCOSCHE CR01B | Not required |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.