

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V	Battery	Must go to battery for 12V Constant
STARTER	BLUE/WHITE	Ignition Harness
IGNITION	WHITE/ORANGE	Ignition Harness
ACCESSORY	PURPLE/GREEN	Ignition Harness
POWER DOOR LOCK (-)	GRAY/YELLOW	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
POWER UNLOCK (-)	PURPLE/GRAY	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
PARKING LIGHTS (+)	GRAY/YELLOW	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
PARKING LIGHTS (-)	GRAY	At Light Switch Or Connector D at Module Attached To Fuse Box
DOOR TRIGGER (-)	Use domelight wire. The individual door trigger wires rest at ground and go to an open circuit when the door is opened.	
Notes: Individual door trigger wires. They are: GREEN/PURPLE (left front door), WHITE (right front door), GREEN (left rear door), and YELLOW (right rear door). These wires are found in connector C at module attached To fuse box		
DOME SUPERVISION (+)	BLUE	Harness In Driver's Kick Panel Or Connector E at Module Attached To Fuse Box
TRUNK TRIGGER (-)	YELLOW/ORANGE	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TRUNK RELEASE (-)	BROWN	Harness In Driver's Kick Panel Or Connector D at Module Attached To Fuse Box
FACTRY ALARM ARM (-)	Arms on lock with a door open	
FACTRY ALARM DISARM (-)	PURPLE/BROWN	Harness In Driver's Kick Panel Or Connector C at Module Attached To Fuse Box
TACHOMETER WIRE	NOT GRAY or WHITE/BLUE	Any Fuel Injector
BRAKE WIRE (+)	PURPLE/WHITE	At Switch Or Connector A at Module Attached To Fuse Box
HORN TRIGGER (-)	BLUE/WHITE	Harness At Steering Column Or Connector B at Module Attached To Fuse Box
LEFT FRONT WINDOW UP	BLUE/GRAY	At Switch In Driver's Door
LEFT FRONT WINDOW DOWN	YELLOW/PURPLE	At Switch In Driver's Door
RIGHT FRONT WINDOW UP	YELLOW/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	YELLOW/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	RED/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	BLUE/RED	Radio Harness	
RADIO GROUND	BLACK/BLUE	Radio Harness	
RADIO SWITCHED	GREEN	Radio Harness	
POWER ANTENNA	PURPLE/BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	WHITE	Radio Harness	
LEFT FRONT SPEAKER (-)	WHITE/BROWN	Radio Harness	
RIGHT FRONT SPEAKER (+)	WHITE/PURPLE	Radio Harness	
RIGHT FRONT SPEAKER (-)	WHITE/ORANGE	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN/GREEN	Radio Harness	
LEFT REAR SPEAKER (-)	BROWN/YELLOW	Radio Harness	
RIGHT REAR SPEAKER (+)	BROWN/WHITE	Radio Harness	
RIGHT REAR SPEAKER (-)	BROWN/BLUE	Radio Harness	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8"	6x8"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-5812, SCOSCHE FD1424B	METRA 70-5520, SCOSCHE FD23B	Not required	
Please verify all part numbers before ordering.			