

Vehicle Wiring Information

for the

1990 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS	+ brown		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	tied in with doors		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is dk. blue (+) located at the instrument cluster.

Vehicle Wiring Information

for the

1989 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS	+ brown		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	tied in with doors		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is dk. blue (+) located at the instrument cluster.

Vehicle Wiring Information
for the
1988 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS +	brown		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	tied in with doors		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is dk. blue (+) located at the instrument cluster.

Vehicle Wiring Information
for the
1987 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS +	brown		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	tied in with doors		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is dk. blue (+) located at the instrument cluster.

Vehicle Wiring Information
for the
1986 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
	12V red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS	+ brown		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	tied in with doors		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is orange (+) located at the instrument cluster.

Vehicle Wiring Information

for the

1985 GMC Suburban

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow or purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	driver door harness
POWER UNLOCK	black/white	+	driver door harness
PARKING LIGHTS	+		switch or fuse panel
HEADLIGHTS	yellow	+	at switch
DOOR TRIGGER	white	-	under dash area
TRUNK/HATCH PIN	+		
TACHOMETER	purple/white *2		dist. or ECM *1
BRAKE WIRE	white	+	at brake pedal switch
HORN TRIGGER	black	-	at column
WIPERS	purple		steering column
LF WINDOW UP/DN	dk. blue - brown	A	at drivers door switch
RF WINDOW UP/DN	blu/wht - tan	A	drivers door or boot
LR WINDOW UP/DN	green - purple	A	drivers door or boot
RR WINDOW UP/DN	lt. grn - pur/wht	A	drivers door or boot

Notes:

*1 4-wire harness exiting back of distributor heading towards pass. side or pull glove box and ECM is silver box with two plugs. *2 Diesel wait to start wire is orange (+) located at the instrument cluster.