

### ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Pin 1 in 2-Pin Plug At Dash Sub Relay Box Above Fuse Box
STARTER WIRE (+)	ORANGE	Pin 8 in 28-Pin Plug At Keyless Access Module Right Of Steering Column
STARTER WIRE 2 (-)	GRAY	Pin 18 in 24-Pin Plug At Keyless Access Module Right Of Steering Column
IGNITION WIRE 1	BLUE	Pin 3 in 4-Pin Plug At Dash Sub Relay Box Above Fuse Box
IGNITION WIRE 2	GREEN	Pin 2 in 4-Pin Plug At Dash Sub Relay Box Above Fuse Box
ACCESSORY WIRE 1	ORANGE	Pin 4 in 4-Pin Plug At Dash Sub Relay Box Above Fuse Box
ACCESSORY WIRE 2	YELLOW	Pin 4 in 4-Pin Plug At Dash Sub Relay Box Above Fuse Box
KEYSENSE (-)	BROWN	Pin 6 in 24-Pin Plug At Keyless Access Module Right Of Steering Column
POWER DOOR LOCK (-)	BLUE	Pin 11 in 25-Pin Plug In Driver Kick Panel From Door
POWER DOOR UNLOCK (-)	GRAY	Pin 18 in 25-Pin Plug In Driver Kick Panel From Door
PARKING LIGHTS (+)	RED	Pin 29 in Green 44-Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GRAY	Pin 8 in 12-Pin Plug At Headlight Switch
LEFT FRONT DOOR TRIGGER	GREEN	Behind Dash Fuse Box
RIGHT FRONT DOOR TRIGGER	LIGHT GREEN	Behind Dash Fuse Box
LEFT REAR DOOR TRIGGER	BROWN	Behind Dash Fuse Box
RIGHT REAR DOOR TRIGGER	GRAY	Behind Dash Fuse Box
DOME SUPERVISION (-)	PINK	Pin 18 in 28-Pin Plug Below Dash Fuse Box
TRUNK TRIGGER (-)	BLUE	Pin 6 in Green 44-Pin Plug At Dash Fuse Box
HOOD TRIGGER (-)	LIGHT BLUE	Pin 16 in Green 38-Pin Plug At Dash Fuse Box
FACTORY ALARM ARM (-)	PINK	Pin 24 in 25-Pin Plug In Driver Kick panel
FACTORY ALARM DISARM (-)	BROWN	Pin 9 in 25-Pin Plug In Driver Kick panel
TACHOMETER WIRE (AC)	*	Any Fuel Injector
<b>NOTE:</b> For Si models use: PURPLE, RED, BLUE, or TAN. For non-Si models use: BROWN, RED, BLUE, YELLOW		
PARKING BRAKE (-)	LIGHT GREEN	
REAR DEFROST (-)	LIGHT GREEN	Behind Dash Fuse Box
BRAKE WIRE (+)	LIGHT GREEN	At Brake Switch
REVERSE LIGHT (+)	BROWN	Pin 5 in Green 44-Pin Plug At Dash Fuse Box
HORN TRIGGER (-)	ORANGE	Pin 35 in 38-Pin Plug At Dash Fuse Box
LEFT FRONT WINDOW UP	YELLOW	At Window Switch In Driver Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	At Window Switch In Driver Door
RIGHT FRONT WINDOW DOWN	BROWN	At Window Switch In Driver Door
LEFT REAR WINDOW UP	GREEN	At Window Switch In Driver Door
LEFT REAR WINDOW DOWN	PURPLE	At Window Switch In Driver Door
RIGHT REAR WINDOW UP	LIGHT BLUE	At Window Switch In Driver Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch In Driver Door

### ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING		
WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	PURPLE	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	GRAY	Radio Harness
POWER ANTENNA (+)	BLACK	Radio Harness
AMP TURN ON (+)		Radio Harness
LEFT FRONT SPEAKER(+)	LIGHT GREEN	Radio Harness or Speaker
LEFT FRONT SPEAKER (-)	PINK	Radio Harness or Speaker
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness or Speaker
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness or Speaker
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness or Speaker
LEFT REAR SPEAKER (-)	BROWN	Radio Harness or Speaker
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness or Speaker
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness or Speaker

AUDIO SYSTEM NOTES			
FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
6.5"	6.5"		

STEREO INSTALLATION PARTS			
BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7882B	70-1731	40-HD11
AMERICAN INTERNATIONAL	HONK840	HWH810	HO8
SCOSCHE	HA1713B	HA11B	HAA2B

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.