

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------|-------------------------|---|
| 12V CONSTANT WIRE | RED and PINK | Ignition Harness |
| 12V IGNITION WIRE | GREEN | Ignition Harness |
| SECOND IGNITION WIRE | BLUE | Ignition Harness |
| 12V ACCESSORY WIRE | ORANGE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| POWER DOOR LOCK (5-wire) | WHITE | At Module Inside Driver's Door |
| POWER DOOR UNLOCK (5-wire) | YELLOW | At Module Inside Driver's Door |
| PARKING LIGHTS (+) | BROWN (LEFT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (+) | ORANGE (RIGHT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE | At Body Control Module Left Of Steering Column |
| DOOR TRIGGER (-) | GREEN | At Body Control Module Left Of Steering Column |
| TRUNK TRIGGER (-) | BLUE/BLACK | At Body Control Module Left Of Steering Column |
| TRUNK RELEASE (-) | GREEN | At Body Control Module Left Of Steering Column |
| FUEL DOOR RELEASE (+) | GREEN | Harness In Driver's Kick Panel From Driver's Door |
| HOOD TRIGGER (-) | YELLOW | At Body Control Module Left Of Steering Column |
| TACHOMETER WIRE | NOT PINK or BLACK/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | RED or GRAY | At Brake Pedal Switch |
| HORN TRIGGER (-) | GREEN/ORANGE | Harness Coming From Steering Wheel At Steering Column |
| LEFT FRONT WINDOW UP | WHITE | At Motor In Left Front Door |
| LEFT FRONT WINDOW DOWN | BLUE | At Motor In Left Front Door |
| RIGHT FRONT WINDOW UP | WHITE | At Motor In Right Front Door |
| RIGHT FRONT WINDOW DOWN | BLUE | At Motor In Right Front Door |
| LEFT REAR WINDOW UP | WHITE | At Motor In Left Rear Door |
| LEFT REAR WINDOW DOWN | BLUE | At Motor In Left Rear Door |
| RIGHT REAR WINDOW UP | WHITE | At Motor In Right Rear Door |
| RIGHT REAR WINDOW DOWN | BLUE | At Motor In Right Rear Door |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---------------------------------------|-------------|--|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system |

Please verify all part numbers before ordering.

| AUDIO WIRING | | |
|-------------------------|--------------|-------------------------|
| WIRE | COLOR | LOCATION |
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

| AUDIO SYSTEM NOTES | | | |
|--------------------|--------------------|---|-----------------------------|
| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

| STEREO INSTALLATION PARTS | | | |
|---------------------------|---------------|----------------------|-----------------|
| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
| METRA | 99-7319 | 70-7301 | Not required |
| SCOSCHE | Not available | KA02B | Not required |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------|-------------------------|---|
| 12V CONSTANT WIRE | RED and PINK | Ignition Harness |
| 12V IGNITION WIRE | GREEN | Ignition Harness |
| SECOND IGNITION WIRE | BLUE | Ignition Harness |
| 12V ACCESSORY WIRE | ORANGE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| POWER DOOR LOCK (5-wire) | WHITE | At Module Inside Driver's Door |
| POWER DOOR UNLOCK (5-wire) | YELLOW | At Module Inside Driver's Door |
| PARKING LIGHTS (+) | BROWN (LEFT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (+) | ORANGE (RIGHT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE | At Body Control Module Left Of Steering Column |
| DOOR TRIGGER (-) | GREEN | At Body Control Module Left Of Steering Column |
| TRUNK TRIGGER (-) | BLUE/BLACK | At Body Control Module Left Of Steering Column |
| TRUNK RELEASE (-) | GREEN | At Body Control Module Left Of Steering Column |
| FUEL DOOR RELEASE (+) | GREEN | Harness In Driver's Kick Panel From Driver's Door |
| HOOD TRIGGER (-) | YELLOW | At Body Control Module Left Of Steering Column |
| TACHOMETER WIRE | NOT PINK or BLACK/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | RED or GRAY | At Brake Pedal Switch |
| HORN TRIGGER (-) | GREEN/ORANGE | Harness Coming From Steering Wheel At Steering Column |
| LEFT FRONT WINDOW UP | WHITE | At Motor In Left Front Door |
| LEFT FRONT WINDOW DOWN | BLUE | At Motor In Left Front Door |
| RIGHT FRONT WINDOW UP | WHITE | At Motor In Right Front Door |
| RIGHT FRONT WINDOW DOWN | BLUE | At Motor In Right Front Door |
| LEFT REAR WINDOW UP | WHITE | At Motor In Left Rear Door |
| LEFT REAR WINDOW DOWN | BLUE | At Motor In Left Rear Door |
| RIGHT REAR WINDOW UP | WHITE | At Motor In Right Rear Door |
| RIGHT REAR WINDOW DOWN | BLUE | At Motor In Right Rear Door |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---------------------------------------|-------------|--|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system |

Please verify all part numbers before ordering.

| AUDIO WIRING | | |
|-------------------------|--------------|-------------------------|
| WIRE | COLOR | LOCATION |
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

| AUDIO SYSTEM NOTES | | | |
|--------------------|--------------------|---|-----------------------------|
| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

| STEREO INSTALLATION PARTS | | | |
|---------------------------|---------------|----------------------|-----------------|
| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
| METRA | 99-7319 | 70-7301 | Not required |
| SCOSCHE | Not available | KA02B | Not required |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|----------------------------|-------------------------|---|
| 12V CONSTANT WIRE | RED and PINK | Ignition Harness |
| 12V IGNITION WIRE | GREEN | Ignition Harness |
| SECOND IGNITION WIRE | BLUE | Ignition Harness |
| 12V ACCESSORY WIRE | ORANGE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| POWER DOOR LOCK (5-wire) | WHITE | At Module Inside Driver's Door |
| POWER DOOR UNLOCK (5-wire) | YELLOW | At Module Inside Driver's Door |
| PARKING LIGHTS (+) | BROWN (LEFT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (+) | ORANGE (RIGHT) | At Harness Right Of Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE | At Body Control Module Left Of Steering Column |
| DOOR TRIGGER (-) | GREEN | At Body Control Module Left Of Steering Column |
| TRUNK TRIGGER (-) | BLUE/BLACK | At Body Control Module Left Of Steering Column |
| TRUNK RELEASE (-) | GREEN | At Body Control Module Left Of Steering Column |
| FUEL DOOR RELEASE (+) | GREEN | Harness In Driver's Kick Panel From Driver's Door |
| HOOD TRIGGER (-) | YELLOW | At Body Control Module Left Of Steering Column |
| TACHOMETER WIRE | NOT PINK or BLACK/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | RED or GRAY | At Brake Pedal Switch |
| HORN TRIGGER (-) | GREEN/ORANGE | Harness Coming From Steering Wheel At Steering Column |
| LEFT FRONT WINDOW UP | WHITE | At Motor In Left Front Door |
| LEFT FRONT WINDOW DOWN | BLUE | At Motor In Left Front Door |
| RIGHT FRONT WINDOW UP | WHITE | At Motor In Right Front Door |
| RIGHT FRONT WINDOW DOWN | BLUE | At Motor In Right Front Door |
| LEFT REAR WINDOW UP | WHITE | At Motor In Left Rear Door |
| LEFT REAR WINDOW DOWN | BLUE | At Motor In Left Rear Door |
| RIGHT REAR WINDOW UP | WHITE | At Motor In Right Rear Door |
| RIGHT REAR WINDOW DOWN | BLUE | At Motor In Right Rear Door |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---------------------------------------|-------------|--|
| Transponder Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system |

Please verify all part numbers before ordering.

AUDIO WIRING

| WIRE | COLOR | LOCATION |
|-------------------------|--------------|-------------------------|
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

AUDIO SYSTEM NOTES

| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
|--------------------|--------------------|---|-----------------------------|
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

STEREO INSTALLATION PARTS

| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
|---------|---------------|----------------------|-----------------|
| METRA | 99-7319 | 70-7301 | Not required |
| SCOSCHE | Not available | KA02B | Not required |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|---|--------------------------------|---|
| 12V CONSTANT WIRE | PINK | Pin 5 in 6-Pin Plug At Ignition Switch |
| STARTER WIRE | YELLOW | Pin 1 in 6-Pin Plug At Ignition Switch |
| IGNITION WIRE 1 | GREEN | Pin 6 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 1 | BLUE | Pin 3 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 2 | ORANGE | Pin 4 in 6-Pin Plug At Ignition Switch |
| KEYSENSE (-) | GREEN/BLACK | Pin 1 in 22-Pin Plug At BCM Or Key Switch |
| NOTE: BCM is located behind the dash fuse box on the driver's side | | |
| POWER DOOR LOCK (-) | | Use factory alarm arm |
| POWER DOOR UNLOCK (-) | | Use factory alarm disarm |
| LEFT PARKING LIGHTS (+) | BROWN | Pin 7 in 14-Pin Plug At Dash Fuse Box |
| RIGHT PARKING LIGHTS (+) | ORANGE | Pin 1 in 14-Pin Plug At Dash Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE or WHITE/BLACK | Pin 10 in 26-Pin Plug At BCM |
| ALL DOOR TRIGGER (-) | GREEN | Pin 16 in 16-Pin Plug At BCM |
| DOME SUPERVISION (-) | GREEN or YELLOW/ORANGE | Pin 2 in 14-Pin Plug At BCM |
| TRUNK TRIGGER (-) | BLUE/BLACK | Pin 12 in 22-Pin Plug At BCM |
| HOOD TRIGGER (-) | YELLOW | Pin 6 in 16-Pin Plug At BCM |
| TRUNK RELEASE (-) | PINK | Pin 7 in 16-Pin Plug At BCM |
| FACTORY ALARM ARM (-) | WHITE/ORANGE or RED/ORANGE | Pin 15 in 16-Pin Plug At BCM |

NOTE: Refer to TechDoc 3122

| | | |
|--|-------------------------------|---|
| FACTORY ALARM DISARM (-) | RED/ORANGE | Pin 17 in 20-Pin Plug At Main Power Window Switch |
| NOTE: Unlock requires a double-pulse. Refer to TechDoc 3122 | | |
| DOOR LOCK DETECTION WIRE (-) | LIGHT GREEN | Pin 17 in 20-Pin Plug At Main Power Window Switch |
| TACHOMETER WIRE (AC) | Not ORANGE | Any Fuel Injector |
| PARKING BRAKE (-) | WHITE or BROWN/ORANGE | Pin 10 in 30-Pin Plug At Dash Fuse Box. Also Found In Pin 8 in 16-Pin Plug At BCM |
| REAR DEFROST (-) | RED/GREEN | At HVAC Control Unit |
| BRAKE WIRE (+) | GRAY | Pin 6 in 14-Pin Plug At BCM |
| REVERSE LIGHT (+) | YELLOW | Pin 19 in 30-Pin Plug At Dash Fuse Box |
| HORN TRIGGER (-) | GREEN/ORANGE or PINK/BLACK | Pin 1 in 26-Pin Plug At Dash Fuse Box. Also Found In Pin 21 in 22-Pin Plug At BCM |
| LEFT FRONT WINDOW UP | BLUE | At Motor In Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT FRONT WINDOW UP | BLUE | At Motor In Door |
| RIGHT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| LEFT REAR WINDOW UP | BLUE | At Motor In Door |
| LEFT REAR WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT REAR WINDOW UP | BLUE | At Motor In Door |
| RIGHT REAR WINDOW DOWN | WHITE | At Motor In Door |
| SUNROOF OPEN (+) | GREEN/ORANGE | At Sunroof Switch |
| SUNROOF CLOSE (+) | BROWN/BLACK | At Sunroof Switch |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---|-------------|---|
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | |
|-------------------------|--------------|-------------------------|
| WIRE | COLOR | LOCATION |
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

| AUDIO SYSTEM NOTES | | | |
|--------------------|--------------------|---|-----------------------------|
| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

| STEREO INSTALLATION PARTS | | | |
|---------------------------|----------|----------------------|-----------------|
| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
| SCOSCHE | KA2095B | KA02B | KAAB |
| METRA | 99-7331 | 70-7303 | 40-KI10 |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|---|--------------------------------|---|
| 12V CONSTANT WIRE | PINK | Pin 5 in 6-Pin Plug At Ignition Switch |
| STARTER WIRE | YELLOW | Pin 1 in 6-Pin Plug At Ignition Switch |
| IGNITION WIRE 1 | GREEN | Pin 6 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 1 | BLUE | Pin 3 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 2 | ORANGE | Pin 4 in 6-Pin Plug At Ignition Switch |
| KEYSENSE (-) | GREEN/BLACK | Pin 1 in 22-Pin Plug At BCM Or Key Switch |
| NOTE: BCM is located behind the dash fuse box on the driver's side | | |
| POWER DOOR LOCK (-) | | Use factory alarm arm |
| POWER DOOR UNLOCK (-) | | Use factory alarm disarm |
| LEFT PARKING LIGHTS (+) | BROWN | Pin 7 in 14-Pin Plug At Dash Fuse Box |
| RIGHT PARKING LIGHTS (+) | ORANGE | Pin 1 in 14-Pin Plug At Dash Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE or WHITE/BLACK | Pin 10 in 26-Pin Plug At BCM |
| ALL DOOR TRIGGER (-) | GREEN | Pin 16 in 16-Pin Plug At BCM |
| DOME SUPERVISION (-) | GREEN or YELLOW/ORANGE | Pin 2 in 14-Pin Plug At BCM |
| TRUNK TRIGGER (-) | BLUE/BLACK | Pin 12 in 22-Pin Plug At BCM |
| HOOD TRIGGER (-) | YELLOW | Pin 6 in 16-Pin Plug At BCM |
| TRUNK RELEASE (-) | PINK | Pin 7 in 16-Pin Plug At BCM |
| FACTORY ALARM ARM (-) | WHITE/ORANGE or RED/ORANGE | Pin 15 in 16-Pin Plug At BCM |
| NOTE: Refer to TechDoc 3122 | | |
| FACTORY ALARM DISARM (-) | RED/ORANGE | Pin 17 in 20-Pin Plug At Main Power Window Switch |
| NOTE: Unlock requires a double-pulse. Refer to TechDoc 3122 | | |
| DOOR LOCK DETECTION WIRE (-) | LIGHT GREEN | Pin 17 in 20-Pin Plug At Main Power Window Switch |
| TACHOMETER WIRE (AC) | Not ORANGE | Any Fuel Injector |
| PARKING BRAKE (-) | WHITE or BROWN/ORANGE | Pin 10 in 30-Pin Plug At Dash Fuse Box. Also Found In Pin 8 in 16-Pin Plug At BCM |
| REAR DEFROST (-) | RED/GREEN | At HVAC Control Unit |
| BRAKE WIRE (+) | GRAY | Pin 6 in 14-Pin Plug At BCM |
| REVERSE LIGHT (+) | YELLOW | Pin 19 in 30-Pin Plug At Dash Fuse Box |
| HORN TRIGGER (-) | GREEN/ORANGE or PINK/BLACK | Pin 1 in 26-Pin Plug At Dash Fuse Box. Also Found In Pin 21 in 22-Pin Plug At BCM |
| LEFT FRONT WINDOW UP | BLUE | At Motor In Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT FRONT WINDOW UP | BLUE | At Motor In Door |
| RIGHT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| LEFT REAR WINDOW UP | BLUE | At Motor In Door |
| LEFT REAR WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT REAR WINDOW UP | BLUE | At Motor In Door |
| RIGHT REAR WINDOW DOWN | WHITE | At Motor In Door |
| SUNROOF OPEN (+) | GREEN/ORANGE | At Sunroof Switch |
| SUNROOF CLOSE (+) | BROWN/BLACK | At Sunroof Switch |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---|-------------|---|
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

| AUDIO WIRING | | |
|-------------------------|--------------|-------------------------|
| WIRE | COLOR | LOCATION |
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

| AUDIO SYSTEM NOTES | | | |
|--------------------|--------------------|---|-----------------------------|
| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

| STEREO INSTALLATION PARTS | | | |
|---------------------------|----------|----------------------|-----------------|
| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
| SCOSCHE | KA2095B | KA02B | KAAB |
| METRA | 99-7331 | 70-7303 | 40-KI10 |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM & REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|-------------------|-------------|---|
| 12V CONSTANT WIRE | PINK | Pin 5 in 6-Pin Plug At Ignition Switch |
| STARTER WIRE | YELLOW | Pin 1 in 6-Pin Plug At Ignition Switch |
| IGNITION WIRE 1 | GREEN | Pin 6 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 1 | BLUE | Pin 3 in 6-Pin Plug At Ignition Switch |
| ACCESSORY WIRE 2 | ORANGE | Pin 4 in 6-Pin Plug At Ignition Switch |
| KEYSENSE (-) | GREEN/BLACK | Pin 1 in 22-Pin Plug At BCM Or Key Switch |

NOTE: BCM is located behind the dash fuse box on the driver's side

| | | |
|--------------------------|--------------------------------|---------------------------------------|
| POWER DOOR LOCK (-) | | Use factory alarm arm |
| POWER DOOR UNLOCK (-) | | Use factory alarm disarm |
| LEFT PARKING LIGHTS (+) | BROWN | Pin 7 in 14-Pin Plug At Dash Fuse Box |
| RIGHT PARKING LIGHTS (+) | ORANGE | Pin 1 in 14-Pin Plug At Dash Fuse Box |
| PARKING LIGHTS (-) | WHITE/ORANGE or WHITE/BLACK | Pin 10 in 26-Pin Plug At BCM |
| ALL DOOR TRIGGER (-) | GREEN | Pin 16 in 16-Pin Plug At BCM |
| DOME SUPERVISION (-) | GREEN or YELLOW/ORANGE | Pin 2 in 14-Pin Plug At BCM |
| TRUNK TRIGGER (-) | BLUE/BLACK | Pin 12 in 22-Pin Plug At BCM |
| HOOD TRIGGER (-) | YELLOW | Pin 6 in 16-Pin Plug At BCM |
| TRUNK RELEASE (-) | PINK | Pin 7 in 16-Pin Plug At BCM |
| FACTORY ALARM ARM (-) | WHITE/ORANGE or RED/ORANGE | Pin 15 in 16-Pin Plug At BCM |

NOTE: Refer to TechDoc 3122

| | | |
|--------------------------|------------|---|
| FACTORY ALARM DISARM (-) | RED/ORANGE | Pin 17 in 20-Pin Plug At Main Power Window Switch |
|--------------------------|------------|---|

NOTE: Unlock requires a double-pulse. Refer to TechDoc 3122

| | | |
|------------------------------|-------------------------------|---|
| DOOR LOCK DETECTION WIRE (-) | LIGHT GREEN | Pin 17 in 20-Pin Plug At Main Power Window Switch |
| TACHOMETER WIRE (AC) | Not ORANGE | Any Fuel Injector |
| PARKING BRAKE (-) | WHITE or BROWN/ORANGE | Pin 10 in 30-Pin Plug At Dash Fuse Box. Also Found In Pin 8 in 16-Pin Plug At BCM |
| REAR DEFROST (-) | RED/GREEN | At HVAC Control Unit |
| BRAKE WIRE (+) | GRAY | Pin 6 in 14-Pin Plug At BCM |
| REVERSE LIGHT (+) | YELLOW | Pin 19 in 30-Pin Plug At Dash Fuse Box |
| HORN TRIGGER (-) | GREEN/ORANGE or PINK/BLACK | Pin 1 in 26-Pin Plug At Dash Fuse Box. Also Found In Pin 21 in 22-Pin Plug At BCM |
| LEFT FRONT WINDOW UP | BLUE | At Motor In Door |
| LEFT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT FRONT WINDOW UP | BLUE | At Motor In Door |
| RIGHT FRONT WINDOW DOWN | WHITE | At Motor In Door |
| LEFT REAR WINDOW UP | BLUE | At Motor In Door |
| LEFT REAR WINDOW DOWN | WHITE | At Motor In Door |
| RIGHT REAR WINDOW UP | BLUE | At Motor In Door |
| RIGHT REAR WINDOW DOWN | WHITE | At Motor In Door |
| SUNROOF OPEN (+) | GREEN/ORANGE | At Sunroof Switch |
| SUNROOF CLOSE (+) | BROWN/BLACK | At Sunroof Switch |

ALARM & REMOTE START INTERFACE MODULES

| MODULE | PART NUMBER | NOTES |
|---|-------------|---|
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

| WIRE | COLOR | LOCATION |
|-------------------------|--------------|-------------------------|
| RADIO 12V | ORANGE | Radio Harness |
| RADIO SWITCHED | PINK | Radio Harness |
| RADIO GROUND | BLACK | Radio Harness |
| ILLUMINATION (+) | BLUE/BLACK | Radio Harness |
| POWER ANTENNA (+) | GREEN/BLACK | Radio Harness |
| AMP TURN ON (+) | ORANGE/BLACK | Radio Harness |
| LEFT FRONT TO AMP (+) | GRAY | Radio Harness or Amp |
| LEFT FRONT TO AMP (-) | RED | Radio Harness or Amp |
| RIGHT FRONT TO AMP (+) | BROWN | Radio Harness or Amp |
| RIGHT FRONT TO AMP (-) | WHITE | Radio Harness or Amp |
| LEFT REAR TO AMP (+) | BLUE | Radio Harness or Amp |
| LEFT REAR TO AMP (-) | YELLOW | Radio Harness or Amp |
| RIGHT REAR TO AMP (+) | GREEN | Radio Harness or Amp |
| RIGHT REAR TO AMP (-) | ORANGE | Radio Harness or Amp |
| SUBWOOFER (+) | YELLOW | At Speaker or Amplifier |
| SUBWOOFER (-) | BLACK | At Speaker or Amplifier |
| LEFT FRONT SPEAKER(+) | BLUE | Amplifier or Speaker |
| LEFT FRONT SPEAKER (-) | RED | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (+) | BROWN | Amplifier or Speaker |
| RIGHT FRONT SPEAKER (-) | WHITE | Amplifier or Speaker |
| LEFT REAR SPEAKER (+) | BLUE | Amplifier or Speaker |
| LEFT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |
| RIGHT REAR SPEAKER (+) | GREEN | Amplifier or Speaker |
| RIGHT REAR SPEAKER (-) | ORANGE | Amplifier or Speaker |

AUDIO SYSTEM NOTES

| FRONT SPEAKERS | REAR SPEAKERS | AMP LOCATION | NOTES |
|--------------------|--------------------|---|-----------------------------|
| 1.5" Tweeter, 6.5" | 1.5" Tweeter, 6.5" | The Infinity amp is in the trunk on the driver's side | Subwoofer is 8" if equipped |

STEREO INSTALLATION PARTS

| BRAND | DASH KIT | WIRE HARNESS ADAPTER | ANTENNA ADAPTER |
|---------|----------|----------------------|-----------------|
| SCOSCHE | KA2095B | KA02B | KAAB |
| METRA | 99-7331 | 70-7303 | 40-KI10 |

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.