

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Battery	Must Go To Battery For 12V
STARTER WIRE	LT.BLUE	In 40-Pin Connector At Module Behind Glove Box
SECOND STARTER WIRE	PURPLE	In 40-Pin Connector At Module Behind Glove Box
IGNITION WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
SECOND IGNITION WIRE	PINK	In 40-Pin Connector At Module Behind Glove Box
ACCESSORY WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
POWER DOOR LOCK	BLUE	At Power Window Switch Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK	WHITE	At Power Window Switch Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
PARKING LIGHTS (+)		
Notes: Use (-) parking light wire		
PARKING LIGHTS (-)	YELLOW	In 28-Pin Connector At Driver Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK or ORANGE	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	BROWN or ORANGE	In 28-Pin Connector At Passenger Fuse Box
RIGHT REAR DOOR TRIGGER (-)	ORANGE	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
DOME LIGHT (-)	PURPLE or PINK	In 10-Pin Connector At Module Attached To Driver Fuse Box Under Dash
TRUNK TRIGGER (-)	BLUE or GREEN	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
HOOD TRIGGER (-)	WHITE/BLUE	At Factory Hood Pin
TRUNK RELEASE (-)	PINK	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
FUEL DOOR RELEASE (+)	BLUE	At Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER	WHITE	At Data Link Connector Under Driver Dash
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	WHITE	At Horn Switch Inside Column
POWER WINDOWS		
Notes: Extended triggers on the door lock wires will roll the windows up or down.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	GREEN	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	YELLOW	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
LEFT FRONT SPEAKER (-)	ORANGE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (+)	WHITE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (+)	BLACK	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (-)	GRAY	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (-)	PINK	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (+)	YELLOW	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (-)	BLACK	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (+)	LT.GREEN	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (-)	BLUE	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (-)	PURPLE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (+)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (-)	WHITE	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.GREEN	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.BLUE	At Amp In Trunk – Passenger Side	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE LS2151B	Included with kit	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Battery	Must Go To Battery For 12V
STARTER WIRE	LT.BLUE	In 40-Pin Connector At Module Behind Glove Box
SECOND STARTER WIRE	PURPLE	In 40-Pin Connector At Module Behind Glove Box
IGNITION WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
SECOND IGNITION WIRE	PINK	In 40-Pin Connector At Module Behind Glove Box
ACCESSORY WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
POWER DOOR LOCK	BLUE	At Power Window Switch Inside Driver's Door

Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.

POWER DOOR UNLOCK	WHITE	At Power Window Switch Inside Driver's Door
-------------------	-------	---

Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.

PARKING LIGHTS (+)

Notes: Use (-) parking light wire

PARKING LIGHTS (-)	YELLOW	In 28-Pin Connector At Driver Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK or ORANGE	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	BROWN or ORANGE	In 28-Pin Connector At Passenger Fuse Box
RIGHT REAR DOOR TRIGGER (-)	ORANGE	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
DOME LIGHT (-)	PURPLE or PINK	In 10-Pin Connector At Module Attached To Driver Fuse Box Under Dash
TRUNK TRIGGER (-)	BLUE or GREEN	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
HOOD TRIGGER (-)	WHITE/BLUE	At Factory Hood Pin
TRUNK RELEASE (-)	PINK	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
FUEL DOOR RELEASE (+)	BLUE	At Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER	WHITE	At Data Link Connector Under Driver Dash
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	WHITE	At Horn Switch Inside Column

POWER WINDOWS

Notes: Extended triggers on the door lock wires will roll the windows up or down.

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	GREEN	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	YELLOW	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
LEFT FRONT SPEAKER (-)	ORANGE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (+)	WHITE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (+)	BLACK	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (-)	GRAY	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (-)	PINK	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (+)	YELLOW	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (-)	BLACK	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (+)	LT.GREEN	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (-)	BLUE	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (-)	PURPLE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (+)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (-)	WHITE	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.GREEN	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.BLUE	At Amp In Trunk – Passenger Side	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE LS2151B	Included with kit	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Battery	Must Go To Battery For 12V
STARTER WIRE	LT.BLUE	In 40-Pin Connector At Module Behind Glove Box
SECOND STARTER WIRE	PURPLE	In 40-Pin Connector At Module Behind Glove Box
IGNITION WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
SECOND IGNITION WIRE	PINK	In 40-Pin Connector At Module Behind Glove Box
ACCESSORY WIRE	LT.GREEN	In 40-Pin Connector At Module Behind Glove Box
POWER DOOR LOCK	BLUE	At Power Window Switch Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
POWER DOOR UNLOCK	WHITE	At Power Window Switch Inside Driver's Door
Notes: Test door lock wires while turning the key in the driver's door. Unlock requires a double pulse.		
PARKING LIGHTS (+)		
Notes: Use (-) parking light wire		
PARKING LIGHTS (-)	YELLOW	In 28-Pin Connector At Driver Fuse Box
LEFT FRONT DOOR TRIGGER (-)	RED	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK or ORANGE	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
LEFT REAR DOOR TRIGGER (-)	BROWN or ORANGE	In 28-Pin Connector At Passenger Fuse Box
RIGHT REAR DOOR TRIGGER (-)	ORANGE	In 16-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
DOME LIGHT (-)	PURPLE or PINK	In 10-Pin Connector At Module Attached To Driver Fuse Box Under Dash
TRUNK TRIGGER (-)	BLUE or GREEN	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
HOOD TRIGGER (-)	WHITE/BLUE	At Factory Hood Pin
TRUNK RELEASE (-)	PINK	In 28-Pin Connector At Module Attached To Passenger Fuse Box Behind Glove Box
FUEL DOOR RELEASE (+)	BLUE	At Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
TACHOMETER	WHITE	At Data Link Connector Under Driver Dash
BRAKE WIRE (+)	RED/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	WHITE	At Horn Switch Inside Column
POWER WINDOWS		
Notes: Extended triggers on the door lock wires will roll the windows up or down.		
INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 555XW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	GREEN	Radio Harness	
RADIO GROUND	WHITE/BLACK	Radio Harness	
RADIO SWITCHED	ORANGE	Radio Harness	
RADIO ILLUMINATION	GREEN	Radio Harness	
POWER ANTENNA	YELLOW	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
LEFT FRONT SPEAKER (-)	ORANGE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (+)	WHITE	At Amp In Trunk – Passenger Side	
LEFT FRONT WOOFER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (+)	BLACK	At Amp In Trunk – Passenger Side	
RIGHT FRONT SPEAKER (-)	GRAY	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
RIGHT FRONT WOOFER (-)	PINK	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (+)	YELLOW	At Amp In Trunk – Passenger Side	
CENTER SPEAKER (-)	BLACK	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (+)	LT.GREEN	At Amp In Trunk – Passenger Side	
LEFT REAR SPEAKER (-)	BLUE	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
LEFT REAR WOOFER (-)	PURPLE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (+)	LT.BLUE	At Amp In Trunk – Passenger Side	
RIGHT REAR SPEAKER (-)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (+)	RED	At Amp In Trunk – Passenger Side	
RIGHT REAR WOOFER (-)	WHITE	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	BROWN	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.GREEN	At Amp In Trunk – Passenger Side	
SUBWOOFER (+)	PINK	At Amp In Trunk – Passenger Side	
SUBWOOFER (-)	LT.BLUE	At Amp In Trunk – Passenger Side	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
SCOSCHE LS2151B	Included with kit	Not required
Please verify all part numbers before ordering.		