

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	YELLOW and LT.GREEN/PURPLE	Ignition Harness
STARTER WIRE	RED/LT.BLUE	Ignition Harness
IGNITION WIRE	BLUE/LT.GREEN	Ignition Harness
ACCESSORY WIRE	GRAY/YELLOW	Ignition Harness
SECOND ACCESSORY WIRE	RED/BLACK	Ignition Harness
THIRD ACCESSORY WIRE	BLACK/LT.GREEN	Ignition Harness
POWER DOOR LOCK (-)	PINK/YELLOW	At Central Security Module In Driver's Kick Panel
POWER DOOR UNLOCK (-)	PINK/LT. GREEN	At Central Security Module In Driver's Kick Panel
PARKING LIGHTS (+)	BROWN	Headlight Switch
LEFT FRONT DOOR TRIGGER (-)	BLACK/YELLOW	At Generic Electronic Module Attached To Back Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	BLACK/PINK	At Generic Electronic Module Attached To Back Of Fuse Box
LEFT REAR DOOR TRIGGER (-)	BLACK/LT.BLUE	At Generic Electronic Module Attached To Back Of Fuse Box
RIGHT REAR DOOR TRIGGER (-)	BLACK/WHITE	At Generic Electronic Module Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION	USE DOOR TRIGGER	
TACHOMETER WIRE	Use any wire that is NOT RED/LT.GREEN	Ignition Coil
BRAKE WIRE (+)	LT. GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE	At Central Security Module In Driver's Kick Panel
LEFT FRONT WINDOW UP	WHITE/BLACK	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	ORANGE/WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	TAN/LT.BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	WHITE/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GRAY/ORANGE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	YELLOW/BLACK	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
SecuriLock Immobilizer Bypass Module	DEI 556SW or DEI 556UW	Required when installing a remote start system.
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	GREEN/BLACK	Radio Harness	
RADIO SWITCHED	BLACK/PINK	Radio Harness	
RADIO GROUND	BLACK/GREEN	Radio Harness	
ILLUMINATION (+)	LIGHT BLUE/RED	Radio Harness	
POWER ANTENNA (+)	BLUE	Radio Harness	
AMP TURN ON (+)	LIGHT GREEN/BLACK	Radio Harness	
LEFT FRONT SPEAKER(+)	ORANGE/GREEN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	TAN/GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	GREEN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	GRAY/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BROWN/YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLACK/VIOLET	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE/VIOLET	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x8", 2" Tweeter	6x8"	Subwoofer amplifier is under the center console	If equipped, subwoofer is 8"
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-5802, SCOSCHE FD1300B		METRA 70-1771, SCOSCHE FDK13	Not required
Please verify all part numbers before ordering.			