

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|-------------------|--|
| 12V CONSTANT WIRE | WHITE | Pin 1 in 3-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 1 (-) | BROWN | Pin 18 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 2 (-) | LIGHT BLUE | Pin 21 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 1 | RED | Pin 11 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 2 | PURPLE or YELLOW | Pin 16 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 1 | ORANGE | Pin 31 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 2 | ORANGE | Pin 24 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| KEYSENSE (+) | RED or LIGHT BLUE | Pin 21 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| POWER DOOR LOCK (-) | | |
| Notes: Use factory arm wire | | |
| POWER DOOR UNLOCK (-) | | |
| Notes: Use factory disarm wire | | |
| PARKING LIGHTS (+) | RED | Pin 8 in White 10-Pin Plug At Dash Fuse Box |
| LEFT FRONT DOOR TRIGGER (-) | GRAY or RED | At Body Control Module In Passenger Kick |
| RIGHT FRONT DOOR TRIGGER (-) | LIGHT GREEN | At Body Control Module In Passenger Kick |
| DOME SUPERVISION (-) | PINK or PURPLE | Pin 16 in White 16-Pin Plug At Body Control Module In Passenger Kick |
| TRUNK TRIGGER (-) | RED or ORANGE | Pin 35 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| HOOD TRIGGER (-) | LIGHT GREEN | At OEM Hood Pin |
| TRUNK RELEASE (-) | GRAY | Pin 36 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| Notes: Test At Rear Handle Switch | | |
| FACTORY ALARM ARM (-) | GRAY | Pin 6 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. | | |
| FACTORY ALARM DISARM (-) | PURPLE or WHITE | Pin 7 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. Double-pulse required | | |
| TACHOMETER WIRE (AC) | See notes | Any Fuel Injector |
| Notes: GRAY, BROWN, RED, ORANGE or PURPLE | | |
| PARKING BRAKE (-) | ORANGE | At Parking Brake Switch |
| REAR DEFROST (-) | GREEN | At Body Control Module In Passenger Kick |
| BRAKE WIRE (+) | PINK or BROWN | Pin 7 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| REVERSE LIGHT (+) | ORANGE | Harness In Driver Kick Panel Running Towards Rear |
| HORN TRIGGER (-) | LIGHT GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | | |
| LEFT FRONT WINDOW DOWN | | |
| RIGHT FRONT WINDOW UP | | |
| RIGHT FRONT WINDOW DOWN | | |
| Notes: Extended pulses on the arm and disarm wires will operate the windows | | |
| INTERFACE | PART NUMBER | NOTES |
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

| WIRE | COLOR | LOCATION | NOTES |
|-------------------------|-------------|--------------------------|-------|
| RADIO 12V | YELLOW | Radio Harness | |
| RADIO SWITCHED | BLUE | Radio Harness | |
| RADIO GROUND | Chassis | Not In Harness | |
| ILLUMINATION (+) | RED | Radio Harness | |
| POWER ANTENNA (+) | | In Antenna Adapter | |
| AMP TURN ON (+) | PURPLE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | BLUE | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | LIGHT GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BLUE | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | GREEN | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|----------------------------|-------------------------|
| SCOSCHE NN1665B | SCOSCHE NN04B | SCOSCHE NAA2B |
| METRA 99-7607B | METRA 70-7552 | METRA 40-NI12 |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|-------------------|--|
| 12V CONSTANT WIRE | WHITE | Pin 1 in 3-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 1 (-) | BROWN | Pin 18 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 2 (-) | LIGHT BLUE | Pin 21 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 1 | RED | Pin 11 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 2 | PURPLE or YELLOW | Pin 16 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 1 | ORANGE | Pin 31 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 2 | ORANGE | Pin 24 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| KEYSENSE (+) | RED or LIGHT BLUE | Pin 21 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| POWER DOOR LOCK (-) | | |
| Notes: Use factory arm wire | | |
| POWER DOOR UNLOCK (-) | | |
| Notes: Use factory disarm wire | | |
| PARKING LIGHTS (+) | RED | Pin 8 in White 10-Pin Plug At Dash Fuse Box |
| LEFT FRONT DOOR TRIGGER (-) | GRAY or RED | At Body Control Module In Passenger Kick |
| RIGHT FRONT DOOR TRIGGER (-) | LIGHT GREEN | At Body Control Module In Passenger Kick |
| DOME SUPERVISION (-) | PINK or PURPLE | Pin 16 in White 16-Pin Plug At Body Control Module In Passenger Kick |
| TRUNK TRIGGER (-) | RED or ORANGE | Pin 35 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| HOOD TRIGGER (-) | LIGHT GREEN | At OEM Hood Pin |
| TRUNK RELEASE (-) | GRAY | Pin 36 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| Notes: Test At Rear Handle Switch | | |
| FACTORY ALARM ARM (-) | GRAY | Pin 6 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. | | |
| FACTORY ALARM DISARM (-) | PURPLE or WHITE | Pin 7 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. Double-pulse required | | |
| TACHOMETER WIRE (AC) | See notes | Any Fuel Injector |
| Notes: GRAY, BROWN, RED, ORANGE or PURPLE | | |
| PARKING BRAKE (-) | ORANGE | At Parking Brake Switch |
| REAR DEFROST (-) | GREEN | At Body Control Module In Passenger Kick |
| BRAKE WIRE (+) | PINK or BROWN | Pin 7 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| REVERSE LIGHT (+) | ORANGE | Harness In Driver Kick Panel Running Towards Rear |
| HORN TRIGGER (-) | LIGHT GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | | |
| LEFT FRONT WINDOW DOWN | | |
| RIGHT FRONT WINDOW UP | | |
| RIGHT FRONT WINDOW DOWN | | |
| Notes: Extended pulses on the arm and disarm wires will operate the windows | | |
| INTERFACE | PART NUMBER | NOTES |
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

| WIRE | COLOR | LOCATION | NOTES |
|-------------------------|-------------|--------------------------|-------|
| RADIO 12V | YELLOW | Radio Harness | |
| RADIO SWITCHED | BLUE | Radio Harness | |
| RADIO GROUND | Chassis | Not In Harness | |
| ILLUMINATION (+) | RED | Radio Harness | |
| POWER ANTENNA (+) | | In Antenna Adapter | |
| AMP TURN ON (+) | PURPLE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | BLUE | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | LIGHT GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BLUE | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | GREEN | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|----------------------------|-------------------------|
| SCOSCHE NN1665B | SCOSCHE NN04B | SCOSCHE NAA2B |
| METRA 99-7607B | METRA 70-7552 | METRA 40-NI12 |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|-------------------|--|
| 12V CONSTANT WIRE | WHITE | Pin 1 in 3-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 1 (-) | BROWN | Pin 18 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 2 (-) | LIGHT BLUE | Pin 21 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 1 | RED | Pin 11 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 2 | PURPLE or YELLOW | Pin 16 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 1 | ORANGE | Pin 31 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 2 | ORANGE | Pin 24 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| KEYSENSE (+) | RED or LIGHT BLUE | Pin 21 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| POWER DOOR LOCK (-) | | |
| Notes: Use factory arm wire | | |
| POWER DOOR UNLOCK (-) | | |
| Notes: Use factory disarm wire | | |
| PARKING LIGHTS (+) | RED | Pin 8 in White 10-Pin Plug At Dash Fuse Box |
| LEFT FRONT DOOR TRIGGER (-) | GRAY or RED | At Body Control Module In Passenger Kick |
| RIGHT FRONT DOOR TRIGGER (-) | LIGHT GREEN | At Body Control Module In Passenger Kick |
| DOME SUPERVISION (-) | PINK or PURPLE | Pin 16 in White 16-Pin Plug At Body Control Module In Passenger Kick |
| TRUNK TRIGGER (-) | RED or ORANGE | Pin 35 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| HOOD TRIGGER (-) | LIGHT GREEN | At OEM Hood Pin |
| TRUNK RELEASE (-) | GRAY | Pin 36 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| Notes: Test At Rear Handle Switch | | |
| FACTORY ALARM ARM (-) | GRAY | Pin 6 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. | | |
| FACTORY ALARM DISARM (-) | PURPLE or WHITE | Pin 7 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. Double-pulse required | | |
| TACHOMETER WIRE (AC) | See notes | Any Fuel Injector |
| Notes: GRAY, BROWN, RED, ORANGE or PURPLE | | |
| PARKING BRAKE (-) | ORANGE | At Parking Brake Switch |
| REAR DEFROST (-) | GREEN | At Body Control Module In Passenger Kick |
| BRAKE WIRE (+) | PINK or BROWN | Pin 7 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| REVERSE LIGHT (+) | ORANGE | Harness In Driver Kick Panel Running Towards Rear |
| HORN TRIGGER (-) | LIGHT GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | | |
| LEFT FRONT WINDOW DOWN | | |
| RIGHT FRONT WINDOW UP | | |
| RIGHT FRONT WINDOW DOWN | | |
| Notes: Extended pulses on the arm and disarm wires will operate the windows | | |
| INTERFACE | PART NUMBER | NOTES |
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

AUDIO WIRING

| WIRE | COLOR | LOCATION | NOTES |
|-------------------------|-------------|--------------------------|-------|
| RADIO 12V | YELLOW | Radio Harness | |
| RADIO SWITCHED | BLUE | Radio Harness | |
| RADIO GROUND | Chassis | Not In Harness | |
| ILLUMINATION (+) | RED | Radio Harness | |
| POWER ANTENNA (+) | | In Antenna Adapter | |
| AMP TURN ON (+) | PURPLE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | BLUE | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | LIGHT GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BLUE | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | GREEN | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|----------------------------|-------------------------|
| SCOSCHE NN1665B | SCOSCHE NN04B | SCOSCHE NAA2B |
| METRA 99-7607B | METRA 70-7552 | METRA 40-NI12 |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|-------------------|--|
| 12V CONSTANT WIRE | WHITE | Pin 1 in 3-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 1 (-) | BROWN | Pin 18 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 2 (-) | LIGHT BLUE | Pin 21 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 1 | RED | Pin 11 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 2 | PURPLE or YELLOW | Pin 16 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 1 | ORANGE | Pin 31 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 2 | ORANGE | Pin 24 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| KEYSENSE (+) | RED or LIGHT BLUE | Pin 21 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| POWER DOOR LOCK (-) | | |
| Notes: Use factory arm wire | | |
| POWER DOOR UNLOCK (-) | | |
| Notes: Use factory disarm wire | | |
| PARKING LIGHTS (+) | RED | Pin 8 in White 10-Pin Plug At Dash Fuse Box |
| LEFT FRONT DOOR TRIGGER (-) | GRAY or RED | At Body Control Module In Passenger Kick |
| RIGHT FRONT DOOR TRIGGER (-) | LIGHT GREEN | At Body Control Module In Passenger Kick |
| DOME SUPERVISION (-) | PINK or PURPLE | Pin 16 in White 16-Pin Plug At Body Control Module In Passenger Kick |
| TRUNK TRIGGER (-) | RED or ORANGE | Pin 35 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| HOOD TRIGGER (-) | LIGHT GREEN | At OEM Hood Pin |
| TRUNK RELEASE (-) | GRAY | Pin 36 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| Notes: Test At Rear Handle Switch | | |
| FACTORY ALARM ARM (-) | GRAY | Pin 6 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. | | |
| FACTORY ALARM DISARM (-) | PURPLE or WHITE | Pin 7 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. Double-pulse required | | |
| TACHOMETER WIRE (AC) | See notes | Any Fuel Injector |
| Notes: GRAY, BROWN, RED, ORANGE or PURPLE | | |
| PARKING BRAKE (-) | ORANGE | At Parking Brake Switch |
| REAR DEFROST (-) | GREEN | At Body Control Module In Passenger Kick |
| BRAKE WIRE (+) | PINK or BROWN | Pin 7 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| REVERSE LIGHT (+) | ORANGE | Harness In Driver Kick Panel Running Towards Rear |
| HORN TRIGGER (-) | LIGHT GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | | |
| LEFT FRONT WINDOW DOWN | | |
| RIGHT FRONT WINDOW UP | | |
| RIGHT FRONT WINDOW DOWN | | |
| Notes: Extended pulses on the arm and disarm wires will operate the windows | | |
| INTERFACE | PART NUMBER | NOTES |
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

AUDIO WIRING

| WIRE | COLOR | LOCATION | NOTES |
|-------------------------|-------------|--------------------------|-------|
| RADIO 12V | YELLOW | Radio Harness | |
| RADIO SWITCHED | BLUE | Radio Harness | |
| RADIO GROUND | Chassis | Not In Harness | |
| ILLUMINATION (+) | RED | Radio Harness | |
| POWER ANTENNA (+) | | In Antenna Adapter | |
| AMP TURN ON (+) | PURPLE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | BLUE | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | LIGHT GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BLUE | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | GREEN | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|----------------------------|-------------------------|
| SCOSCHE NN1665B | SCOSCHE NN04B | SCOSCHE NAA2B |
| METRA 99-7607B | METRA 70-7552 | METRA 40-NI12 |

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|-------------------|--|
| 12V CONSTANT WIRE | WHITE | Pin 1 in 3-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 1 (-) | BROWN | Pin 18 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| STARTER WIRE 2 (-) | LIGHT BLUE | Pin 21 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 1 | RED | Pin 11 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| IGNITION WIRE 2 | PURPLE or YELLOW | Pin 16 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 1 | ORANGE | Pin 31 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| ACCESSORY WIRE 2 | ORANGE | Pin 24 in Black 40-Pin Plug At Body Control Module In Passenger Kick |
| KEYSENSE (+) | RED or LIGHT BLUE | Pin 21 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| POWER DOOR LOCK (-) | | |
| Notes: Use factory arm wire | | |
| POWER DOOR UNLOCK (-) | | |
| Notes: Use factory disarm wire | | |
| PARKING LIGHTS (+) | RED | Pin 8 in White 10-Pin Plug At Dash Fuse Box |
| LEFT FRONT DOOR TRIGGER (-) | GRAY or RED | At Body Control Module In Passenger Kick |
| RIGHT FRONT DOOR TRIGGER (-) | LIGHT GREEN | At Body Control Module In Passenger Kick |
| DOME SUPERVISION (-) | PINK or PURPLE | Pin 16 in White 16-Pin Plug At Body Control Module In Passenger Kick |
| TRUNK TRIGGER (-) | RED or ORANGE | Pin 35 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| HOOD TRIGGER (-) | LIGHT GREEN | At OEM Hood Pin |
| TRUNK RELEASE (-) | GRAY | Pin 36 in Gray 40-Pin Plug At Body Control Module In Passenger Kick |
| Notes: Test At Rear Handle Switch | | |
| FACTORY ALARM ARM (-) | GRAY | Pin 6 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. | | |
| FACTORY ALARM DISARM (-) | PURPLE or WHITE | Pin 7 in 16-Pin Plug At Window Switch In Driver Door |
| Notes: Test using key in driver door. Double-pulse required | | |
| TACHOMETER WIRE (AC) | See notes | Any Fuel Injector |
| Notes: GRAY, BROWN, RED, ORANGE or PURPLE | | |
| PARKING BRAKE (-) | ORANGE | At Parking Brake Switch |
| REAR DEFROST (-) | GREEN | At Body Control Module In Passenger Kick |
| BRAKE WIRE (+) | PINK or BROWN | Pin 7 in Green 40-Pin Plug At Body Control Module In Passenger Kick |
| REVERSE LIGHT (+) | ORANGE | Harness In Driver Kick Panel Running Towards Rear |
| HORN TRIGGER (-) | LIGHT GREEN | Harness At Steering Column |
| LEFT FRONT WINDOW UP | | |
| LEFT FRONT WINDOW DOWN | | |
| RIGHT FRONT WINDOW UP | | |
| RIGHT FRONT WINDOW DOWN | | |
| Notes: Extended pulses on the arm and disarm wires will operate the windows | | |
| INTERFACE | PART NUMBER | NOTES |
| Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. |
| Please verify all part numbers before ordering. | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING

| WIRE | COLOR | LOCATION | NOTES |
|-------------------------|-------------|--------------------------|-------|
| RADIO 12V | YELLOW | Radio Harness | |
| RADIO SWITCHED | BLUE | Radio Harness | |
| RADIO GROUND | Chassis | Not In Harness | |
| ILLUMINATION (+) | RED | Radio Harness | |
| POWER ANTENNA (+) | | In Antenna Adapter | |
| AMP TURN ON (+) | PURPLE | Radio Harness | |
| LEFT FRONT SPEAKER(+) | BLUE | Radio Harness or Speaker | |
| LEFT FRONT SPEAKER (-) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (+) | PURPLE | Radio Harness or Speaker | |
| RIGHT FRONT SPEAKER (-) | LIGHT GREEN | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (+) | BLUE | Radio Harness or Speaker | |
| LEFT REAR SPEAKER (-) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (+) | RED | Radio Harness or Speaker | |
| RIGHT REAR SPEAKER (-) | GREEN | Radio Harness or Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|------------------------|----------------------------|-------------------------|
| SCOSCHE NN1665B | SCOSCHE NN04B | SCOSCHE NAA2B |
| METRA 99-7607B | METRA 70-7552 | METRA 40-NI12 |

Please verify all part numbers before ordering.