

TRIPLE S *Customs*

**PONTIAC FIREBIRD 1984-2002
VEHICLE WIRING**

WIRING INFORMATION 1984 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 1985 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 1986 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1987 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1988 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1989 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1990 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BROWN	At Release Switch
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1991 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BLACK	Relay Right Of Steering Column
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1992 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
POWER DOOR LOCK (+)	LIGHTBLUE	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (+)	BLACK	Harness In Driver's Kick Panel Or Harness Coming Into Vehicle From Driver's Door
PARKING LIGHTS (+)	BROWN	At Light Switch Or Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	WHITE	Courtesy Light Under Dash
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK RELEASE WIRE (+)	BLACK	Relay Right Of Steering Column
TRUNK TRIGGER WIRE (-)	BLACK/ORANGE	At Light In Trunk
TACHOMETER WIRE	WHITE or PURPLE/WHITE	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch Or In Driver's Kick Panel
HORN TRIGGER (-)	BLACK	Harness In Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1993 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
DOOR LOCK (5-WIRE REVERSE POLARITY)	LIGHT BLUE (non-keyless versions) RED/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
DOOR UNLOCK (5-WIRE REVERSE POLARITY)	DARK BLUE (non-keyless versions) ORANGE/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	GRAY	Behind Driver's Side Rear Speaker
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK TRIGGER WIRE		Tied in with doors
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Harness In Driver's Kick Panel Running To Vehicle's Rear
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1994 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
DOOR LOCK (5-WIRE REVERSE POLARITY)	LIGHT BLUE (non-keyless versions) RED/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
DOOR UNLOCK (5.WIRE REVERSE POLARITY)	DARK BLUE (non-keyless versions) ORANGE/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	GRAY	Behind Driver's Side Rear Speaker
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK TRIGGER WIRE		Tied in with doors
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Harness In Driver's Kick Panel Running To Vehicle's Rear
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION 1995 Pontiac Firebird

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
DOOR LOCK (5-WIRE REVERSE POLARITY)	LIGHT BLUE (non-keyless versions) RED/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
DOOR UNLOCK (5.WIRE REVERSE POLARITY)	DARK BLUE (non-keyless versions) ORANGE/BLACK (keyless versions)	Harness Coming Into Vehicle From Door Or OEM Keyless Module In Passenger Kick
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel
DOOR TRIGGER WIRE (-)	GRAY	Behind Driver's Side Rear Speaker
DOME LIGHT SUPERVISION (-)		Use door trigger wire
TRUNK TRIGGER WIRE		Tied in with doors
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Harness In Driver's Kick Panel Running To Vehicle's Rear
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition coil
BRAKE WIRE (+)	LT.BLUE or YELLOW	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	DARK BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick Panel From Driver Door

This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system

WIRING INFORMATION: 1996 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-wire reverse polarity)	TAN (driver's door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running To Rear Of Vehicle
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay In Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 1997 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
12V IGNITION WIRE	PINK	Ignition Harness
12V ACCESSORY WIRE	ORANGE	Ignition Harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-wire reverse polarity)	TAN (driver's door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Running To Rear Of Vehicle
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay In Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake Pedal Switch
HORN TRIGGER (-)	BLACK	Harness At Steering Column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 1998 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-WIRE REVERSE POLARITY)	TAN (driver door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Body Control Module Located In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay At Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake pedal switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 1999 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-WIRE REVERSE POLARITY)	TAN (driver door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Body Control Module Located In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay At Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake pedal switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 2000 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-WIRE REVERSE POLARITY)	TAN (driver door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Body Control Module Located In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay At Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake pedal switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 2001 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-WIRE REVERSE POLARITY)	TAN (driver door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Body Control Module Located In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay At Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake pedal switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		

WIRING INFORMATION: 2002 Pontiac Firebird

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
12V IGNITION WIRE	PINK	Ignition harness
12V ACCESSORY WIRE	ORANGE	Ignition harness
POWER LOCK (-)	RED/BLACK	Body Control Module Located In Passenger Kick Panel
POWER UNLOCK (5-WIRE REVERSE POLARITY)	TAN (driver door) and GRAY/BLACK (passenger door)	Body Control Module Located In Passenger Kick Panel
PARKING LIGHTS (+)	BROWN	Body Control Module Located In Passenger Kick Panel
DRIVER DOOR TRIGGER (-)	GRAY/BLACK	Body Control Module
PASSENGER DOOR TRIGGER (-)	BLACK/WHITE	Body Control Module
TRUNK TRIGGER WIRE (-)	ORANGE/BLACK	Body Control Module Located In Passenger Kick Panel
TRUNK RELEASE WIRE (+)	BLACK/WHITE	Relay At Passenger Kick Panel
FACTORY ALARM ARM	Some models are equipped with a factory alarm. The only way to disarm these alarms is with the factory remote or turning on the ignition	
FACTORY ALARM DISARM		
TACHOMETER WIRE	WHITE or RED/BLACK	At Ignition Coil
BRAKE WIRE (+)	LT.BLUE	Plug At Brake pedal switch
HORN TRIGGER (-)	BLACK	Harness At Steering column
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Inside Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Inside Driver's Door
This vehicle is equipped with the VATS anti-theft system. This must be bypassed when installing a remote start system		