

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	
LEFT REAR WINDOW UP	DK.GREEN	
LEFT REAR WINDOW DOWN	PURPLE	
RIGHT REAR WINDOW UP	LT.GREEN	
RIGHT REAR WINDOW DOWN	PURPLE	

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1.5" Tweeter	6x9"	Factory amplifier is under the driver's side dash	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B	METRA Harness included in kit, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	
LEFT REAR WINDOW UP	DK.GREEN	
LEFT REAR WINDOW DOWN	PURPLE	
RIGHT REAR WINDOW UP	LT.GREEN	
RIGHT REAR WINDOW DOWN	PURPLE	

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1.5" Tweeter	6x9"	Factory amplifier is under the driver's side dash	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B	METRA Harness included in kit, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE (-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
Notes: The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	BROWN	Ignition Harness
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
Notes: Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.		
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	
LEFT REAR WINDOW UP	DK.GREEN	
LEFT REAR WINDOW DOWN	PURPLE	
RIGHT REAR WINDOW UP	LT.GREEN	
RIGHT REAR WINDOW DOWN	PURPLE	

INTERFACE	PART NUMBER	NOTES
Passlock II Bypass Module	DEI 556LW or DEI 555LW	Required when installing a remote start system. Refer to TechDoc 3741.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio Harness	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio Harness	
POWER ANTENNA WIRE	YELLOW	Radio Harness	
AMP TURN-ON WIRE (+)	PINK	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Left Front Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Left Front Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Right Front Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Right Front Speaker	
LEFT REAR SPEAKER (+)	BROWN	Left Rear Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Left Rear Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Right Rear Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Right Rear Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5", 1.5" Tweeter	6x9"	Factory amplifier is under the driver's side dash	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3303, SCOSCHE GM1593B	METRA Harness included in kit, SCOSCHE S3-SR1 + S3GM11CB	METRA 40-GM10, SCOSCHE MDA-1B

Please verify all part numbers before ordering.