

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V	Battery
STARTER WIRE	PURPLE	Ignition harness
IGNITION WIRE	ORANGE	Ignition harness
ACCESSORY WIRE	BROWN/WHITE	Ignition harness
Notes: There are two BROWN/WHITE wires in the ignition harness. They are common, so connect to either one.		
POWER DOOR LOCK (-)	BROWN/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-)	LT.GREEN/YELLOW	In 26-Pin Connector At Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	At Fuse Box OR In Harness In Passenger Kick Panel
PARKING LIGHTS (-)	BLUE	At Switch
DRIVER DOOR TRIGGER (-)	GRAY/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
PASSENGER DOORS TRIGGER (-)	WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
TRUNK RELEASE (-)	BLACK/RED	At Switch OR In 16-Pin Connector At Body Control Module Behind Glove Box
FUEL DOOR RELEASE (-)	PURPLE/WHITE	At Release Switch
Notes: A relay must be used to activate fuel door release		
TRUNK TRIGGER (-)	YELLOW/GREEN	In 26-Pin Connector At Body Control Module Behind Glove Box
FACTORY ALARM ARM	Factory remote only	
FACTORY ALARM DISARM	Factory remote only	Harness In Driver's Kick Panel
FACTORY DISARM NO UNLOCK	With Ignition and Immobilizer key	
TACHOMETER WIRE	BROWN/RED	In Green Plug Of Module Under Coolant Bottle
BRAKE WIRE (+)	BLUE/RED	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW	At Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN	At Switch
LEFT FRONT WINDOW DOWN	BLUE	At Switch
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Switch
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	At Switch

INTERFACE	PART NUMBER	NOTES
Passkey III Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	ORANGE/BLACK	Radio Harness	
RADIO GROUND	BLACK/WHITE	Radio Harness	
RADIO SWITCHED	YELLOW	Radio Harness	
RADIO ILLUMINATION	BROWN/WHITE	Radio Harness	
FACTORY AMP TURNS ON			No wire – turns on when it receives signal from rear speakers
POWER ANTENNA	YELLOW/RED	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	GREEN	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW/BLUE	Radio Harness	
RIGHT REAR SPEAKER (+)	BLUE/ORANGE	Radio Harness	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness	
LEFT SUBWOOFER (+)	YELLOW/WHITE	At Amp In Driver's Side Of Trunk	
LEFT SUBWOOFER (-)	YELLOW/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (+)	GREEN/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (-)	GREEN/WHITE	At Amp In Driver's Side Of Trunk	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	On Driver Side of Trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3528, SCOSCHE GM1596B		METRA 70-1784, SCOSCHE VW01B/BCB	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V	Battery
STARTER WIRE	PURPLE	Ignition harness
IGNITION WIRE	ORANGE	Ignition harness
ACCESSORY WIRE	BROWN/WHITE	Ignition harness
Notes: There are two BROWN/WHITE wires in the ignition harness. They are common, so connect to either one.		
POWER DOOR LOCK (-)	BROWN/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-)	LT.GREEN/YELLOW	In 26-Pin Connector At Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	At Fuse Box OR In Harness In Passenger Kick Panel
PARKING LIGHTS (-)	BLUE	At Switch
DRIVER DOOR TRIGGER (-)	GRAY/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
PASSENGER DOORS TRIGGER (-)	WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
TRUNK RELEASE (-)	BLACK/RED	At Switch OR In 16-Pin Connector At Body Control Module Behind Glove Box
FUEL DOOR RELEASE (-)	PURPLE/WHITE	At Release Switch
Notes: A relay must be used to activate fuel door release		
TRUNK TRIGGER (-)	YELLOW/GREEN	In 26-Pin Connector At Body Control Module Behind Glove Box
FACTORY ALARM ARM	Factory remote only	
FACTORY ALARM DISARM	Factory remote only	Harness In Driver's Kick Panel
FACTORY DISARM NO UNLOCK	With Ignition and Immobilizer key	
TACHOMETER WIRE	BROWN/RED	In Green Plug Of Module Under Coolant Bottle
BRAKE WIRE (+)	BLUE/RED	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW	At Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN	At Switch
LEFT FRONT WINDOW DOWN	BLUE	At Switch
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Switch
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	At Switch

INTERFACE	PART NUMBER	NOTES
Passkey III Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	ORANGE/BLACK	Radio Harness	
RADIO GROUND	BLACK/WHITE	Radio Harness	
RADIO SWITCHED	YELLOW	Radio Harness	
RADIO ILLUMINATION	BROWN/WHITE	Radio Harness	
FACTORY AMP TURNS ON			No wire – turns on when it receives signal from rear speakers
POWER ANTENNA	YELLOW/RED	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	GREEN	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW/BLUE	Radio Harness	
RIGHT REAR SPEAKER (+)	BLUE/ORANGE	Radio Harness	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness	
LEFT SUBWOOFER (+)	YELLOW/WHITE	At Amp In Driver's Side Of Trunk	
LEFT SUBWOOFER (-)	YELLOW/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (+)	GREEN/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (-)	GREEN/WHITE	At Amp In Driver's Side Of Trunk	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	On Driver Side of Trunk	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3528, SCOSCHE GM1596B		METRA 70-1784, SCOSCHE VW01B/BCB	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	Must go to battery for 12V	Battery
STARTER WIRE	PURPLE	Ignition harness
IGNITION WIRE	ORANGE	Ignition harness
ACCESSORY WIRE	BROWN/WHITE	Ignition harness
Notes: There are two BROWN/WHITE wires in the ignition harness. They are common, so connect to either one.		
POWER DOOR LOCK (-)	BROWN/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
POWER DOOR UNLOCK (-)	LT.GREEN/YELLOW	In 26-Pin Connector At Body Control Module Behind Glove Box
PARKING LIGHTS (+)	BROWN	At Fuse Box OR In Harness In Passenger Kick Panel
PARKING LIGHTS (-)	BLUE	At Switch
DRIVER DOOR TRIGGER (-)	GRAY/WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
PASSENGER DOORS TRIGGER (-)	WHITE	In 26-Pin Connector At Body Control Module Behind Glove Box
TRUNK RELEASE (-)	BLACK/RED	At Switch OR In 16-Pin Connector At Body Control Module Behind Glove Box
FUEL DOOR RELEASE (-)	PURPLE/WHITE	At Release Switch
Notes: A relay must be used to activate fuel door release		
TRUNK TRIGGER (-)	YELLOW/GREEN	In 26-Pin Connector At Body Control Module Behind Glove Box
FACTORY ALARM ARM	Factory remote only	
FACTORY ALARM DISARM	Factory remote only	Harness In Driver's Kick Panel
FACTORY DISARM NO UNLOCK	With Ignition and Immobilizer key	
TACHOMETER WIRE	BROWN/RED	In Green Plug Of Module Under Coolant Bottle
BRAKE WIRE (+)	BLUE/RED	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	BLACK/YELLOW	At Body Control Module Behind Glove Box
LEFT FRONT WINDOW UP	GREEN	At Switch
LEFT FRONT WINDOW DOWN	BLUE	At Switch
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Switch
RIGHT FRONT WINDOW DOWN	GREEN/BLACK	At Switch

INTERFACE	PART NUMBER	NOTES
Passkey III Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	ORANGE/BLACK	Radio Harness	
RADIO GROUND	BLACK/WHITE	Radio Harness	
RADIO SWITCHED	YELLOW	Radio Harness	
RADIO ILLUMINATION	BROWN/WHITE	Radio Harness	
FACTORY AMP TURNS ON			No wire – turns on when it receives signal from rear speakers
POWER ANTENNA	YELLOW/RED	Radio Harness	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness	
RIGHT FRONT SPEAKER (-)	GREEN	Radio Harness	
LEFT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness	
LEFT REAR SPEAKER (-)	YELLOW/BLUE	Radio Harness	
RIGHT REAR SPEAKER (+)	BLUE/ORANGE	Radio Harness	
RIGHT REAR SPEAKER (-)	BLUE/BLACK	Radio Harness	
LEFT SUBWOOFER (+)	YELLOW/WHITE	At Amp In Driver's Side Of Trunk	
LEFT SUBWOOFER (-)	YELLOW/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (+)	GREEN/RED	At Amp In Driver's Side Of Trunk	
RIGHT SUBWOOFER (-)	GREEN/WHITE	At Amp In Driver's Side Of Trunk	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"	On Driver Side of Trunk	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-3528, SCOSCHE GM1596B	METRA 70-1784, SCOSCHE VW01B/BCB	METRA 40-VW10, SCOSCHE VWAB

Please verify all part numbers before ordering.