

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|---|--------------------|-----------------------------|-------------------------------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |
| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
| 6.5" | 6.5" | | |
| RADIO DASH KIT OPTIONS | | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
| METRA 99-4000, SCOSCHE GM1588B | | METRA 70-1858, SCOSCHE GM02 | METRA 40-GM10, SCOSCHE MDA-1B |
| Please verify all part numbers before ordering. | | | |

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-3301, SCOSCHE GM1583B | METRA 70-2001, SCOSCHE GM03 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-3301, SCOSCHE GM1583B | METRA 70-2001, SCOSCHE GM03 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-3301, SCOSCHE GM1583B | METRA 70-2001, SCOSCHE GM03 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-3301, SCOSCHE GM1583B | METRA 70-2001, SCOSCHE GM03 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-4000, SCOSCHE GM1588B | METRA 70-1858, SCOSCHE GM02 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |

ALARM REMOTE START WIRING

| WIRE | COLOR | LOCATION |
|--|--------------------|---|
| 12V CONSTANT WIRE | RED & RED/WHITE | Ignition Harness |
| STARTER WIRE | YELLOW | Ignition Harness |
| IGNITION WIRE | PINK | Ignition Harness |
| SECOND IGNITION WIRE | WHITE | Ignition Harness |
| ACCESSORY WIRE | ORANGE | Ignition Harness |
| POWER DOOR LOCK (-) | RED/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder. **On vehicles without the factory alarm, use LT. BLUE for lock** | | |
| POWER DOOR UNLOCK (-) | ORANGE/BLACK | Body Control Module Behind Glove Box |
| Notes: Wire will only meter when turning the key in either door key cylinder- Must give a pulse duration for 3.5 seconds to unlock the doors. **On vehicles without the factory alarm, use WHITE for unlock** | | |
| PARKING LIGHTS (+) | BROWN | Harness In Drivers Kick Panel Or Light Switch |
| LEFT FRONT DOOR TRIGGER (-) | TAN | Body Control Module Above Passenger Kick Panel |
| RIGHT FRONT DOOR TRIGGER (-) | DK.BLUE | Body Control Module Above Passenger Kick Panel |
| Notes: This wire also catches the rear lift gate. | | |
| SLIDING DOOR TRIGGER (-) | ORANGE | Body Control Module Above Passenger Kick Panel |
| DOMESUPERVISION | USE DOOR TRIGGER | |
| REAR HATCH TRIGGER | TIED IN WITH DOORS | |
| FACTORY ALARM ARM | ARMS W/ LOCK | |
| FACTORY ALARM DISARM | DISARMS W/ UNLOCK | |
| DISARM NO UNLOCK | | |
| Notes: To disarm the factory alarm without unlocking the doors, use a 0.8 second pulse on the unlock wire | | |
| TACHOMETER WIRE | PURPLE/WHITE | At Ignition Coil |
| BRAKE WIRE (+) | WHITE | At Brake Pedal Switch |
| HORN TRIGGER (-) | BLACK | Body Control Module Behind Glove Box |
| LEFT FRONT WINDOW UP | DARK BLUE | At Motor Inside Driver's Door |
| LEFT FRONT WINDOW DOWN | BROWN | At Motor Inside Driver's Door |
| RIGHT FRONT WINDOW UP | LIGHT BLUE | Harness In Driver's Kick Panel From Driver Door |
| RIGHT FRONT WINDOW DOWN | TAN | Harness In Driver's Kick Panel From Driver Door |

| INTERFACE | PART NUMBER | NOTES |
|---------------------------------------|-------------|---|
| Passkey III Immobilizer Bypass Module | DEI 556UW | Required when installing a remote start system. Also use the LT. GREEN (-) key sense wire at the steering column to interrupt the Passkey bypass unit, so that when the key is inserted to do take over the vehicle does not see two transponders at the same t |

Please verify all part numbers before ordering.

| AUDIO WIRING | | | |
|-------------------------|----------|---------------|-------|
| WIRE | COLOR | LOCATION | NOTES |
| RADIO 12V | ORANGE | Radio Harness | |
| RADIO SWITCHED | YELLOW | Radio Harness | |
| RADIO GROUND | BLACK | Radio Harness | |
| ILLUMINATION (+) | GRAY | Radio Harness | |
| LEFT FRONT SPEAKER(+) | TAN | At Speaker | |
| LEFT FRONT SPEAKER (-) | GRAY | At Speaker | |
| RIGHT FRONT SPEAKER (+) | LT.GREEN | At Speaker | |
| RIGHT FRONT SPEAKER (-) | DK.GREEN | At Speaker | |
| LEFT REAR SPEAKER (+) | BROWN | At Speaker | |
| LEFT REAR SPEAKER (-) | YELLOW | At Speaker | |
| RIGHT REAR SPEAKER (+) | DK.BLUE | At Speaker | |
| RIGHT REAR SPEAKER (-) | LT.BLUE | At Speaker | |

| FRONT SPEAKERS SIZE | REAR SPEAKERS SIZE | AMP LOCATION | NOTES |
|---------------------|--------------------|--------------|-------|
| 6.5" | 6.5" | | |

| RADIO DASH KIT OPTIONS | RADIO WIRE HARNESS OPTIONS | ANTENNA ADAPTER OPTIONS |
|---|-----------------------------|-------------------------------|
| METRA 99-4000, SCOSCHE GM1588B | METRA 70-1858, SCOSCHE GM02 | METRA 40-GM10, SCOSCHE MDA-1B |
| Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar | | |
| Please verify all part numbers before ordering. | | |