

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Behind Fuse Box
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
ACCESSORY WIRE	BROWN	Ignition harness
POWER DOOR LOCK (-)	RED/BLACK	Connector C2 At Body Control Module
POWER DOOR UNLOCK (-)	ORANGE/BLACK	Connector C2 At Body Control Module
PARKING LIGHTS (-)	BROWN/WHITE	Smaller Connector At Body Control Module
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Connector C2 At Body Control Module
RIGHT FRONT DOOR TRIGGER (-)	TAN/WHITE	Connector C2 At Body Control Module
LEFT REAR DOOR TRIGGER (-)	LT.BLUE/BLACK	Connector C2 At Body Control Module
RIGHT REAR DOOR TRIGGER (-)	LT.GREEN/BLACK	Connector C2 At Body Control Module
TRUNK TRIGGER (-)	DARK GREEN	Connector C2 At Body Control Module
FACTORY ALARM ARM	ARMS WITH LOCK AND A DOOR OPEN	
FACTORY ALARM DISARM (-)	PURPLE	Connector C2 At Body Control Module
DOMELIGHT SUPERVISION (+)	GRAY/BLACK	Connector C1 At Body Control Module
TACHOMETER WIRE	NOT PINK	Any Fuel Injector
BRAKE WIRE (+)	WHITE	Connector C2 At Body Control Module
HORN TRIGGER (-)	TAN	Connector C1 At Body Control Module
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	Radio Harness	
RADIO SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3304, SCOSCHE GM1583B	METRA GMOS-01, SCOSCHE DCGM09		METRA 40-GM10, SCOSCHE MDA-1B
Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar			
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Behind Fuse Box
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	PINK	Ignition harness
ACCESSORY WIRE	BROWN	Ignition harness
POWER DOOR LOCK (-)	RED/BLACK	Connector C2 At Body Control Module
POWER DOOR UNLOCK (-)	ORANGE/BLACK	Connector C2 At Body Control Module
PARKING LIGHTS (-)	BROWN/WHITE	Smaller Connector At Body Control Module
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Connector C2 At Body Control Module
RIGHT FRONT DOOR TRIGGER (-)	TAN/WHITE	Connector C2 At Body Control Module
LEFT REAR DOOR TRIGGER (-)	LT.BLUE/BLACK	Connector C2 At Body Control Module
RIGHT REAR DOOR TRIGGER (-)	LT.GREEN/BLACK	Connector C2 At Body Control Module
TRUNK TRIGGER (-)	DARK GREEN	Connector C2 At Body Control Module
FACTORY ALARM ARM	ARMS WITH LOCK AND A DOOR OPEN	
FACTORY ALARM DISARM (-)	PURPLE	Connector C2 At Body Control Module
DOMELIGHT SUPERVISION (+)	GRAY/BLACK	Connector C1 At Body Control Module
TACHOMETER WIRE	NOT PINK	Any Fuel Injector
BRAKE WIRE (+)	WHITE	Connector C2 At Body Control Module
HORN TRIGGER (-)	TAN	Connector C1 At Body Control Module
LEFT FRONT WINDOW UP	DARK BLUE	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	BROWN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	LIGHT BLUE	Harness In Driver's Kick Panel From Driver Door

INTERFACE	PART NUMBER	NOTES
Passkey III Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system.

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	ORANGE	Radio Harness	
RADIO SWITCHED			The radio harness does not provide a switched power source
RADIO GROUND	BLACK/WHITE	Radio Harness	
LEFT FRONT SPEAKER(+)	TAN	At Speaker	
LEFT FRONT SPEAKER (-)	GRAY	At Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	At Speaker	
LEFT REAR SPEAKER (+)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3304, SCOSCHE GM1583B	METRA GMOS-01, SCOSCHE DCGM09		METRA 40-GM10, SCOSCHE MDA-1B
Notes: Use METRA GMRC-01 for wiring harness if not equipped with OnStar			
Please verify all part numbers before ordering.			