

ALARM REMOTE START WIRING		
WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/WHITE	Ignition harness
STARTER WIRE	YELLOW	Ignition harness
IGNITION WIRE	BLACK	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
THIRD IGNITION WIRE	ORANGE	Ignition harness
POWER DOOR LOCK (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
POWER DOOR UNLOCK (-)	BROWN/RED	Harness In Driver's Kick Panel Or Module Under Driver's Seat
<b>Notes:</b> Test door lock wires with both doors closed using the passenger key cylinder		
LEFT PARKING LIGHTS (+)	GRAY/BLACK	At Headlight Switch
RIGHT PARKING LIGHTS (+)	GRAY/RED	At Headlight Switch
DRIVER DOOR TRIGGER (-)	BROWN/GREEN WITH WHITE DOTS	Harness In Driver's Kick Panel Or Module Under Driver's Seat
PASSENGER DOOR TRIGGER (-)	BROWN/GREEN	Harness In Driver's Kick Panel Or Module Under Driver's Seat
TRUNK TRIGGER (-)	BROWN/RED	Module Under Driver's Seat
HOOD TRIGGER (-)	YELLOW/BROWN	Module Under Driver's Seat
TRUNK RELEASE (-)	BLUE/BLACK	Module Under Driver's Seat
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	PURPLE/GREEN	Diagnostic Connector Under Dash On Driver's Side
BRAKE WIRE (+)	BLACK/YELLOW or BLACK/ORANGE	At Brake Pedal Switch
HORN TRIGGER (-)	BROWN/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED		Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW	At Speaker or Amplifier Under Passenger Seat	
LEFT FRONT SPEAKER (-)	YELLOW/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (+)	RED	At Speaker or Amplifier Under Passenger Seat	
RIGHT FRONT SPEAKER (-)	RED/BROWN	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (+)	VIOLET	At Speaker or Amplifier Under Passenger Seat	
LEFT REAR SPEAKER (-)	VIOLET/BROWN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (+)	GREEN	At Speaker or Amplifier Under Passenger Seat	
RIGHT REAR SPEAKER (-)	GREEN/BROWN	At Speaker or Amplifier Under Passenger Seat	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
4"	5.25"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW10, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.