

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	YELLOW, GREEN or BLUE	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor
INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		
<p>Please verify all part numbers before ordering.</p>		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	YELLOW, GREEN or BLUE	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		
<p>Please verify all part numbers before ordering.</p>		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	YELLOW, GREEN or BLUE	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		
<p>Please verify all part numbers before ordering.</p>		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	Any wire that is NOT BLACK/WHITE, WHITE/BLACK, or BLACK	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		
<p>Please verify all part numbers before ordering.</p>		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	Any wire that is NOT BLACK/WHITE, WHITE/BLACK, or BLACK	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		
<p>Please verify all part numbers before ordering.</p>		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHT/BLUE & WHT/RED	Ignition Harness
STARTER WIRE 1	RED	Ignition Harness
IGNITION WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 2	BLACK/RED	Ignition Harness
ACCESSORY WIRE 1	BLUE	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
TACHOMETER WIRE	Any wire that is NOT BLACK/WHITE, WHITE/BLACK, or BLACK	At Any Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
PARKING LIGHTS (-)	GREEN/ORANGE	At Steering Column
HEADLIGHTS (-)	RED/GREEN	At Steering Column
DOOR TRIGGER (-)	RED/WHITE	Plug At Top Right Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/BLACK	Harness On Right Of Fuse Box
REAR DOOR TRIGGER (-)	GREEN/BLACK	Plug At Top Right Of Fuse Box
HOOD TRIGGER (-)	BLACK	At Factory Alarm Module In Center Console
POWER DOOR LOCK (-)	BLUE/WHITE	Harness In Passenger Kick Panel
POWER DOOR UNLOCK (-)	BLUE/YELLOW	Harness In Passenger Kick panel
Notes: Test door lock wires using the key in the passenger door		
LEFT FRONT WINDOW UP	GREEN	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	GREEN/WHITE	At Window Switch In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLUE	At Window Switch In Driver's Door
LEFT REAR WINDOW UP	RED	At Motor
LEFT REAR WINDOW DOWN	YELLOW	At Motor
RIGHT REAR WINDOW UP	RED	At Motor
RIGHT REAR WINDOW DOWN	YELLOW	At Motor

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
ISO Mount - No kit needed	METRA 70-1761, SCOSCHE TA02B	Not required
<p>Notes: For models with a DOUBLE DIN radio, a replacement pocket may be needed to fill the extra space when installing a SINGLE DIN radio, use METRA 88-00-9000 or SCOSCHE TN2150B</p>		

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	BLACK/ORANGE	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	Interior Light Switch On Dash
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	BLACK/ORANGE	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	Interior Light Switch On Dash
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	BLACK/ORANGE	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	Interior Light Switch On Dash
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	BLACK/ORANGE	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	RED/GREEN	Interior Light Switch On Dash
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	BROWN	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
KEY-SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	GREEN/RED	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	BLUE	Ignition Harness
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	WHITE/BLACK	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
KEY-SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	GREEN/RED	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	BLUE	Ignition Harness
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	WHITE/BLACK	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED and WHITE/BLUE	Ignition Harness
STARTER WIRE 1	BLACK/YELLOW	Ignition Harness
IGNITION WIRE 1	BLACK	Ignition Harness
IGNITION WIRE 2	BLACK/YELLOW	Ignition Harness
ACCESSORY WIRE 1	PINK	Ignition Harness
KEY-SENSE WIRE (-)	BLUE/BLACK	Ignition Harness
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM	DISARMS WITH UNLOCK	
DISARM NO UNLOCK (-)	BLUE/BLACK (key-sense wire)	Ignition Harness
TACHOMETER WIRE	GREEN/RED	ECM Behind Glove Box
BRAKE WIRE (+)	GREEN/WHITE	Brake pedal switch
HORN TRIGGER (-)	GREEN/BLACK	Harness At Steering Column
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	GREEN/BLACK	At Steering Column
ALL DOOR TRIGGER (-)	BLUE	Interior Light Switch On Dash
LF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
RF DOOR TRIGGER (-)	RED/YELLOW	At Body ECU Attached To Back Of Fuse Box
LR DOOR TRIGGER (-)	GRAY	In Harness On Right Side of Fuse Box
RR DOOR TRIGGER (-)	RED/WHITE	At Body ECU Attached To Back Of Fuse Box
TRUNK/ REAR HATCH TRIGGER (-)	GREEN/WHITE	At Body ECU Attached To Back Of Fuse Box
DOMELIGHT SUPERVISION (-)	BLUE	Ignition Harness
HOOD TRIGGER (-)	RED/WHITE	At Body ECU
POWER DOOR LOCK (-)	LIGHT GREEN	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	BLUE	Harness In Driver's Kick Panel
Notes: Test door lock wires using the key in the driver door.		
LEFT FRONT WINDOW UP	RED	At Window Switch In Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Window Switch In Driver's Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick Panel
RIGHT FRONT WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick Panel
LEFT REAR WINDOW UP	RED/YELLOW	Harness In Driver's Kick Panel
LEFT REAR WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick Panel
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel
RIGHT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick Panel

INTERFACE	PART NUMBER	NOTES
Transponder Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	At Radio Harness	
12V SWITCHED	GRAY	At Radio Harness	
RADIO GROUND	WHITE/BLACK	At Radio Harness	
ILLUMINATION (+)	GREEN	At Radio Harness	
POWER ANTENNA (+)	BLACK/RED	At Radio Harness	
LEFT FRONT SPEAKER (+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6.5"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8208, SCOSCHE TA2051B	METRA 70-1761, SCOSCHE TA02B	Not required

Please verify all part numbers before ordering.