

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/RED	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	BLACK	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-)	RED/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	RED/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	BLACK/WHITE	2 Wire Harness On Back Of Fuse Box
TACHOMETER WIRE	BLACK	
<b>Notes:</b> V6 Models- Igniter On Passenger Side Of Engine Bay, 4-Cylinder- Igniter On Driver Side Of Engine Bay		
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/GREEN	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/GREEN	In Driver's Door
RIGHT FRONT WINDOW DOWN	RED/BLACK	In Driver's Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"			
5x7"	5x7"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back OF Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN	Big Harness Front Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	GREEN/WHITE	
REAR DOORS TRIGGER (-)	YEL/GREEN	
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5x7"	5x7"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back OF Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN	Big Harness Front Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	GREEN/WHITE	
REAR DOORS TRIGGER (-)	YEL/GREEN	
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5x7"	5x7"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### RADIO REMOVAL

**NOTE:** Factory provision is for a ISO mount double din. When installing an aftermarket stereo a kit will need to be used.

- 1 Remove climate control knobs and unsnap climate control indicator panel
- 2 Remove 2 screws from behind climate control panel and cup holder
- 3 Unsnap radio trim bezel, lift upward, and unplug bezel to remove
- 4 Remove 4 screws securing radio to the dash, unplug, and remove radio.

### FRONT SPEAKER REMOVAL

**NOTE:** Factory provision is for a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Unsnap inside mirror cover.
- 2 Remove 1 plastic push-pin fastener from front top corner of door panel.
- 3 Unsnap front of power window control panel, unplug, and remove
- 4 Remove one screw from behind door release handle.
- 5 Push door release handle forward, uncouple metal rod and remove the handle.
- 6 Remove 2 screw caps from armrest and remove the screw behind each cap.
- 7 Using a panel removal tool, pry out around the sides and bottom of door panel to release the remaining panel fasteners
- 8 Lift door panel up and away from door, unplug any remaining connectors and remove.
- 9 Remove 4 screws securing speaker, unplug, and remove.

### REAR SPEAKER REMOVAL

**NOTE:** Factory speaker is a 6.5" speaker. When installing an aftermarket speaker an adapter may need to be used.

- 1 Using a panel removal tool, carefully pop out the speaker grill and remove.
- 2 Remove 4 screws from enclosure, disconnect, and remove.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition harness
SECOND IGNITION WIRE	BLACK/RED	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back OF Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
POWER DOOR UNLOCK (-)	PURPLE	Harness Next to Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN	Big Harness Front Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	GREEN/WHITE	
REAR DOORS TRIGGER (-)	YEL/GREEN	
TACHOMETER WIRE	LT.GREEN/BLACK	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	N/A	N/A
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5x7"	5x7"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 88-00-9000, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE and WHITE/RED	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLACK/YELLOW	Ignition harness
ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK	Ignition harness
KEY SENSE WIRE (-)	LT.GREEN/RED	Ignition harness
PARKING LIGHTS (+)	GREEN	Harness On Back Of Fuse Box
PARKING LIGHTS (-)	PURPLE/RED, RED, or YELLOW	Harness At Front Of Fuse Box
POWER DOOR LOCK (-)	GRAY	Harness At Front Of Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
POWER DOOR UNLOCK (-)	PURPLE	Harness At Front Of Fuse Box
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN	Harness At Front Of Fuse Box
RIGHT FRONT DOOR TRIGGER (-)	GREEN/WHITE	Harness At Front Of Fuse Box
REAR DOORS TRIGGER (-)	YELLOW/GREEN	Harness At Front Of Fuse Box
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	Wire that is NOT BLACK/YELLOW, BLACK/RED, or BROWN	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLACK	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	RED/GREEN	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5x7"	5x7"		

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8101, SCOSCHE TA2154B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	PURPLE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
POWER DOOR UNLOCK (-)	GREEN/BLACK	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2052B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	PURPLE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
POWER DOOR UNLOCK (-)	GREEN/BLACK	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2052B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	PURPLE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
POWER DOOR UNLOCK (-)	GREEN/BLACK	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2052B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/BLUE and WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	PURPLE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
POWER DOOR UNLOCK (-)	GREEN/BLACK	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Test door lock wires by using the key in the passenger door, not the rocker switch.		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2052B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	BLUE/WHITE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm arm wire unless the door locks do not function when the vehicle is running		
POWER DOOR UNLOCK (-)	GRAY	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm disarm wire unless the door locks do not function when the vehicle is running		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM (-)	PURPLE	Pin 4 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test arm wire by using the key in the driver door, not the rocker switch.		
FACTORY ALARM DISARM (-)	GREEN/BLACK	Pin 8 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test disarm wire by using the key in the driver door, not the rocker switch. A double-pulse will unlock the doors		
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2053S9B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	BLUE/WHITE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm arm wire unless the door locks do not function when the vehicle is running		
POWER DOOR UNLOCK (-)	GRAY	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm disarm wire unless the door locks do not function when the vehicle is running		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM (-)	PURPLE	Pin 4 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test arm wire by using the key in the driver door, not the rocker switch.		
FACTORY ALARM DISARM (-)	GREEN/BLACK	Pin 8 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test disarm wire by using the key in the driver door, not the rocker switch. A double-pulse will unlock the doors		
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2053S9B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A
Please verify all part numbers before ordering.		

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	BLUE/WHITE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm arm wire unless the door locks do not function when the vehicle is running		
POWER DOOR UNLOCK (-)	GRAY	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm disarm wire unless the door locks do not function when the vehicle is running		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM (-)	PURPLE	Pin 4 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test arm wire by using the key in the driver door, not the rocker switch.		
FACTORY ALARM DISARM (-)	GREEN/BLACK	Pin 8 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test disarm wire by using the key in the driver door, not the rocker switch. A double-pulse will unlock the doors		
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8214, SCOSCHE TA2053S9B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A
Please verify all part numbers before ordering.		

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	BLUE/WHITE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm arm wire unless the door locks do not function when the vehicle is running		
POWER DOOR UNLOCK (-)	GRAY	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm disarm wire unless the door locks do not function when the vehicle is running		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM (-)	PURPLE	Pin 4 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test arm wire by using the key in the driver door, not the rocker switch.		
FACTORY ALARM DISARM (-)	GREEN/BLACK	Pin 8 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test disarm wire by using the key in the driver door, not the rocker switch. A double-pulse will unlock the doors		
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8235B or 99-8235CHG, SCOSCHE TA2111B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE/RED	Ignition harness
STARTER WIRE	GREEN/BLACK	Ignition harness
SECOND STARTER WIRE	BLACK/WHITE	Ignition harness
12V IGNITION WIRE	BLACK/RED	Ignition harness
SECOND IGNITION WIRE	BLUE/YELLOW	Ignition harness
ACCESSORY WIRE	WHITE/GREEN	Ignition harness
KEY SENSE WIRE (-)	GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN	Pin 10 of 13 Pin Plug At Dash Fuse Box
PARKING LIGHTS (-)	GREEN	Pin 18 of 20 Pin Plug At Headlight Switch
POWER DOOR LOCK (-)	BLUE/WHITE	Pin 7 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm arm wire unless the door locks do not function when the vehicle is running		
POWER DOOR UNLOCK (-)	GRAY	Pin 6 in 10-pin Connector In Driver's Kick Panel
<b>Notes:</b> Use factory alarm disarm wire unless the door locks do not function when the vehicle is running		
LEFT FRONT DOOR TRIGGER (-)	GREEN/YELLOW	Pin 7 In 18-pin Plug At Fuse Box.
RIGHT FRONT DOOR TRIGGER (-)	RED/BLACK	Pin 8 In 22-Pin Connector On Rear Of Fuse Box
REAR DOORS TRIGGER (-)	PINK/BLACK	Pin 6 In 18-pin Plug At Fuse Box.
DOMELIGHT SUPERVISION (-)	BLUE	Pin 9 In 13-Pin Plug At Fuse Box
FACTORY ALARM ARM (-)	PURPLE	Pin 4 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test arm wire by using the key in the driver door, not the rocker switch.		
FACTORY ALARM DISARM (-)	GREEN/BLACK	Pin 8 in 10-Pin Plug In Driver's Kick Panel
<b>Notes:</b> Test disarm wire by using the key in the driver door, not the rocker switch. A double-pulse will unlock the doors		
DISARM NO UNLOCK (-)	Use key sense wire	
TACHOMETER WIRE	BLACK/WHITE	At Data Link Connector Under Driver's Side Dash
BRAKE WIRE (+)	BLUE	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

### AUDIO WIRING

WIRE	COLOR	LOCATION	NOTES
RADIO 12V	BLUE/YELLOW	Radio Harness	
RADIO SWITCHED	GRAY	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GREEN	Radio Harness	
LEFT FRONT SPEAKER(+)	PINK	At Speaker	
LEFT FRONT SPEAKER (-)	VIOLET	At Speaker	
RIGHT FRONT SPEAKER (+)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	BLUE	At Speaker	
LEFT REAR SPEAKER (+)	BLACK	At Speaker	
LEFT REAR SPEAKER (-)	YELLOW	At Speaker	
RIGHT REAR SPEAKER (+)	RED	At Speaker	
RIGHT REAR SPEAKER (-)	WHITE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6x9", 1.5" Tweeter	6.5"	Behind the passenger rear seat, if equipped	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-8235B or 99-8235CHG, SCOSCHE TA2111B	METRA 70-1761, SCOSCHE TA02B/BCB	N/A

Please verify all part numbers before ordering.