

STS-451

SET ADVANCED KEYPAD ZONE NAMES

TO PROGRAM THE ZONE NAMES:

HOLD * FOR 3 SECONDS

ENTER YOUR MASTER CODE (DEFAULT: 1234)

PRESS # TO ENTER THE USER PROGRAMMING MENU

SELECT OPTION #6

ENTER THE ZONE NUMBER; NAME THE ZONE BY USING THE NUMBER KEYS