

# STS-300 Quick Programming Guide

[www.shieldtechsecurity.com](http://www.shieldtechsecurity.com) (Version 0.01)

Security Code: Set 7 * ???? + ???? Set	???? = New 4-Digit Code
Alarm Code to Disarm: Program 4 * X Program	X = 0 Not Required, 1 Required
Entry Delay: Program 8 * X X Program	XX = 00-99 Seconds
Exit Delay: Program 5 * X X Program	XX = 00-99 Seconds
Siren Duration: Program 6 * X X Program	XX = 01-30 Minutes
Door Chime: Program 0 * X Program	X = 2 Off or 3 On
Audible/Silent Alarm: Program 1 * X Program	X = 0 Off or 1 On
Keypad Tone: Program 3 * X Program	X = 0 Off or 1 On
Phone Numbers: Set M * XXXXXXXXXX Set	M = Slot 1-6; X's = 1-31 Digit Phone Number
Delete Phone Number: Set M * Set	M = Slot 1-6
Record Message: Record ???? Record	???? = Security Code
Phone Line Anti-Cut: Program 2 * X Program	X = 0 Off or 1 On
Rings Before Answer: Program 7 * X Program	X = 0 Off, or 1-3
Learn Remote: Program 9 * ???? 11 Program	???? = Security Code
Learn Sensor: Program 9 * ???? 11 XX Program	???? = Security Code, XX = Zone Number 01-08
Delete All Remotes: Program 9 * ???? 10 Program	???? = Security Code
Delete All Sensors: Program 9 * ???? 20 Program	???? = Security Code
Wireless Siren Code: Program 0 * XXXXXXXX Program	X's = 8-Bit Wireless Siren Code
Bypass Zone: Program 9 * ???? 9 0 XX B Program	???? = Security Code, XX = Zone Number 01-08 B = 0 Bypass, 1 Re-Enable
Reset Settings to Factory Default: Clear Off ???? + ???? Clear Off	???? = Security Code
(This does not delete remotes, sensors, phone numbers, or recording.)	