

Smoke Detector Instructions

Version 1.0


24 Hour Monitoring

If you want the smoke detector to be active 24 hours a day (no matter if the alarm is armed or disarmed,) please set the pins to the following:

Pins 1 through 8: These pins need to be the same on all the smoke detectors.

Pins 9 through 12: These pins need to be set as shown in the picture below.

Program one of the smoke detectors to Zone 1 and you are finished.



smoke fire
2122