

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

REAR SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

REAR SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool

REAR SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.
- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

REAR SPEAKER REMOVAL

- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.
- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

REAR SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

ALARM & REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	BLACK/WHITE	Ignition Harness
IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	YELLOW	Ignition Harness
ACCESSORY WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	BLACK/ORANGE	Module Attached To Passenger Fuse Box
POWER DOOR UNLOCK (-)	BLUE/ORANGE	Module Attached To Passenger Fuse Box
PARKING LIGHTS (+)	RED/BLACK	Harness In Driver's Kick Panel
HEADLIGHTS (-)	BLUE/GREEN	At Light Switch
DOOR TRIGGER (-)	BLACK/WHITE	Courtesy Light Or Harness In Driver's Kick Panel
DOME SUPERVISION	USE DOOR TRIGGER	
TRUNK TRIGGER	TIED IN WITH DOORS	
HOOD TRIGGER (-)	YELLOW	Factory Hood Pin Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
DISARM NO UNLOCK (-)	BLUE	Drivers Lock Key Cylinder
TACHOMETER WIRE	BLUE	2-Pin Plug On Driver's Inner Fender.
BRAKE WIRE (+)	WHITE/BLACK	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	LT. GREEN/BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	RED/BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED/YELLOW	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	BLUE/WHITE	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BLUE/YELLOW	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	RED/BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED/YELLOW	At Window Switch Inside Right Rear Door

ALARM & REMOTE START INTERFACE MODULES

MODULE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AMPLIFIED AUDIO WIRING

WIRE	COLOR	LOCATION
RADIO 12V	WHITE	Radio Harness
RADIO SWITCHED	WHITE/RED	Radio Harness
RADIO GROUND	BLACK	Radio Harness
ILLUMINATION (+)	RED/BLACK	Radio Harness
POWER ANTENNA (+)	YELLOW/WHITE	Radio Harness
AMP TURN ON (+)	*	Radio Harness
LEFT FRONT TO AMP (+)	WHITE	Radio Harness
LEFT FRONT TO AMP (-)	ORANGE	Radio Harness
RIGHT FRONT TO AMP (+)	YELLOW	Radio Harness
RIGHT FRONT TO AMP (-)	BROWN	Radio Harness
LEFT REAR TO AMP (+)	RED/BLACK	Radio Harness
LEFT REAR TO AMP (-)	GREEN	Radio Harness
RIGHT REAR TO AMP (+)	BLUE	Radio Harness
RIGHT REAR TO AMP (-)	BLACK	Radio Harness
LEFT FRONT DOOR SPEAKER (+)	BLUE/GREEN	At Front Bose Amp Under Center Console
LEFT FRONT DOOR SPEAKER (-)	GRAY/BLACK	At Front Bose Amp Under Center Console
LEFT FRONT TWEETER (+)		Wired in parallel with door speaker
LEFT FRONT TWEETER (-)		Wired in parallel with door speaker
RIGHT FRONT DOOR SPEAKER (+)	RED/GREEN	At Front Bose Amp Under Center Console
RIGHT FRONT DOOR SPEAKER (-)	BROWN/BLACK	At Front Bose Amp Under Center Console
RIGHT FRONT TWEETER (+)		Wired in parallel with door speaker
RIGHT FRONT TWEETER (-)		Wired in parallel with door speaker
LEFT REAR SPEAKER (+)	BLUE/YELLOW	At Front Bose Amp Under Center Console
LEFT REAR SPEAKER (-)	GRAY/WHITE	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (+)	RED/YELLOW	At Front Bose Amp Under Center Console
RIGHT REAR SPEAKER (-)	BROWN/WHITE	At Front Bose Amp Under Center Console
REAR TWEETER (+)	GREEN	At Rear Bose Amp Behind Subwoofer
REAR TWEETER (-)	RED	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (+)	BLUE/GREEN	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 1 (-)	ORANGE/BLUE	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (+)	BLUE/YELLOW	At Rear Bose Amp Behind Subwoofer
SUBWOOFER OUTPUT 2 (-)	WHITE/BLUE	At Rear Bose Amp Behind Subwoofer

AUDIO SYSTEM NOTES

FRONT SPEAKERS	REAR SPEAKERS	AMP LOCATION	NOTES
1" Tweeter, 6.5"	6.5"	The front Bose amp is under the center console. The rear Bose amp is behind the subwoofer in the right rear quarter panel.	Subwoofer is 10" if equipped

STEREO INSTALLATION PARTS

BRAND	DASH KIT	WIRE HARNESS ADAPTER	ANTENNA ADAPTER
METRA	99-7866	70-1721	Not required
Notes: If installing double-DIN stereo use 95-7866B dash kit			
SCOSCHE	AA1576B	HA08B	Not required

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

RADIO REMOVAL

- 1 The dash surrounding the trim can be easily scratched by removal tools or the trim panel. Exercise caution
- 2 Carefully remove the dash surrounding the stereo and computer using a pick tool. Unplug all connectors and set aside.
- 3 Remove six (6) screws securing the radio and computer to the dash. Unplug all connectors and remove.

FRONT SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

REAR SPEAKER REMOVAL

- 1 Carefully remove the speaker grill using a pick tool or panel removal tool
- 2 Remove three (3) screws securing the speaker to the door. Unplug and remove.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOME SUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available		Not available	
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	RED	Ignition Harness
KEY SENSE WIRE (-)	PINK	Ignition Harness
POWER DOOR LOCK (+)	PINK	At Door Lock Switch Inside Driver's Door
POWER DOOR UNLOCK (+)	RED	At Door Lock Switch Inside Driver's Door
PARKING LIGHTS (+)	GRAY	At Harness In Driver's Kick Panel Running Towards Rear Of Vehicle
LEFT FRONT DOOR (-)	GREEN	In Green 16-pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In Green 14-pin Plug At Fuse Box
LEFT REAR DOOR (-)	GREEN	In Green 14-pin Plug On Edge Of Fuse Box
RIGHT REAR DOOR (-)	GRAY	In Green 14-pin Plug On Edge Of Fuse Box
DOMESUPERVISION	PINK	In Green 39-pin Plug At Fuse Box
REAR HATCH TRIGGER (-)	LT.GREEN	In Green 42-pin Plug At Rear Fuse Box In Driver's Side Rear Quarter Panel
HOOD PIN (-)	GREEN	At Factory Hood Pin Switch
FACTORY ALARM ARM (-)	LT.BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BLUE	At Key Cylinder Insider Driver Door
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	In 45-pin Plug At Fuse Box
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP		
LEFT FRONT WINDOW DOWN		
RIGHT FRONT WINDOW UP		
RIGHT FRONT WINDOW DOWN		
LEFT REAR WINDOW UP		
LEFT REAR WINDOW DOWN		
RIGHT REAR WINDOW UP		
RIGHT REAR WINDOW DOWN		
Notes: Extended triggers on the factory alarm arm/disarm wires will roll the windows up/down and close/open the sunroof.		
INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556HW or DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	WHITE	Radio Harness	
RADIO SWITCHED	VIOLET	Radio Harness	
RADIO GROUND	BLACK	Radio Harness	
AMP TURN ON (+)	LT GREEN	Radio Harness	
POWER ANTENNA (+)	BLACK		
LEFT FRONT SPEAKER (-)	WHITE	At Speaker	
LEFT FRONT SPEAKER (-)	GREEN	At Speaker	
RIGHT FRONT SPEAKER (-)	RED	At Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	At Speaker	
LEFT REAR SPEAKER (-)	PINK	At Speaker	
LEFT REAR SPEAKER (-)	PURPLE	At Speaker	
RIGHT REAR SPEAKER (-)	BLUE	At Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	At Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is under the right side of the dash near the blower motor	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available		Not available	
Please verify all part numbers before ordering.			