

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOME SUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOME SUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOME SUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOME SUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOME SUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system

Please verify all part numbers before ordering.

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
STARTER WIRE 1	YELLOW	Ignition Harness
IGNITION WIRE 1	BLUE	Ignition Harness
ACCESSORY WIRE 1	ORANGE	Ignition Harness
ACCESSORY WIRE 2	RED	Ignition Harness
FACTORY ALARM ARM (-)	PINK	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
FACTORY ALARM DISARM (-)	BROWN	
Notes: Test arm and disarm wires by turning the key in the driver's door key cylinder.		
TACHOMETER WIRE	NOT BLACK or BLACK/WHITE or YELLOW/BLACK	Any Ignition Coil
BRAKE WIRE (+)	LT.GREEN	Harness In Driver's Kick Panel Or Brake Pedal Switch
HORN TRIGGER (-)	ORANGE	Harness At Steering Column
POWER DOOR LOCK (-)	BLUE	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
POWER DOOR UNLOCK (-)	GRAY	In 34-Pin Plug On Back Of The Fuse/Relay Box Under Driver's Side Dash
PARKING LIGHTS (+)	GRAY	In 42-Pin Plug At Fuse Box
LEFT FRONT DOOR (-)	GREEN	In 42-Pin Plug At Fuse Box
RIGHT FRONT DOOR (-)	LT.GREEN	In 42-Pin Plug At Fuse Box
LEFT REAR DOOR (-)	BROWN	In 42-Pin Plug At Fuse Box
RIGHT REAR DOOR (-)	LT.BLUE	In 42-Pin Plug At Fuse Box
DOMESUPERVISION (-)	PINK	In 8-Pin Plug On Rear Of Fuse Box
REAR HATCH TRIGGER (-)	BLUE	In 42-Pin Plug At Fuse Box
REAR HATCH RELEASE (-)	PINK	In 42-Pin Plug At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Window Switch Inside Driver's Door
LEFT FRONT WINDOW DOWN	RED	At Window Switch Inside Driver's Door
RIGHT FRONT WINDOW UP	YELLOW	At Window Switch Inside Right Front Door
RIGHT FRONT WINDOW DOWN	RED	At Window Switch Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Window Switch Inside Left Rear Door
LEFT REAR WINDOW DOWN	RED	At Window Switch Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Window Switch Inside Right Rear Door
RIGHT REAR WINDOW DOWN	RED	At Window Switch Inside Right Rear Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO CONSTANT	WHITE	Radio Harness	
RADIO GROUND	VIOLET	Radio Harness	
RADIO SWITCHED	BLACK	Radio Harness	
LEFT FRONT SPEAKER (+)	LT.GREEN	Radio Harness Or Speaker	
LEFT FRONT SPEAKER (-)	PINK	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (+)	GRAY	Radio Harness Or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN	Radio Harness Or Speaker	
LEFT REAR SPEAKER (+)	YELLOW	Radio Harness Or Speaker	
LEFT REAR SPEAKER (-)	BROWN	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (+)	BLUE	Radio Harness Or Speaker	
RIGHT REAR SPEAKER (-)	ORANGE	Radio Harness Or Speaker	

FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5	6.5	Amp is located in center console below radio	8" subwoofer, if equipped

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
Not available	Not available	

Please verify all part numbers before ordering.