

**Vehicle Wiring Information**  
for the  
**1990 Alfa Romeo Spider (UK)**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	battery		
STARTER	black		at the steering column
IGNITION	brown *1		at the steering column
SECOND IGNITION			
ACCESSORY			
POWER LOCK	white/violet	-	next to fuse box, 9 pin plug
POWER UNLOCK	white/brown	-	next to fuse box, 9 pin plug
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blue & blue/black		at the steering column
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black or green/white	-	n/s/f door switch
DOME SUPERVISION			
TRUNK/HATCH PIN	black		at the bootlight
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	green		
RF WINDOW UP/DN	yellow		
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

**Notes:**

\*1 Fuel pump wire is green/black wire located on fuel pump relay found behind the fusebox.