

**Vehicle Wiring Information**  
for the  
1989 Audi 90 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY			
SECOND ACCESSORY			
POWER LOCK	grn/red or grn/blu	E	behind o/s/f kick panel
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		brn plug, steering column
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	brn/yel or brn/wht	-	interior light
DOME SUPERVISION			
TRUNK/HATCH PIN	brown/blue		at the bootlight
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

**Vehicle Wiring Information**  
for the  
**1988 Audi 90**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	red/black	+	ignition harness
IGNITION	black	+	ignition harness
ACCESSORY	black/yellow	+	ignition harness
POWER LOCK	grn/red or grn/blu	E	either kick
POWER UNLOCK	same wire		
PARKING LIGHTS +	gray/red & gray/blk		bottom of fuse box
PARKING LIGHTS -			
HEADLIGHTS	yellow	+	switch-low beam only
DOOR TRIGGER	brown/white	-	any pin
TRUNK/HATCH PIN	brown/blue	-	light or switch in trunk
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
TACHOMETER	green/blue		instrument cluster or ECM *1
BRAKE WIRE	red/black	+	brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	blk/red - yel/blu	A	driver door switch
RF WINDOW UP/DN	blk/grn - white	A	driver switch or kick panel
LR WINDOW UP/DN	yellow - yel/blk	A	driver switch or kick panel
RR WINDOW UP/DN	wht/blk - grn/yel	A	driver switch or kick panel

**Notes:**

\*1 The ECM is located behind the passenger kick panel.

**Vehicle Wiring Information**  
for the  
**1993 Audi 90**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	red/black	+	ignition harness
IGNITION	black	+	ignition harness
ACCESSORY	black/yellow	+	ignition harness
POWER LOCK	green/blue	E	driver kick panel
POWER UNLOCK	same wire		
PARKING LIGHTS +	gray/red & gray/blk		bottom of fuse box
PARKING LIGHTS -			
HEADLIGHTS	yellow	+	switch-low beam only
DOOR TRIGGER	brown/white	-	any pin
TRUNK/HATCH PIN	brown/blue	-	light or switch in trunk
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM	brown/white	-	driver kick panel
FCTRY ALRM DISARM	brown/green	-	driver kick panel
TACHOMETER	green/blue		rear of dash *1
BRAKE WIRE	red/black	+	brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	blk/red - yel/blu	A	driver door switch
RF WINDOW UP/DN	blk/grn - white	A	driver switch or kick panel
LR WINDOW UP/DN	yellow - yel/blk	A	driver switch or kick panel
RR WINDOW UP/DN	wht/blk - grn/yel	A	driver switch or kick panel

**Notes:**

\*1 Behind instrument cluster, pin #22 in yellow plug.

**Vehicle Wiring Information**  
for the  
**1994 Audi 90**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	red/black	+	ignition harness
IGNITION	black	+	ignition harness
POWER LOCK	green/blue	E	driver kick panel
POWER UNLOCK	same wire		
PARKING LIGHTS +	gray/red & gray/blk		bottom of fuse box
PARKING LIGHTS -			
HEADLIGHTS	yellow	+	switch-low beam only
DOOR TRIGGER	brown/white	-	any pin
TRUNK/HATCH PIN	brown/blue	-	light or switch in trunk
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM	brown/blue	-	driver kick panel
FCTRY ALRM DISARM	brown/green	-	driver kick panel
TACHOMETER	green/blue		rear of dash *1
BRAKE WIRE	red/black	+	brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			

**Notes:**

\*1 Behind instrument cluster, pin #22 in yellow plug.