

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	Behind Fuse Box
POWER DOOR LOCK (-)	BROWN/GRAY	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness Coming Into Vehicle From Driver's Door
<b>Notes:</b> Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.		
DOOR TRIGGER (-)	BROWN/BLUE	At Door Pin
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/WHITE	At Light In Trunk
HOOD TRIGGER (-)	BROWN/RED	At Hood Pin
TRUNK RELEASE (+)	RED/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	YELLOW, YELLOW/RED, or YELLOW/GREEN	Any Ignition Coil
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLUE	Radio Harness	
RADIO SWITCHED	BLACK/RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	RED	Radio Harness	
AMP TURN ON (+)	RED/BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GRAY	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	Behind Fuse Box
POWER DOOR LOCK (-)	BROWN/GRAY	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness Coming Into Vehicle From Driver's Door
<b>Notes:</b> Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.		
DOOR TRIGGER (-)	BROWN/BLUE	At Door Pin
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/WHITE	At Light In Trunk
HOOD TRIGGER (-)	BROWN/RED	At Hood Pin
TRUNK RELEASE (+)	RED/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	YELLOW, YELLOW/RED, or YELLOW/GREEN	Any Ignition Coil
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLUE	Radio Harness	
RADIO SWITCHED	BLACK/RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	RED	Radio Harness	
AMP TURN ON (+)	RED/BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GRAY	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-1784, SCOSCHE VW01	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	Behind Fuse Box
POWER DOOR LOCK (-)	BROWN/GRAY	Harness Coming Into Vehicle From Driver's Door
POWER DOOR UNLOCK (-)	BROWN/GREEN	Harness Coming Into Vehicle From Driver's Door
<b>Notes:</b> Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.		
DRIVER DOOR TRIGGER (-)	BROWN/BLACK	At Driver's Door Pin
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	At Passenger Door Pin
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
HOOD TRIGGER (-)	BROWN/RED	At Hood Pin
TRUNK RELEASE (+)	RED/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	YELLOW, YELLOW/RED, or YELLOW/GREEN	Any Ignition Coil
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLUE	Radio Harness	
RADIO SWITCHED	BLACK/RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	RED	Radio Harness	
AMP TURN ON (+)	RED/BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GRAY	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS	
METRA 99-9106, SCOSCHE AU2300B	METRA 70-1784, SCOSCHE VW01	METRA 40-VW10, SCOSCHE VWA-2	
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN/BLACK and GREEN/RED	At Headlight Switch

**Notes:** If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition

POWER DOOR LOCK (-)	GREEN/BLUE	At Keyless Module Under Driver's Floor Mat In Front Of Seat
POWER DOOR UNLOCK (-)	BROWN/YELLOW or BROWN/GRAY	At Keyless Module

**Notes:** Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.

DRIVER FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Module
DRIVER REAR DOOR TRIGGER (-)	BLACK/RED	At Keyless Module
FRONT PASSENGER DOOR TRIGGER (-)	RED/GRAY	At Keyless Module
REAR PASSENGER DOOR TRIGGER (-)	BLACK/PURPLE	At Keyless Module
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
HOOD TRIGGER (-)	GRAY/RED	At Keyless Module
TRUNK RELEASE (+)	PURPLE/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	GRAY/YELLOW, GREEN/WHITE, or GREEN/GRAY	At Coil Pack In Front Of Engine
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLUE	Radio Harness	
RADIO SWITCHED	BLACK/RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	RED	Radio Harness	
AMP TURN ON (+)	RED/BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GRAY	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-9106, SCOSCHE AU2300B		METRA 70-1784, SCOSCHE VW01	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN/BLACK and GREEN/RED	At Headlight Switch

**Notes:** If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition

POWER DOOR LOCK (-)	GREEN/BLUE	At Keyless Module Under Driver's Floor Mat In Front Of Seat
POWER DOOR UNLOCK (-)	BROWN/YELLOW or BROWN/GRAY	At Keyless Module

**Notes:** Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.

DRIVER FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Module
DRIVER REAR DOOR TRIGGER (-)	BLACK/RED	At Keyless Module
FRONT PASSENGER DOOR TRIGGER (-)	RED/GRAY	At Keyless Module
REAR PASSENGER DOOR TRIGGER (-)	BLACK/PURPLE	At Keyless Module
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
HOOD TRIGGER (-)	GRAY/RED	At Keyless Module
TRUNK RELEASE (+)	PURPLE/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	GRAY/YELLOW, GREEN/WHITE, or GREEN/GRAY	At Coil Pack In Front Of Engine
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/BLUE	Radio Harness	
RADIO SWITCHED	BLACK/RED	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	RED	Radio Harness	
AMP TURN ON (+)	RED/BLUE	Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/GRAY	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLUE/BROWN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED/GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/GRAY	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/GREEN	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED/GREEN	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-9106, SCOSCHE AU2300B		METRA 70-1784, SCOSCHE VW01	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN/BLACK and GREEN/RED	At Headlight Switch

**Notes:** If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition

POWER DOOR LOCK (-)	GREEN/BLUE	At Keyless Module Under Driver's Floor Mat In Front Of Seat
POWER DOOR UNLOCK (-)	BROWN/YELLOW or BROWN/GRAY	At Keyless Module

**Notes:** Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.

DRIVER FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Module Under Driver's Floor Mat In Front Of Seat
DRIVER REAR DOOR TRIGGER (-)	BLACK/RED	At Keyless Module
FRONT PASSENGER DOOR TRIGGER (-)	RED/GRAY	At Keyless Module
REAR PASSENGER DOOR TRIGGER (-)	BLACK/PURPLE	At Keyless Module
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
HOOD TRIGGER (-)	GRAY/RED	At Keyless Module
TRUNK RELEASE (+)	PURPLE/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	GRAY/YELLOW, GREEN/WHITE, or GREEN/GRAY	At Coil Pack In Front Of Engine
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	BLACK/BLUE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-9101, SCOSCHE AU2380B		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW53, SCOSCHE VWAB
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	BLACK	Ignition harness
STARTER WIRE	RED/BLACK	Ignition harness
SECOND STARTER WIRE	BLUE	Ignition harness
12V ACCESSORY WIRE	YELLOW/BLACK	Ignition harness
PARKING LIGHTS (+)	GREEN/BLACK and GREEN/RED	At Headlight Switch

**Notes:** If vehicle has daytime running lights, use GREEN/GRAY at the headlight switch and use a relay to isolate the wire from the switch to prevent backfeeding to the ignition

POWER DOOR LOCK (-)	GREEN/BLUE	At Keyless Module Under Driver's Floor Mat In Front Of Seat
POWER DOOR UNLOCK (-)	BROWN/YELLOW or BROWN/GRAY	At Keyless Module

**Notes:** Unlock requires a double pulse. The first pulse unlocks the driver's door and disarms the factory security. The second pulse unlocks the rest of the doors.

DRIVER FRONT DOOR TRIGGER (-)	GREEN/YELLOW	At Keyless Module
DRIVER REAR DOOR TRIGGER (-)	BLACK/RED	At Keyless Module
FRONT PASSENGER DOOR TRIGGER (-)	RED/GRAY	At Keyless Module
REAR PASSENGER DOOR TRIGGER (-)	BLACK/PURPLE	At Keyless Module
TRUNK TRIGGER (-)	RED/BLACK	At Light In Trunk
HOOD TRIGGER (-)	GRAY/RED	At Keyless Module
TRUNK RELEASE (+)	PURPLE/GREEN	At Trunk Release Switch
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER WIRE	GRAY/YELLOW, GREEN/WHITE, or GREEN/GRAY	At Coil Pack In Front Of Engine
BRAKE WIRE (+)	RED/BLACK	At Brake Pedal Switch
HORN TRIGGER (+)	BLACK/YELLOW	Relay Under Dash On Driver's Side
LEFT FRONT WINDOW UP	Not recommended	
LEFT FRONT WINDOW DOWN	Not recommended	
RIGHT FRONT WINDOW UP	Not recommended	
RIGHT FRONT WINDOW DOWN	Not recommended	
LEFT REAR WINDOW UP	Not recommended	
LEFT REAR WINDOW DOWN	Not recommended	
RIGHT REAR WINDOW UP	Not recommended	
RIGHT REAR WINDOW DOWN	Not recommended	

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	BLACK/BLUE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)	GRAY/BLUE	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	BLUE/WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN/WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLUE/WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BROWN/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	6.5"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-9101, SCOSCHE AU2380B		METRA 70-1787, SCOSCHE VW05B	METRA 40-VW53, SCOSCHE VWAB
Please verify all part numbers before ordering.			