

Vehicle Wiring Information
for the
1995 Audi A8 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	black/yellow		ignition harness
SECOND ACCESSORY	thin red/blue		ignition harness
POWER LOCK	brown/yellow	-	black plug at pump in boot
POWER UNLOCK	brown/red	-	black plug at pump in boot
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		at the steering column
PARKING LIGHTS -			
HEADLIGHTS	thick yellow *1	+	light switch
DOOR TRIGGER	brn/vio or grn/blu	-	underdash light
DOVE SUPERVISION			
TRUNK/HATCH PIN	brown/blue		boot light
HOOD PIN			
TRNK/HTCH RELEASE	*2		
FCTRY ALARM ARM			
FCTRY ALRM DISARM	brown/green		driver kick panel
DISARM NO UNLOCK			
TACHOMETER	grn/blu or yellow		ignition coil module
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	total close - open		
RF WINDOW UP/DN	total close - open		
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Cut the wire and relay isolate the positive trigger from the switch. *2 Memory seats - mem1/white/black - mem2/black. Found in loom to door.

Vehicle Wiring Information
for the
1996 Audi A8 (UK)

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/black		ignition harness
SECOND STARTER			
IGNITION	black		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	black/yellow		ignition harness
SECOND ACCESSORY	thin red/blue		ignition harness
POWER LOCK	brown/yellow	-	black plug at pump in boot
POWER UNLOCK	brown/red	-	black plug at pump in boot
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	blk/grn & blk/wht		at the steering column
PARKING LIGHTS -			
HEADLIGHTS	thick yellow *1	+	light switch
DOOR TRIGGER	brn/vio or grn/blu	-	underdash light
DOOR SUPERVISION			
TRUNK/HATCH PIN	brown/blue		boot light
HOOD PIN			
TRNK/HATCH RELEASE	*2		
FCTRY ALARM ARM			
FCTRY ALRM DISARM	brown/green		driver kick panel
DISARM NO UNLOCK			
TACHOMETER	grn/blu or yellow		ignition coil module
SPEED SENSE			
BRAKE WIRE	red/black		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	total close - open		
RF WINDOW UP/DN	total close - open		
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

*1 Cut the wire and relay isolate the positive trigger from the switch. *2 Memory seats - mem1/white/black - mem2/black. Found in loom to door.