

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	Not available	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	Not available	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	Not available	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	Not available	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	Not available	Not required
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel

Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.

POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk

TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	WHITE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BLACK	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
Notes: On models without the OEM alarm plug, door lock wires can be found at the ZV module. The ZV module is a black plastic box behind the glove box on the right side to the right of the ABS control module. Remove the ABS module WITHOUT UNPLUGGING IT to access		
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
Notes: On 318 models without the OEM alarm plug, use BROWN/PURPLE at the passenger pin switch for door trigger.		
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	

Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4"	Behind Rear Seat	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GRAY/WHITE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (-)	YELLOW/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
POWER DOOR UNLOCK (-)	GREEN/BLUE	In Driver's Kick Panel
Notes: To access power door lock wires, remove speaker panel and plastic cover below speaker in driver's kick panel. Remove two screws to remove relays. Keep relays upright to prevent them from filling with water later. Only operate locks with all doors closed.		
DOOR TRIGGER (-)	BROWN/PURPLE	Relay In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN/PURPLE on convertible models	At Light In Trunk
TACHOMETER WIRE	BLACK	Diagnostic Connector Under Hood
BRAKE WIRE (+)	GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW	At Steering Column
LEFT FRONT WINDOW UP	BLACK	At Window Switch In Center Console
LEFT FRONT WINDOW DOWN	PURPLE	At Window Switch In Center Console
RIGHT FRONT WINDOW UP	BLACK/GRAY	At Window Switch In Center Console
RIGHT FRONT WINDOW DOWN	PURPLE/GRAY	At Window Switch In Center Console
LEFT REAR WINDOW UP	BLUE/GREEN	At Window Switch In Center Console
LEFT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console
RIGHT REAR WINDOW UP	BROWN/GREEN	At Window Switch In Center Console
RIGHT REAR WINDOW DOWN	BLACK/YELLOW	At Window Switch In Center Console

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
5.25"	4"	Behind Rear Seat	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required		METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B		METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B		METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED or RED/WHITE	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
SECOND IGNITION WIRE	PURPLE or PURPLE/WHITE	Ignition harness
STARTER WIRE	BLACK/YELLOW or GREEN/BLACK	Ignition harness
PARKING LIGHTS (+)	GRAY/PURPLE and GRAY/YELLOW	At Headlight Switch
POWER DOOR LOCK (+)	WHITE/RED	OEM Alarm Plug Behind Glove Box
POWER DOOR UNLOCK (+)	BLUE/RED	OEM Alarm Plug Behind Glove Box
DRIVER DOOR TRIGGER (-)	BROWN/GRAY	OEM Alarm Plug Behind Glove Box
PASSENGER DOOR TRIGGER (-)	BROWN/BLUE	OEM Alarm Plug Behind Glove Box
REAR DOORS TRIGGER (-)	BROWN/BLACK	OEM Alarm Plug Behind Glove Box
DOMELIGHT SUPERVISION	Comes on with unlock	
TRUNK TRIGGER (-)	BROWN/BLACK or BROWN	At Light In Trunk
HOOD TRIGGER (-)	PURPLE/GREEN	Hood Pin Switch
TACHOMETER WIRE	BLACK	Instrument Cluster
Notes: Do not unplug the instrument cluster with the ignition on or turn the ignition on when the instrument cluster is disconnected.		
BRAKE WIRE (+)	BLUE/RED or GREEN/RED	At Brake Pedal Switch
HORN TRIGGER (+)	BROWN/YELLOW or BROWN/RED	At Steering Column
LEFT FRONT WINDOW UP	Not Recommended	
LEFT FRONT WINDOW DOWN	Not Recommended	
RIGHT FRONT WINDOW UP	Not Recommended	
RIGHT FRONT WINDOW DOWN	Not Recommended	
LEFT REAR WINDOW UP	Not Recommended	
LEFT REAR WINDOW DOWN	Not Recommended	
RIGHT REAR WINDOW UP	Not Recommended	
RIGHT REAR WINDOW DOWN	Not Recommended	
Notes: The OEM alarm plug is a black 12-pin plug behind the glove box. The pins of the plug face towards the rear of the car.		
INTERFACE	PART NUMBER	NOTES
EWS II Bypass Module	DEI 556UW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED/WHITE	Radio Harness	
RADIO SWITCHED	PURPLE/WHTIE	Radio Harness	
RADIO GROUND	BROWN	Radio Harness	
ILLUMINATION (+)		Radio Harness	
POWER ANTENNA (+)	WHITE	Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	YELLOW/RED	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	BLACK/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLACK	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	BLACK/ORANGE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	BLUE/BLACK	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	BROWN/ORANGE	Radio Harness or Speaker	

RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
DIN opening - none required	METRA 70-8590, SCOSCHE BW01B	METRA 40-VW10, SCOSCHE VWA-2
Please verify all part numbers before ordering.		