

Vehicle Wiring Information
for the
1980 Buick Regal

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	either kick
POWER UNLOCK	black	+	either kick
PARKING LIGHTS +	brown		headlight switch *1
HEADLIGHTS	yellow	+	headlight switch
DOOR TRIGGER	white	-	headlight switch *1
DOME SUPERVISION	use door trigger		
TRNK/HTCH RELEASE	black	+	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green	-	either kick or alarm *2
TACHOMETER	pur/wht or white		distributor *3
BRAKE WIRE	white	+	brake switch
HORN TRIGGER	black	-	steering column
WIPERS	purple	+	wiper switch
LF WINDOW UP/DN	dk. blu - brown	A	in drivers door
RF WINDOW UP/DN	dk. blu/wht - tan	A	in drivers door or dkp
LR WINDOW UP/DN	gray - tan	A	in drivers door or dkp
RR WINDOW UP/DN	lt. blue - dk. blue	A	in drivers door or dkp

Notes:

*1 Also found low in the drivers side kick panel. *2 The factory alarm is located to the left of the steering column. *3 Also found at the rear of the instrument cluster.

Vehicle Wiring Information
for the
1981 Buick Regal

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	purple	+	ignition harness
IGNITION	pink	+	ignition harness
ACCESSORY	orange	+	ignition harness
POWER LOCK	lt. blue	+	either kick
POWER UNLOCK	black	+	either kick
PARKING LIGHTS	+ brown		headlight switch *1
HEADLIGHTS	yellow	+	headlight switch
DOOR TRIGGER	white	-	headlight switch *1
DOME SUPERVISION	use door trigger		
TRNK/HTCH RELEASE	black	+	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green	-	either kick or alarm *2
TACHOMETER	pur/wht or white		distributor *3
BRAKE WIRE	white	+	brake switch
HORN TRIGGER	black	-	steering column
WIPERS	purple	+	wiper switch
LF WINDOW UP/DN	dk. blu - brown	A	in drivers door
RF WINDOW UP/DN	dk. blu/wht - tan	A	in drivers door or dkp
LR WINDOW UP/DN	gray - tan	A	in drivers door or dkp
RR WINDOW UP/DN	lt. blue - dk. blue	A	in drivers door or dkp

Notes:

*1 Also found low in the drivers side kick panel. *2 The factory alarm is located to the left of the steering column. *3 Also found at the rear of the instrument cluster.