

**Vehicle Wiring Information**  
for the  
**1986 Buick Riviera**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	yellow		ignition harness
SECOND STARTER			
IGNITION	pink		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	orange		ignition harness
SECOND ACCESSORY	brown		ignition harness
POWER LOCK +	lt blue	+	driver kick panel
POWER UNLOCK	black	+	driver kick panel
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		at switch or driver kick
PARKING LIGHTS -			
HEADLIGHTS	yellow		at switch
DOOR TRIGGER	white	-	underdash light
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE	black	+	at switch or driver kick
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	white		ignition coil
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

**Vehicle Wiring Information**  
for the  
**1987 Buick Riviera**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	lt. blue	+	either kick
POWER UNLOCK	black	+	either kick
PARKING LIGHTS +	brown		light switch
HEADLIGHTS	yellow	+	light switch
DOOR TRIGGER	white	-	at door jamb *2
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black or black/org	+	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green *3	-	either kick or alarm
TACHOMETER	purple/white		ignition module *1
BRAKE WIRE	lt. blue	+	brake switch
HORN TRIGGER	black	-	steering column
WIPERS	purple, gray	+	wiper switch
LF WINDOW UP/DN	blu - brown	A	switch in console
RF WINDOW UP/DN	dk. blue - tan	A	switch in console
LR WINDOW UP/DN			
RR WINDOW UP/DN			

**Notes:**

\*1 Located between engine and firewall on passenger side. Follow spark plug wires. 14 pin plug. \*2 Not interior illumination. Use lt. blue if equipped with factory alarm. \*3 The factory alarm is located to the left of the steering column.

## Vehicle Wiring Information

for the  
1988 Buick Riviera

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	(+)	ignition harness
STARTER	yellow	(+)	ignition harness
IGNITION	pink	(+)	ignition harness
SECOND IGNITION	blue/white	(+)	ignition harness
ACCESSORY	orange	(+)	ignition harness
SECOND ACCESSORY	purple/white	(+)	ignition harness
POWER LOCK	lt. blue	(+)	either kick
POWER UNLOCK	black	(+)	either kick
PARKING LIGHTS +	brown or purple	(+)	light switch
HEADLIGHTS	yellow	(+)	light switch
DOOR TRIGGER	white	(-)	at door jamb *2
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black or black/org	(+)	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green *3	(-)	either kick or alarm
TACHOMETER	purple/white		ignition module *1
BRAKE WIRE	lt. blue	(+)	brake switch
HORN TRIGGER	black	(-)	steering column
WIPERS	purple, gray	(+)	wiper switch
LF WINDOW UP/DN	blu - brown	(A)	switch in console
RF WINDOW UP/DN	dk. blue - tan	(A)	switch in console
LR WINDOW UP/DN			
RR WINDOW UP/DN			

**Notes:**

\*1 Located between engine and firewall on passenger side. Follow spark plug wires. 14 pin plug. \*2 Not interior illumination. Use lt. blue if equipped with factory alarm. \*3 The factory alarm is located to the left of the steering column.

## Vehicle Wiring Information

for the  
1989 Buick Riviera

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	lt. blue	+	either kick
POWER UNLOCK	black	+	either kick
PARKING LIGHTS +	brown or purple		light switch
HEADLIGHTS	yellow	+	light switch
DOOR TRIGGER	white	-	at door jamb *2
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black or black/org	+	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green *3	-	either kick or alarm
TACHOMETER	purple/white		ignition module *1
BRAKE WIRE	lt. blue	+	brake switch
HORN TRIGGER	black	-	steering column
WIPERS	purple, gray	+	wiper switch
LF WINDOW UP/DN	blu - brown	A	switch in console
RF WINDOW UP/DN	dk. blue - tan	A	switch in console
LR WINDOW UP/DN			
RR WINDOW UP/DN			

**Notes:**

\*1 Located between engine and firewall on passenger side. Follow spark plug wires. 14 pin plug. \*2 Not interior illumination. Use lt. blue if equipped with factory alarm. \*3 The factory alarm is located to the left of the steering column.

**Vehicle Wiring Information**  
for the  
**1990 Buick Riviera**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	lt. blue	+	leather kick
POWER UNLOCK	black	+	leather kick
PARKING LIGHTS	+ brown or purple		light switch
HEADLIGHTS	yellow	+	light switch
DOOR TRIGGER	white	-	at door jamb *2
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black or black/org	+	release switch
FCTRY ALARM ARM	arms with lock		
FCTRY ALRM DISARM	lt. green *3	-	leather kick or alarm
TACHOMETER	purple/white		ignition module *1
BRAKE WIRE	lt. blue	+	brake switch
HORN TRIGGER	black	-	steering column
WIPERS	purple, gray	+	wiper switch
LF WINDOW UP/DN	blu - brown	A	switch in console
RF WINDOW UP/DN	dk. blue - tan	A	switch in console
LR WINDOW UP/DN			
RR WINDOW UP/DN			

Notes:

\*1 Located between engine and firewall on passenger side. Follow spark plug wires. 14 pin plug. \*2 Not interior illumination. Use lt. blue if equipped with factory alarm. \*3 The factory alarm is located to the left of the steering column.

**Vehicle Wiring Information**  
for the  
**1991 Buick Riviera**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	yellow		ignition harness
SECOND STARTER			
IGNITION	pink		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	orange		ignition harness
SECOND ACCESSORY	brown		ignition harness
POWER LOCK	lt blue	+	driver kick panel
POWER UNLOCK	black	+	driver kick panel
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		at switch or driver kick
PARKING LIGHTS -			
HEADLIGHTS	yellow		at switch
DOOR TRIGGER	white	-	underdash light
DOVE SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black	+	at switch or driver kick
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	white		ignition coil
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: