

Vehicle Wiring Information
for the
1987 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black/white	+	at switch
FACTRY ALARM ARM			
FACTRY ALRM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1988 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black/white	+	at switch
FACTORY ALARM ARM			
FACTORY ALRM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1989 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black/white	+	at switch
FACTRY ALARM ARM			
FACTRY ALRM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1990 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE	black/white	+	at switch
FCTRY ALARM ARM			
FCTRY ALRM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1991 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black/white	+	at switch
FCTRY ALARM ARM			
FCTRY ALRM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1992 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	red	+	ignition harness
STARTER	yellow	+	ignition harness
IGNITION	pink	+	ignition harness
SECOND IGNITION	blue/white	+	ignition harness
ACCESSORY	orange	+	ignition harness
SECOND ACCESSORY	purple/white	+	ignition harness
POWER LOCK	blu/wht or wht/blu	+	driver kick panel
POWER UNLOCK	black/white	+	driver kick panel
PARKING LIGHTS +	*1		
PARKING LIGHTS -	*1		
HEADLIGHTS	gray *2	-	at switch
DOOR TRIGGER	white	-	door pin
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE	black/white	+	at switch
FACTORY ALARM ARM			
FACTORY ALARM DISARM	white/green	-	at theft module *3
TACHOMETER	white 20 awg		at coil pack
BRAKE WIRE			
HORN TRIGGER	black	-	steering column
WIPERS			
LF WINDOW UP/DN	brown - blue	A	at switch
RF WINDOW UP/DN	wht/brn - blue/wht	A	at switch

Notes:

*1 We have not yet verified a correct park light connection for this vehicle. Separate park light switch only works with key on, works through computer. There is a gray/black (-) at the light switch that gets the park lights and head lights - flashing halogen bulbs usually results in blown bulbs but use this wire if you must. *2 Low current required. Grounding this wire activates headlights, park lights, and dash lights. *3 Theft module is located in the right side of dash above the A/C and heater.

Vehicle Wiring Information
for the
1993 Cadillac Allante

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	yellow		ignition harness
SECOND STARTER			
IGNITION	pink		ignition harness
SECOND IGNITION	blu/wht or pur/wht		ignition harness
THIRD IGNITION			
ACCESSORY	orange		ignition harness
SECOND ACCESSORY	brown		ignition harness
POWER LOCK	blue/white	+	relay left of steering colmn
POWER UNLOCK	black/white	+	relay left of steering colmn
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +			
PARKING LIGHTS -	gry/blu or gry/blk		switch
HEADLIGHTS			
DOOR TRIGGER	orange	-	underdash light
DOVE SUPERVISION			
TRUNK/HATCH PIN	black/white	+	at switch
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM	green/white		
DISARM NO UNLOCK			
TACHOMETER	white		coil pack on pass. firewall
SPEED SENSE			
BRAKE WIRE	white		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: