

TRIPLE S *Customs*

CADILLAC SRX 2004-2005 VEHICLE WIRING

WIRING INFORMATION: 2004 Cadillac SRX

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	12V wires at the ignition harness are low current 12V sources that should not be used to drive any high current positive circuits. Must go to the battery for 12V.	
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
KEYSENSE WIRE (-)	LT.GREEN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	At Door Lock Switch Inside Driver Door
POWER DOOR UNLOCK (-)	ORANGE/BLACK	At Door Lock Switch Inside Driver Door
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	BROWN/WHITE	In Brown Plug At Module Under Glove Box
LEFT FRONT DOOR TRIGGER (-)	TAN	At Driver Door Module In Driver Door
RIGHT FRONT DOOR TRIGGER (-)	LT.GREEN	At Module Inside Right Front Door
LEFT REAR DOOR TRIGGER (-)	DK.BLUE/WHITE	At Module Inside Left Rear Door
RIGHT REAR DOOR TRIGGER (-)	YELLOW/BLACK	At Module Inside Right Rear Door
REAR HATCH TRIGGER (-)	ORANGE/BLACK	In Red Plug Ag Module In Right Rear Quarter Panel
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver Door Module Inside Driver Door
TACHOMETER WIRE	WHITE	At PCM On Passenger Side Of Engine Bay
BRAKE WIRE (+)	WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	TAN	At Module Under Glove Box
LEFT FRONT WINDOW UP	BLUE	At Driver Door Module Inside Driver Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Door Module Inside Driver Door
RIGHT FRONT WINDOW UP	BLUE	At Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	At Module Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	At Module Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	At Module Inside Right Rear Door
This vehicle is equipped with the Pass-Key III Immobilizer anti-theft system. This must be bypassed when installing a remote start system.		

WIRING INFORMATION: 2005 Cadillac SRX

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	12V wires at the ignition harness are low current 12V sources that should not be used to drive any high current positive circuits. Must go to the battery for 12V.	
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	PINK	Ignition Harness
ACCESSORY WIRE	ORANGE	Ignition Harness
SECOND ACCESSORY WIRE	BROWN	Ignition Harness
KEYSENSE WIRE (-)	LT.GREEN	Ignition Harness
POWER DOOR LOCK (-)	RED/BLACK	At Door Lock Switch Inside Driver Door
POWER DOOR UNLOCK (-)	ORANGE/BLACK	At Door Lock Switch Inside Driver Door
PARKING LIGHTS (+)	DO NOT USE	
PARKING LIGHTS (-)	BROWN/WHITE	In Brown Plug At Module Under Glove Box
LEFT FRONT DOOR TRIGGER (-)	TAN	At Driver Door Module In Driver Door
RIGHT FRONT DOOR TRIGGER (-)	LT.GREEN	At Module Inside Right Front Door
LEFT REAR DOOR TRIGGER (-)	DK.BLUE/WHITE	At Module Inside Left Rear Door
RIGHT REAR DOOR TRIGGER (-)	YELLOW/BLACK	At Module Inside Right Rear Door
REAR HATCH TRIGGER (-)	ORANGE/BLACK	In Red Plug Ag Module In Right Rear Quarter Panel
FACTORY ALARM DISARM (-)	LT.GREEN	At Driver Door Module Inside Driver Door
TACHOMETER WIRE	WHITE	At PCM On Passenger Side Of Engine Bay
BRAKE WIRE (+)	WHITE	Harness In Driver's Kick Panel
HORN TRIGGER (-)	TAN	At Module Under Glove Box
LEFT FRONT WINDOW UP	BLUE	At Driver Door Module Inside Driver Door
LEFT FRONT WINDOW DOWN	BROWN	At Driver Door Module Inside Driver Door
RIGHT FRONT WINDOW UP	BLUE	At Module Inside Right Front Door
RIGHT FRONT WINDOW DOWN	BROWN	At Module Inside Right Front Door
LEFT REAR WINDOW UP	BLUE	At Module Inside Left Rear Door
LEFT REAR WINDOW DOWN	BROWN	At Module Inside Left Rear Door
RIGHT REAR WINDOW UP	BLUE	At Module Inside Right Rear Door
RIGHT REAR WINDOW DOWN	BROWN	At Module Inside Right Rear Door
This vehicle is equipped with the Pass-Key III Immobilizer anti-theft system. This must be bypassed when installing a remote start system.		