

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA XSVI-2103, S3-SR1 + S3GM11CB		METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA XSVI-2103, S3-SR1 + S3GM11CB		METRA 40-GM10, SCOSCHE MDA-1B
Please verify all part numbers before ordering.			

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

Remote starter and security installations should be attempted by experienced security installers only. Information contained is accurate to the best of our knowledge and experience. Information contained is without any representation of warranty. It is the installer's responsibility to test and confirm all circuits with a digital multi-meter. Proper installation remains the responsibility of the installer. CarAlarmPros assumes no liability or responsibility resulting from an improper installation, even in reliance with the information contained in this guide.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA GMOS-LAN-03, S3-SR1 + S3GM11LB		METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not provide a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA GMOS-LAN-03, S3-SR1 + S3GM11LB		METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not supply a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA GMOS-LAN-03, S3-SR1 + S3GM11LB		METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			

### ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT WIRE	RED/BLACK	In Plug C3 At BCM On Front Passenger Side Of Center Console
STARTER WIRE 1(-)	YELLOW (Not For Remote Start)	In Blue Connector At PCM In Front Of Fuse Box In Engine Bay
<b>Notes:</b> The two Passlock wires (WHITE and WHITE/BLACK) function as key sense, second ignition, starter, and Passlock. Refer to TechDoc 3746		
IGNITION WIRE 1	YELLOW	Ignition Harness
ACCESSORY WIRE 1	BROWN	Ignition Harness
FACTORY ALARM ARM AND DISARM	Factory Remote Only	
TACHOMETER WIRE	NOT PINK or PINK/BLACK	Any Fuel Injector
BRAKE WIRE (+)	LT.BLUE	At Brake Pedal Switch
HORN TRIGGER (-)	TAN	Plug C2 At BCM On Front Passenger Side Of Center Console
POWER DOOR LOCK AND UNLOCK	WHITE	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console

**Notes:** Lock is a negative trigger. Unlock is negative trigger through a 1500-ohm resistor.

TRUNK RELEASE (-)	TAN	Release Switch Or Plug C2 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (+)	BROWN	Harness In Driver's Kick Panel Or Plug C3 At BCM On Front Passenger Side Of Center Console
PARKING LIGHTS (-)	BROWN/WHITE	Harness In Driver's Kick Panel Or Plug C2 At BCM On Front Passenger Side Of Center Console
LEFT FRONT DOOR TRIGGER (-)	GRAY/BLACK	Harness In Each Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
PASSENGER DOOR(S) TRIGGER (-)	TAN/WHITE	
DOMELIGHT SUPERVISION (-)	GRAY	Plug C3 At BCM On Front Passenger Side Of Center Console
TRUNK TRIGGER (-)	ORANGE/BLACK	Harness In Driver's Kick Panel Or Plug C1 At BCM On Front Passenger Side Of Center Console
LEFT FRONT WINDOW UP	DK.BLUE	At Switch Inside Door
LEFT FRONT WINDOW DOWN	BROWN	
RIGHT FRONT WINDOW UP	LT.BLUE	Harness In Driver's Kick From Driver's Door
RIGHT FRONT WINDOW DOWN	TAN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW UP	DK.GREEN	Harness In Driver's Kick From Driver's Door
LEFT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW UP	LT.GREEN	Harness In Driver's Kick From Driver's Door
RIGHT REAR WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver's Door

INTERFACE	PART NUMBER	NOTES
Immobilizer Bypass / Door Lock Module	457GW	Required when installing a remote start system
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V CONSTANT WIRE	RED/WHITE	Radio	
RADIO SWITCHED WIRE			The radio harness does not supply a switched power source
RADIO GROUND WIRE	BLACK/WHITE	Radio	
POWER ANTENNA WIRE	YELLOW	Radio	
AMP TURN-ON WIRE (+)	PINK	Radio	
LEFT FRONT SPEAKER (+)	TAN	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	GRAY	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	LT.GREEN	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	DK.GREEN	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	BROWN	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	YELLOW	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	DK.BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	LT.BLUE	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"		
RADIO DASH KIT OPTIONS	RADIO WIRE HARNESS OPTIONS		ANTENNA ADAPTER OPTIONS
METRA 99-3302, SCOSCHE GM1587B	METRA GMOS-LAN-03, S3-SR1 + S3GM11LB		METRA 40-CR10, SCOSCHE CRAB
Please verify all part numbers before ordering.			