

TRIPLE S *Customs*

CHEVROLET PRIZM 1998-2002 VEHICLE WIRING

WIRING INFORMATION 1998 Chevy Prizm

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-) **Test by using key in passenger lock cylinder**	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-) **Test by using key in passenger lock cylinder**	GREEN/WHITE	Connector On Right Side Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 1999 Chevy Prizm

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-) **Test by using key in passenger lock cylinder**	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-) **Test by using key in passenger lock cylinder**	GREEN/WHITE	Connector On Right Side Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 2000 Chevy Prizm

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-) **Test by using key in passenger lock cylinder**	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-) **Test by using key in passenger lock cylinder**	GREEN/WHITE	Connector On Right Side Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 2001 Chevy Prizm

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-) **Test by using key in passenger lock cylinder**	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-) **Test by using key in passenger lock cylinder**	GREEN/WHITE	Connector On Right Side Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick Panel From Driver Door

WIRING INFORMATION 2002 Chevy Prizm

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	BLACK/YELLOW	Ignition Harness
SECOND IGNITION WIRE	BLACK/WHITE	Ignition Harness
ACCESSORY WIRE	BLUE/RED	Ignition Harness
STARTER WIRE	RED	Ignition Harness
PARKING LIGHTS (+)	GREEN	Harness At Bottom Of Fuse Box
POWER DOOR LOCK (-) **Test by using key in passenger lock cylinder**	BLUE/BLACK	Connector On Right Side Of Fuse Box
POWER DOOR UNLOCK (-) **Test by using key in passenger lock cylinder**	GREEN/WHITE	Connector On Right Side Of Fuse Box
DOOR TRIGGER (-)	RED/WHITE	Harness At Rear Of Fuse Box
TRUNK TRIGGER (-)	RED/WHITE	At Light In Trunk
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
TACHOMETER	YELLOW/GREEN or RED/BLUE	At Ignition Coil
BRAKE WIRE (+)	GREEN/WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED	Harness At Steering Column
LEFT FRONT WINDOW UP	YELLOW	At Motor Inside Driver's Door
LEFT FRONT WINDOW DOWN	GREEN	At Motor Inside Driver's Door
RIGHT FRONT WINDOW UP	GREEN/RED	Harness In Driver's Kick Panel From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE/WHITE	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW UP	RED/GREEN	Harness In Driver's Kick Panel From Driver Door
LEFT REAR WINDOW DOWN	BLUE/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW UP	RED/BLACK	Harness In Driver's Kick Panel From Driver Door
RIGHT REAR WINDOW DOWN	BLUE/RED	Harness In Driver's Kick Panel From Driver Door