

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA

Please verify all part numbers before ordering.

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			

ALARM REMOTE START WIRING

WIRE	COLOR	LOCATION
12V CONSTANT	WHITE	Ignition harness
12V IGNITION	BLACK/WHITE	Ignition harness
12V ACCESSORY	BLUE/BLACK	Ignition harness
STARTER	BLACK/RED	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness in Driver's Kick Panel
PARKING LIGHTS (-)	GREEN/WHITE	Harness At Steering Column
POWER LOCK (-)	RED/BLUE	Harness Behind Glove Box
POWER UNLOCK (-)	BROWN/RED	Harness Behind Glove Box
Notes: Door lock wires can sometimes be found under the dash to the left of the steering column in a small 4-wire plug taped to a harness		
DOOR TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel
Notes: The RED/GREEN door trigger wire has a delay. To avoid the dome light delay use RED/WHITE (-) at the door ajar indicator behind the instrument cluster. This wire will catch all doors plus the trunk.		
DOMELIGHT SUPERVISION (-)		Use door trigger
TRUNK TRIGGER (-)	RED/GREEN	Harness In Driver Kick Panel Or Light In Trunk
HOOD TRIGGER (-)	BLUE/BLACK	Pin Switch Under hood
FACTORY ALARM ARM	Arms with lock	
FACTORY ALARM DISARM	Disarms with unlock	
FACTORY DISARM NO UNLOCK (-)	GREEN/WHITE	Harness Coming Into Vehicle From Driver Door
TACHOMETER	WHITE	Behind Instrument Cluster
BRAKE WIRE (+)	GREEN/WHITE	Brake switch
HORN TRIGGER (-)	GREEN/BLACK	Steering column
LEFT FRONT WINDOW UP	GREEN/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN/BLACK	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/YELLOW	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	GREEN/YELLOW	Harness In Driver's Kick From Driver Door

INTERFACE	PART NUMBER	NOTES
None required	NA	NA
Please verify all part numbers before ordering.		

AUDIO WIRING			
WIRE	COLOR	LOCATION	NOTES
RADIO 12V	RED	Radio Harness	
RADIO SWITCHED	BLUE	Radio Harness	
RADIO GROUND	BLACK/YELLOW	Radio Harness	
ILLUMINATION (+)	GREEN/YELLOW	Radio Harness	
POWER ANTENNA (+)		Radio Harness	
AMP TURN ON (+)		Radio Harness	
LEFT FRONT SPEAKER(+)	WHITE/BLUE	Radio Harness or Speaker	
LEFT FRONT SPEAKER (-)	BLACK/BLUE	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (+)	WHITE/RED	Radio Harness or Speaker	
RIGHT FRONT SPEAKER (-)	BLACK/RED	Radio Harness or Speaker	
LEFT REAR SPEAKER (+)	YELLOW/BLUE	Radio Harness or Speaker	
LEFT REAR SPEAKER (-)	GRAY/BLUE	Radio Harness or Speaker	
RIGHT REAR SPEAKER (+)	YELLOW/RED	Radio Harness or Speaker	
RIGHT REAR SPEAKER (-)	GRAY/RED	Radio Harness or Speaker	
FRONT SPEAKERS SIZE	REAR SPEAKERS SIZE	AMP LOCATION	NOTES
6.5"	6x9"	Under Rear Deck	
RADIO DASH KIT OPTIONS		RADIO WIRE HARNESS OPTIONS	ANTENNA ADAPTER OPTIONS
METRA 99-6501, SCOSCHE CJ1282B		METRA 70-1817, SCOSCHE CR01B	Not required
Please verify all part numbers before ordering.			