

# **TRIPLE S** *Customs*

## **DODGE DYNASTY 1990-1993 VEHICLE WIRING**

WIRING INFORMATION: 1990 Dodge Dynasty

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED or PINK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (+)	ORANGE/PURPLE or ORANGE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	TAN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	DARK BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	DARK BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	DARK GREEN	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1991 Dodge Dynasty

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED, PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (+)	ORANGE/PURPLE or ORANGE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1992 Dodge Dynasty

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED, PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (+)	ORANGE/PURPLE or ORANGE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION: 1993 Dodge Dynasty

WIRE	WIRE COLOR	WIRE LOCATION
12V CONSTANT WIRE	RED, PINK/BLACK	Ignition Harness
STARTER WIRE	YELLOW	Ignition Harness
IGNITION WIRE	DK. BLUE	Ignition Harness
ACCESSORY WIRE	BLACK/ORANGE	Ignition Harness
POWER DOOR LOCK (+)	ORANGE/PURPLE or ORANGE/WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (+)	PINK/PURPLE	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	BLACK/YELLOW	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	YELLOW	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	BROWN/BLACK	Harness In Driver's Kick Panel
TRUNK RELEASE (+)	BLACK/WHITE	At Trunk Release Switch
FACTORY ALARM ARM	ARMS WITH LOCK	
FACTORY ALARM DISARM (-)	LT.GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BLACK/GRAY	At Ignition Coil
BRAKE WIRE (+)	WHITE	At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/RED	At Relay At Fuse Box
LEFT FRONT WINDOW UP	LT.BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	WHITE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BROWN/WHITE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	PURPLE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GRAY/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door