

# **TRIPLE S** *Customs*

## **DODGE MAGNUM 2005-2006 VEHICLE WIRING**

WIRING INFORMATION: 2005 Dodge Magnum

| WIRE   | WIRE COLOR  | WIRE LOCATION                           |
|--|---|---|
| 12V CONSTANT WIRE  | Must go to battery for 12V constant.                              |   |
| STARTER WIRE   | PINK/DK.GREEN   | Ignition Harness                        |
| SECOND STARTER WIRE  | PURPLE/BROWN  | Ignition Harness                        |
| The second starter wire is a negative trigger through a 180-ohm resistor.  |   |   |
| IGNITION WIRE  | PINK/WHITE  | Ignition Harness                        |
| ACCESSORY WIRE   | PURPLE/BROWN  | Ignition Harness                        |
| The accessory wire is the same wire as the second starter wire. The accessory wire is a negative trigger through a 610-ohm resistor.   |   |   |
| POWER DOOR LOCK AND UNLOCK   | PURPLE/DK.GREEN   | Harness In Driver's Kick Panel          |
| Lock is a negative trigger through a 330-ohm resistor. Unlock is negative trigger through a 100-ohm resistor.  |   |   |
| PARKING LIGHTS (+)   | WHITE/PURPLE  | Brown Connector In Passenger Kick Panel |
| PARKING LIGHTS (-)   | WHITE/BROWN   | At Light Switch                         |
| Parking light wire is a negative trigger through a 1670-ohm resistor. A relay must be used to isolate away from the switch.  |   |   |
| LEFT FRONT DOOR TRIGGER (-)  | PURPLE  | Harness In Driver's Kick Panel          |
| RIGHT FRONT DOOR TRIGGER (-)   | PURPLE/WHITE  | Harness In Passenger Kick Panel         |
| LEFT REAR DOOR TRIGGER (-)   | PURPLE/GRAY   | Harness In Driver's Kick Panel          |
| RIGHT REAR DOOR TRIGGER (-)  | PURPLE/YELLOW   | Harness In Passenger Kick Panel         |
| DOMELIGHT SUPERVISION (-)  | YELLOW/WHITE  | In Passenger "A" Pillar                 |
| TRUNK TRIGGER (-)  | PURPLE/ORANGE   | Harness In Passenger Kick Panel         |
| TRUNK RELEASE  | PURPLE/TAN  | At Trunk Release Switch                 |
| FACTORY ALARM ARM  | Arms when lock switch is pressed with door open                   |   |
| FACTORY ALARM DISARM   | Disarms with factory remote                                       |   |
| FACTORY DISARM NO UNLOCK   | Disarms when ignition is turned on and Immobilizer key is present |   |
| TACHOMETER WIRE  | Wire NOT BROWN/YELLOW   | At Any Ignition Coil                    |
| BRAKE WIRE (+)   | DK.GREEN/WHITE  | At Brake Pedal Switch                   |
| HORN TRIGGER (+)   | DK.GREEN/ORANGE   | At Horn                                 |
| LEFT FRONT WINDOW UP   | ORANGE/LT.GREEN   | Motor In Left Front Door                |
| LEFT FRONT WINDOW DOWN   | ORANGE/WHITE  | Motor In Left Front Door                |
| Base model vehicles use ORANGE/WHITE for UP and ORANGE/LT.GREEN for DOWN found in the harness coming into the vehicle from the left front door.  |   |   |
| RIGHT FRONT WINDOW UP  | DK.BLUE/ORANGE  | Motor In Right Front Door               |
| RIGHT FRONT WINDOW DOWN  | LT.GREEN/ORANGE   | Motor In Right Front Door               |
| Base model vehicles use ORANGE/GRAY for UP and ORANGE/TAN for DOWN found in the harness coming into the vehicle from the right front door.   |   |   |
| LEFT REAR WINDOW UP  | ORANGE/GRAY   | Harness In Driver's Kick Panel          |
| LEFT REAR WINDOW DOWN  | ORANGE/WHITE  |   |
| RIGHT REAR WINDOW UP   | ORANGE/DK.BLUE  |   |
| RIGHT REAR WINDOW DOWN   | ORANGE/LT.BLUE  |   |
| <b>NOTE: This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.</b>  |   |   |
| RADIO 12V CONSTANT WIRE  | GRAY/LT. GREEN  | Radio Harness                           |
| RADIO SWITCHED WIRE  | The radio harness does not provide a switched power source        |   |
| RADIO GROUND WIRE  | BLACK/LT. GREEN   |   |
| POWER ANTENNA WIRE   |   |   |
| AMP TURN-ON WIRE   |   |   |
| LEFT FRONT SPEAKER (+)   | GRAY/PURPLE   | Left Front Speaker                      |
| LEFT FRONT SPEAKER (-)   | GRAY/YELLOW   | Left Front Speaker                      |
| RIGHT FRONT SPEAKER (+)  | DK. GREEN/PURPLE  | Right Front Speaker                     |
| RIGHT FRONT SPEAKER (-)  | DK. GREEN/YELLOW  | Right Front Speaker                     |
| If equipped: LF dash (+) is GRAY/ORANGE. LF dash (-) is GRAY/YELLOW. Center dash (+) is GRAY/BROWN. Center dash (-) is GRAY/ORANGE. RF dash (+) is GRAY/GREEN. RF dash (-) GRAY/LT.GREEN |   |   |
| LEFT REAR SPEAKER (+)  | DK. GREEN/TAN   | Left Rear Speaker                       |
| LEFT REAR SPEAKER (-)  | GREEN/GRAY  | Left Rear Speaker                       |
| RIGHT REAR SPEAKER (+)   | DK. GREEN/BROWN   | Right Rear Speaker                      |
| RIGHT REAR SPEAKER (-)   | YELLOW/GRAY   | Right Rear Speaker                      |
| If equipped: Subwoofer (+) is GRAY/BROWN. Subwoofer (-) is GREEN/BROWN   |   |   |
| Factory amplifier is under the dash on the driver's side.  |   |   |

WIRING INFORMATION: 2006 Dodge Magnum

| WIRE   | WIRE COLOR  | WIRE LOCATION                           |
|--|---|---|
| 12V CONSTANT WIRE  | Must go to battery for 12V constant.                              |   |
| STARTER WIRE   | PINK/DK.GREEN   | Ignition Harness                        |
| SECOND STARTER WIRE  | PURPLE/BROWN  | Ignition Harness                        |
| The second starter wire is a negative trigger through a 180-ohm resistor.  |   |   |
| IGNITION WIRE  | PINK/WHITE  | Ignition Harness                        |
| ACCESSORY WIRE   | PURPLE/BROWN  | Ignition Harness                        |
| The accessory wire is the same wire as the second starter wire. The accessory wire is a negative trigger through a 610-ohm resistor.   |   |   |
| POWER DOOR LOCK AND UNLOCK   | PURPLE/DK.GREEN   | Harness In Driver's Kick Panel          |
| Lock is a negative trigger through a 330-ohm resistor. Unlock is negative trigger through a 100-ohm resistor.  |   |   |
| PARKING LIGHTS (+)   | WHITE/PURPLE  | Brown Connector In Passenger Kick Panel |
| PARKING LIGHTS (-)   | WHITE/BROWN   | At Light Switch                         |
| Parking light wire is a negative trigger through a 1670-ohm resistor. A relay must be used to isolate away from the switch.  |   |   |
| LEFT FRONT DOOR TRIGGER (-)  | PURPLE  | Harness In Driver's Kick Panel          |
| RIGHT FRONT DOOR TRIGGER (-)   | PURPLE/WHITE  | Harness In Passenger Kick Panel         |
| LEFT REAR DOOR TRIGGER (-)   | PURPLE/GRAY   | Harness In Driver's Kick Panel          |
| RIGHT REAR DOOR TRIGGER (-)  | PURPLE/YELLOW   | Harness In Passenger Kick Panel         |
| DOMELIGHT SUPERVISION (-)  | YELLOW/WHITE  | In Passenger "A" Pillar                 |
| TRUNK TRIGGER (-)  | PURPLE/ORANGE   | Harness In Passenger Kick Panel         |
| TRUNK RELEASE  | PURPLE/TAN  | At Trunk Release Switch                 |
| FACTORY ALARM ARM  | Arms when lock switch is pressed with door open                   |   |
| FACTORY ALARM DISARM   | Disarms with factory remote                                       |   |
| FACTORY DISARM NO UNLOCK   | Disarms when ignition is turned on and Immobilizer key is present |   |
| TACHOMETER WIRE  | Wire NOT BROWN/YELLOW   | At Any Ignition Coil                    |
| BRAKE WIRE (+)   | DK.GREEN/WHITE  | At Brake Pedal Switch                   |
| HORN TRIGGER (+)   | DK.GREEN/ORANGE   | At Horn                                 |
| LEFT FRONT WINDOW UP   | ORANGE/LT.GREEN   | Motor In Left Front Door                |
| LEFT FRONT WINDOW DOWN   | ORANGE/WHITE  | Motor In Left Front Door                |
| Base model vehicles use ORANGE/WHITE for UP and ORANGE/LT.GREEN for DOWN found in the harness coming into the vehicle from the left front door.  |   |   |
| RIGHT FRONT WINDOW UP  | DK.BLUE/ORANGE  | Motor In Right Front Door               |
| RIGHT FRONT WINDOW DOWN  | LT.GREEN/ORANGE   | Motor In Right Front Door               |
| Base model vehicles use ORANGE/GRAY for UP and ORANGE/TAN for DOWN found in the harness coming into the vehicle from the right front door.   |   |   |
| LEFT REAR WINDOW UP  | ORANGE/GRAY   | Harness In Driver's Kick Panel          |
| LEFT REAR WINDOW DOWN  | ORANGE/WHITE  |   |
| RIGHT REAR WINDOW UP   | ORANGE/DK.BLUE  |   |
| RIGHT REAR WINDOW DOWN   | ORANGE/LT.BLUE  |   |
| <b>NOTE: This vehicle is equipped with a factory Immobilizer system. This must be bypassed when installing a remote start system.</b>  |   |   |
| RADIO 12V CONSTANT WIRE  | GRAY/LT. GREEN  | Radio Harness                           |
| RADIO SWITCHED WIRE  | The radio harness does not provide a switched power source        |   |
| RADIO GROUND WIRE  | BLACK/LT. GREEN   |   |
| POWER ANTENNA WIRE   |   |   |
| AMP TURN-ON WIRE   |   |   |
| LEFT FRONT SPEAKER (+)   | GRAY/PURPLE   | Left Front Speaker                      |
| LEFT FRONT SPEAKER (-)   | GRAY/YELLOW   | Left Front Speaker                      |
| RIGHT FRONT SPEAKER (+)  | DK. GREEN/PURPLE  | Right Front Speaker                     |
| RIGHT FRONT SPEAKER (-)  | DK. GREEN/YELLOW  | Right Front Speaker                     |
| If equipped: LF dash (+) is GRAY/ORANGE. LF dash (-) is GRAY/YELLOW. Center dash (+) is GRAY/BROWN. Center dash (-) is GRAY/ORANGE. RF dash (+) is GRAY/GREEN. RF dash (-) GRAY/LT.GREEN |   |   |
| LEFT REAR SPEAKER (+)  | DK. GREEN/TAN   | Left Rear Speaker                       |
| LEFT REAR SPEAKER (-)  | GREEN/GRAY  | Left Rear Speaker                       |
| RIGHT REAR SPEAKER (+)   | DK. GREEN/BROWN   | Right Rear Speaker                      |
| RIGHT REAR SPEAKER (-)   | YELLOW/GRAY   | Right Rear Speaker                      |
| If equipped: Subwoofer (+) is GRAY/BROWN. Subwoofer (-) is GREEN/BROWN   |   |   |
| Factory amplifier is under the dash on the driver's side.  |   |   |