

**Vehicle Wiring Information**  
for the  
**1998 Dodge Viper (UK)**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	yellow		ignition harness
SECOND STARTER			
IGNITION	blue		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY			
SECOND ACCESSORY			
POWER LOCK	white/green *1	+	grey plug, o/e alarm *2
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	green & lt brown		at column loom
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	blk/blu & brn/red	-	blue plug, o/e alarm *2
DOME SUPERVISION			
TRUNK/HATCH PIN	grey/black		blue plug, o/e alarm *2
HOOD PIN	brown/tan		blue plug, o/e alarm *2
TRNK/HTCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

\*1 Pulse to lock and pulse to unlock. To pop open each door via remote the connections are as follows: driver door pin 12 and driver door pin 11 pink/white at o/e alarm