

Vehicle Wiring Information
for the
1996 Dodge Viper GTS

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	yellow		ignition harness
SECOND STARTER			
IGNITION	blue		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY			
SECOND ACCESSORY			
POWER LOCK	white/green *1	+	right of steering column
POWER UNLOCK	same wire		
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	black/yellow		right of steering column
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	yellow	-	behind fuse panel
DOME SUPERVISION			
TRUNK/HATCH PIN	gray/black		at switch
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN	white - blue		
RF WINDOW UP/DN	purple - brown		
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

* Pulse once to lock doors, pulse again to unlock doors.