

**Vehicle Wiring Information**  
for the  
**1996 Eagle Summit**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white	+	ignition harness
STARTER	black/yellow	+	ignition harness
IGNITION	black/white	+	ignition harness
SECOND IGNITION			
ACCESSORY	blue/black	+	ignition harness
POWER LOCK	brown/white	-	rear of relay box L of colum
POWER UNLOCK	brown/blue	-	rear of relay box L of colum
PARKING LIGHTS +	green/white		dimmer control
PARKING LIGHTS -	green/yellow		steering column
HEADLIGHTS	red/yellow	-	steering column
DOOR TRIGGER	black	-	left 'A' pillar
TRUNK/HATCH PIN	red/green	-	at light in trunk
TACHOMETER	white		ignition coil *1
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/red	-	column wht. 3 pin plug
WIPERS	blue	+	steering column
LF WINDOW UP/DN	grn/red - grn/blk	A	in drivers door
RF WINDOW UP/DN	red/yel - grn/yel	A	in drivers door
LR WINDOW UP/DN	red/grn - green	A	in drivers door
RR WINDOW UP/DN	red/blu - grn/blu	A	in drivers door

Notes:

\*1 Also can be found in a black plug behind glove box above pass. kick panel.

**Vehicle Wiring Information**  
for the  
**1995 Eagle Summit**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white	+	ignition harness
STARTER	black/yellow	+	ignition harness
IGNITION	black/white	+	ignition harness
SECOND IGNITION			
ACCESSORY	blue/black	+	ignition harness
POWER LOCK	brown/white	-	rear of relay box L of colum
POWER UNLOCK	brown/blue	-	rear of relay box L of colum
PARKING LIGHTS +	green/white		dimmer control
PARKING LIGHTS -	green/yellow		steering column
HEADLIGHTS	red/yellow	-	steering column
DOOR TRIGGER	black	-	left 'A' pillar
TRUNK/HATCH PIN	red/green	-	at light in trunk
TACHOMETER	white		ignition coil *1
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/red	-	column wht. 3 pin plug
WIPERS	blue	+	steering column
LF WINDOW UP/DN	grn/red - grn/blk	A	in drivers door
RF WINDOW UP/DN	red/yel - grn/yel	A	in drivers door
LR WINDOW UP/DN	red/grn - green	A	in drivers door
RR WINDOW UP/DN	red/blu - grn/blu	A	in drivers door

Notes:

\*1 Also can be found in a black plug behind glove box above pass. kick panel.

**Vehicle Wiring Information**  
for the  
**1994 Eagle Summit**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	white	+	ignition harness
STARTER	black/yellow	+	ignition harness
IGNITION	black/white	+	ignition harness
SECOND IGNITION			
ACCESSORY	blue/black	+	ignition harness
POWER LOCK	brown/white	-	rear of relay box L of colum
POWER UNLOCK	brown/blue	-	rear of relay box L of colum
PARKING LIGHTS +	green/white		dimmer control
PARKING LIGHTS -	green/yellow		steering column
HEADLIGHTS	red/yellow	-	steering column
DOOR TRIGGER	black	-	left 'A' pillar
TRUNK/HATCH PIN	red/green	-	at light in trunk
TACHOMETER	white		ignition coil *1
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/red	-	column wht. 3 pin plug
WIPERS	blue	+	steering column
LF WINDOW UP/DN	grn/red - grn/blk	A	in drivers door
RF WINDOW UP/DN	red/yel - grn/yel	A	in drivers door
LR WINDOW UP/DN	red/grn - green	A	in drivers door
RR WINDOW UP/DN	red/blu - grn/blu	A	in drivers door

Notes:

\*1 Also can be found in a black plug behind glove box above pass. kick panel.

**Vehicle Wiring Information**  
for the  
**1993 Eagle Summit**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	black/yellow		ignition harness
SECOND STARTER			
IGNITION	black/white		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	blue/black		ignition harness
SECOND ACCESSORY			
POWER LOCK	brown/white	-	passenger kick panel
POWER UNLOCK	brown/blue	-	passenger kick panel
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +			
PARKING LIGHTS -	green/yellow		at the steering column
HEADLIGHTS			
DOOR TRIGGER	red/green	-	driver kick panel
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER	white		ignition coil
SPEED SENSE			
BRAKE WIRE	green		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

**Vehicle Wiring Information**  
for the  
**1992 Eagle Summit**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	black/yellow		ignition harness
SECOND STARTER			
IGNITION	black/white		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	white		ignition harness
SECOND ACCESSORY			
POWER LOCK	black/blue/silver	-	relay pack in fusebox
POWER UNLOCK	black/green/silver	-	relay pack in fusebox
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +			
PARKING LIGHTS -	gray		right of steering column
HEADLIGHTS			
DOOR TRIGGER	black	-	2 wire wht conn in fusebox
DOVE SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE			
HORN TRIGGER	green/black	-	steering column
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			