

Vehicle Wiring Information
for the
1989 Ford Escort

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	yellow	+	ignition harness
STARTER	white/pink	+	ignition harness
IGNITION	red/green	+	ignition harness
ACCESSORY	gray/yellow	+	ignition harness
SECOND ACCESSORY	black/lt green	+	ignition harness
POWER LOCK			
POWER UNLOCK			
PARKING LIGHTS +	brown		behind fuse box
PARKING LIGHTS -			
HEADLIGHTS	pink/yellow	+	headlight switch
DOOR TRIGGER	black/lt. blue	+	drivers kick panel
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
TACHOMETER			
BRAKE WIRE			
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			

Notes:

Vehicle Wiring Information
for the
1988 Ford Escort

ITEM	WIRE COLOR	POL.	WIRE LOCATION
12V			
STARTER	red/blue		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY			
POWER LOCK			
POWER UNLOCK			
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		driver kick panel
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	driver kick panel
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE	red/green		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

Vehicle Wiring Information
for the
1987 Ford Escort

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blue		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY			
POWER LOCK			
POWER UNLOCK			
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		driver kick panel
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	driver kick panel
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HTCH RELEASE			
FCTRY ALARM ARM			
FCTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE	red/green		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes:

Vehicle Wiring Information
for the
1986 Ford Escort

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V			
STARTER	red/blue		ignition harness
SECOND STARTER			
IGNITION	red/green		ignition harness
SECOND IGNITION			
THIRD IGNITION			
ACCESSORY	gray/yellow		ignition harness
SECOND ACCESSORY			
POWER LOCK			
POWER UNLOCK			
LOCK MOTOR			
UNLOCK MOTOR			
DISARM DEFEAT			
PARKING LIGHTS +	brown		driver kick panel
PARKING LIGHTS -			
HEADLIGHTS			
DOOR TRIGGER	black/blue	+	driver kick panel
DOME SUPERVISION			
TRUNK/HATCH PIN			
HOOD PIN			
TRNK/HATCH RELEASE			
FACTRY ALARM ARM			
FACTRY ALRM DISARM			
DISARM NO UNLOCK			
TACHOMETER			
SPEED SENSE			
BRAKE WIRE	red/green		brake pedal switch
HORN TRIGGER			
WIPERS			
LF WINDOW UP/DN			
RF WINDOW UP/DN			
LR WINDOW UP/DN			
RR WINDOW UP/DN			
SUN RF OPEN/CLOSE			
SUN ROOF LIMIT			
RADIO 12V			
RADIO GROUND			
RADIO SWITCH			
RADIO ILLUMINATE			
POWER ANTENNA			
LF SPEAKER			
RF SPEAKER			
LR SPEAKER			
RR SPEAKER			

Notes: