

## Vehicle Wiring Information

for the  
1996 Ford Escort

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOME SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

**Notes:**

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick. All other models will have a red at the rear light.

**Vehicle Wiring Information**  
for the  
**1995 Ford Escort**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOVE SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

Notes:

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick.  
All other models will have a red at the rear light.

**Vehicle Wiring Information**  
for the  
**1994 Ford Escort**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOME SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

**Notes:**

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick. All other models will have a red at the rear light.

**Vehicle Wiring Information**  
for the  
**1993 Ford Escort**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOVE SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

Notes:

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick. All other models will have a red at the rear light.

**Vehicle Wiring Information**  
for the  
**1992 Ford Escort**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOME SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

Notes:

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick.  
All other models will have a red at the rear light.

**Vehicle Wiring Information**  
for the  
**1991 Ford Escort**

ITEM	WIRE COLOR	POL	WIRE LOCATION
12V	black	+	ignition harness
STARTER	black/blue	+	ignition harness
IGNITION	blue	+	ignition harness
ACCESSORY	black/red	+	ignition harness
POWER LOCK	add actuator		to drivers door
POWER UNLOCK	add actuator		to drivers door
PARKING LIGHTS +	red/black		above kick at relays
PARKING LIGHTS -	lt. green		steering column
HEADLIGHTS	blue/yellow	-	steering column
DOOR TRIGGER	red/wht or pnk/yel	-	low in drivers kick
DOVE SUPERVISION	use door trigger		
TRUNK/HATCH PIN	red or red/yel	-	*1
TACHOMETER	yel/blue or grn/yel		ignition coil
BRAKE WIRE	green	+	brake switch
HORN TRIGGER	green/orange	-	at column
WIPERS			
LF WINDOW UP/DN	red/blk - red/green	A	drivers window switch
RF WINDOW UP/DN	grn/wht - red/wht	A	drivers door harness
LR WINDOW UP/DN	grn/yel - wht/red	A	drivers door harness
RR WINDOW UP/DN	blu/wht - yel/wht	A	drivers door harness

Notes:

\*1 On models with an ajar indicator in the dash, find a red/yellow low in the drivers kick.  
All other models will have a red at the rear light.